

Advance copy for use in  
Ordnance Office only.  
Regular distribution by  
A. G. O. to follow.

UNCLASSIFIED

TM 9-1750G

ART CHECKED BY TYPO.

RESTRICTED

NOV 30 1942

WAR DEPARTMENT

TECHNICAL MANUAL

8

ORDNANCE MAINTENANCE

GENERAL MOTORS TWIN DIESEL  
6-71 POWER PLANT FOR MEDIUM  
TANKS M3A3, M3A5, AND M4A2

SEPTEMBER 1, 1942

LIBRARY,  
PUBLICATIONS DEPT  
BARITAN ARSENAL.

REGRADED UNCLASSIFIED BY

AUTHORITY OF DOD DIR. 5200.1 R

BY PAKAS ON 013/26

TECHNICAL DATA  
PUBLICATIONS DIV.

UNCLASSIFIED

ORDNANCE MAINTENANCE

GENERAL MOTORS TWIN DIESEL 6-71 POWER PLANT  
FOR MEDIUM TANKS M3A3, M3A5, AND M4A2

Prepared under the direction of the  
Chief of Ordnance

CONTENTS

SECTION		Paragraphs	Pages
I:	Introduction	1- 3	2
II:	Engine	4- 29	3- 39
III:	Engine trouble shooting	30- 32	40
IV:	Removal of engine assembly from tank	33	41
V:	Disassembly of the engine	34- 68	42-104
VI:	Disassembly, inspection, serv- ice, repair, and assembly of subassemblies	69-139	105-177
VII:	Assembly of the engine	140-180	178-220
VIII:	Air inlet housing and blower assemblies	181-191	221-243
IX:	Water pump assembly	192-200	244-248
X:	Fuel pump assembly	201-209	249-255
XI:	Governor assembly	210-226	256-264
XII:	Injector assembly	227-235	265-281
XIII:	Oil cooler and adapter assembly	236-244	282-285
XIV:	Air heater assemblies	245-253	286-289
XV:	Engine transfer gear housing assembly	254-262	290-298
XVI:	Clutch housing and clutch assemblies	263-275	299-309
XVII:	Propeller shaft assembly	276-284	310-313
XVIII:	Starting motor and solenoid switch assemblies	285-295	314-326
XIX:	Generator assembly	296-305	327-335
XX:	Installation of engine assembly in tank	306	336
XXI:	Preparation of engine for use under unusual conditions	307	337
XXII:	Decontamination	308	338
XXIII:	Instructions for packing, ship- ment, and storage	309-312	339-341.
XXIV:	Clearances, tolerances, and spe- cial tools	313-315	342-356
XXV:	References	316-318	357
INDEX			358-368

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section I**

**INTRODUCTION**

	<b>Paragraph</b>
<b>Purpose and scope</b> .....	<b>1</b>
<b>Content and arrangement of the manual</b> .....	<b>2</b>
<b>References</b> .....	<b>3</b>

**1. PURPOSE AND SCOPE.**

These instructions are published for the information and guidance of the ordnance personnel charged with the maintenance and repair of this materiel. They contain a description of the General Motors 6-71 dual Diesel Engine Model 6046 for Medium Tanks M3A3, M3A5 and M4A2, all of its component parts and accessories, and the clutch and propeller shaft, as well as detailed instructions for their disassembly, inspection, servicing, and assembly.

**2. CONTENT AND ARRANGEMENT OF THE MANUAL.**

Section I covers the purpose and scope of the manual and gives references to other technical manuals. Sections II to XXIV give information for ordnance personnel on the maintenance of the engine, its accessories, and the propeller shaft and universal joints.


**3. REFERENCES.**

Section XXV at the end of this technical manual lists all standard nomenclature lists, technical manuals, and other publications for the materiel described herein. This power plant is used on three models of medium tanks. Information concerning Medium Tank M3A3 and M3A5 will be found in TM9-753 and that concerning Medium Tank M4A2 in TM9-758.

Section II

ENGINE

	Paragraph
Serial numbers .....	4
Model designation .....	5
General .....	6
The Diesel principle .....	7
Cylinder block and crankcase .....	8
End plates .....	9
Cylinder liners .....	10
Main bearings .....	11
Crankshaft .....	12
Flywheel .....	13
Pistons .....	14
Connecting rods .....	15
Gear train .....	16
Camshaft and balance shaft .....	17
Engine gear train timing .....	18
Engine balance .....	19
Cylinder head .....	20
Valve and injector operating mechanism .....	21




RA PD 11146

Figure 1—Three-quarter Rear View of Power Plant



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11136

*Figure 2—Three-quarter Front View of Power Plant*

## ENGINE

	Paragraph
Lubrication system .....	22
Air intake system .....	23
Fuel system .....	24
Governor .....	25
Cooling system .....	26
Tabulated data .....	27
Reference to TM 9-753 .....	28
Echelon breakdown of maintenance operations .....	29

### 4. SERIAL NUMBERS.

Power plant serial numbers start with 6046-1 and run consecutively. The power plant serial number appears on a plate on the transfer gear housing. Individual engine serial numbers are not available.

### 5. MODEL DESIGNATION (figs. 1 through 14).

**NOTE:** The term power plant is used to designate the twin engine assembly. Individually, the engines are designated as Model 671LA24M and Model 671LC24M. In the following description and throughout this manual all references to the left and right side of the power plant or of either engine are established as follows: The fan end is the rear end and the left side is that side nearest the left side of the tank. The transfer gear housing end is the front end and the right side is that side nearest the right side of the tank. Both of these engines are right-hand rotation as established from the front of the engine. The engine on the right side of the tank is the LA engine and the engine on the left side is the LC engine.


### 6. GENERAL.

a. The twin Diesel power plant discussed in this text consists of two six-cylinder engines paired together by a transfer gear train. Both engines have the same bore and stroke and use the same parts wherever possible. Thus the major working parts such as injectors, pistons, connecting rods, and all bearings and other numerous parts are interchangeable. See paragraph 27 b for non-interchangeable parts.

b. Although certain accessories and subassemblies can be mounted only on one side of the engine, the blower, water pump, oil cooler, oil filter, governor and fuel pump can be located on either the right or left side of each engine. This flexibility in the arrangement of parts is obtained by having both the cylinder block and cylinder head symmetrical at both ends and with respect to each other.

c. Power from each engine is transmitted through its clutch to its drive shaft and gear. The drive gears of the two engines jointly drive a single driven gear, which transmits the power to the propeller shaft.

# **ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71 POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11147

**Figure 3—Rotation Diagrams of LA and LC Engines**

## **7. THE DIESEL PRINCIPLE.**


a. The Model 6046 Diesel power plant consists of 2 two-stroke cycle, internal combustion engines. An internal combustion engine converts the heat of fuel into work energy in the cylinder of the engine.

b. The Diesel engine differs from the gasoline engine principally in the method used to introduce and ignite the fuel. The gasoline engine draws a mixture of fuel and air through the carburetor into the combustion chamber, where it is ignited by an electric spark. In the Diesel engine, air alone is compressed in the cylinder. A charge of fuel is sprayed into the cylinder after the air has been compressed, and ignition is accomplished by the heat of compression (fig. 4).


c. In the LA24M and LC24M Diesel engines, intake and exhaust take place during part of the compression and power strokes. Since a two-stroke cycle engine does not function as an air pump, an external means of supplying the air is provided. Specially designed blowers, bolted to the side of each engine, force air into the cylinders, thus expelling the exhaust gases and filling the cylinders with fresh air for combustion.

d. A series of ports in double rows of 32 each and equally spaced and staggered cut into the cylinder walls and the cylinder liners. These


ENGINE




AIR ENTERING THROUGH PORT  
TO COMBUSTION CHAMBER



AIR BEING COMPRESSED WITH  
EXHAUST VALVES CLOSED



CHARGE OF FUEL BEING INJECTED  
INTO COMBUSTION CHAMBER



EXHAUST TAKING PLACE AND CYLINDERS  
ABOUT TO BE SWEEPED WITH CLEAN  
SCAVENGING AIR

RA PD 11137

Figure 4—Operating Cycle of the 6046 Power Plant


# **ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71 POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

ports admit air from the blower into the cylinder as soon as the top face of the piston uncovers the ports. The inrush of fresh air toward the exhaust valves produces a scavenging effect. This eliminates the burnt gases and leaves the cylinders full of clean air when the piston again covers the inlet ports (fig. 4, diagram 1).

e. As the piston continues on the upward stroke, the exhaust valves close and the charge of fresh air is subjected to compression (fig. 4, diagram 2). The engines have a 16 to 1 compression ratio.

f. Shortly before the piston reaches its highest position, a measured amount of fuel is sprayed into the combustion chamber by the fuel injector (fig. 4, diagram 3). The intense heat generated by the high compression of the air ignites the fine fuel spray immediately, and the combustion continues as long as the fuel spray lasts. Combustion forces the piston downward, and the exhaust valves are again opened as the effective part of the power stroke is completed (fig. 4, diagram 4). The burnt gases escape into the exhaust manifold and the downward moving piston uncovers the inlet ports. As these ports are uncovered, the cylinder is again swept with clean scavenging air. Combustion is completed in each cylinder once for each revolution of the crankshaft. The entire combustion cycle is completed in each cylinder in each revolution of the crankshaft, or in other words, in each two strokes.

**BLOCK, CYLINDER ASSEMBLY**



RA PD 11138

**Figure 5—Cylinder Block**


**ENGINE****8. CYLINDER BLOCK AND CRANKCASE.**

a. The cylinder block and crankcase, which is the main structural part of the engine, is a box-like, one-piece casting made of alloy cast iron (fig. 5). The two ends of the block are identical, so that the flywheel housing and gear train can be put on either end.

b. Each cylinder is bored to receive a cylinder liner, which has a number of air inlet ports drilled into it. The water jackets extend the full length of the bores and are divided into upper and lower sections, which are connected by hollow struts. Cooling water enters at the bottom of the water jacket from the water pump and leaves at the top through holes which line up with corresponding openings in the cylinder head. Surrounding the water space is an air chamber which conducts the air from the blower to all inlet ports.

c. The camshaft and balancer shaft are located near the top of the cylinder block.

d. The upper halves of the main bearing seats are cast integrally with the block. Drilled passages in the block, which carry lubricating oil to all moving parts, eliminate exterior piping. Handhole plates on the side opposite the blower provide access to the air chamber. Also, there are two handhole plates on the blower side.



RA PD 11139

**Figure 6—Cylinder Liner**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

c. Replacement cylinder blocks are furnished with main bearing caps, studs, and the necessary plugs.

**9. END PLATES.**

Two steel end plates, bolted to either end of the cylinder block, serve as mounting bases for the flywheel housing, the balance weight cover, and the crankshaft front cover.

**10. CYLINDER LINERS.**

a. A flange at the top of the cylinder liner fits into a recess in the cylinder block for proper positioning in the block. The liner is slip-fitted in the cylinder block bore, thus facilitating replacement.

b. Even temperature and minimum distortion are insured by water cooling of each liner over its entire length, except at the ports, which are cooled by the scavenging air. To permit introduction of fresh air into the cylinder sixty-four  $\frac{1}{8}$ -inch ports are drilled into the circumference of each cylinder liner. These ports are arranged in rows, 32 in each row, and are equally spaced and staggered.

**11. MAIN BEARINGS.**

a. Main bearing shells are readily replaceable without machining. The main bearing caps are marked 1, 2, 3, etc., and when removed should always be replaced in their respective positions, with the stamped numbers toward the blower side of the engine.

b. The upper halves of the main bearing shells are seated in the crankcase. The lower halves are held in place by the main bearing caps, each of which is bolted to the crankcase by two studs and nuts. Each half of the bearing shell is prevented from endwise or radial movement by a tang at the one side of the bearing end. Each bearing cap is locked from sidewise movement by a milled slot in the crankcase. There are seven main bearings in each engine (fig. 7).

c. All upper halves of the main bearing shells are alike. These shells carry a semicircular groove midway between the bearing edges, which runs the length of the bearing from end to end and lines up with the oil holes in the crankshaft journals at all times. This groove has an oil hole directly in the center of the bearing which provides oil passage through holes in the cylinder block to the drilled passages in the crankshaft and on to the various connecting rod bearings.

d. The lower halves of the main bearing shells have no oil grooves; consequently, the upper and lower halves of these bearing shells are not interchangeable.

## **ENGINE**

### **12. CRANKSHAFT.**

- a. Crankshafts are interchangeable in the two engines (fig. 8).
- b. Complete static and dynamic balance of the rotating parts are provided by counterweights in the crankshaft.
- c. The crankshaft thrust is taken through two-piece, bronze washers on each side of the front main bearing. The crankshaft is drilled for full-pressure lubrication to the main and connecting rod bearings (fig. 10).

### **13. FLYWHEEL.**

- a. Each engine has a flywheel bolted securely to the end of the crankshaft and supported by dowel pins in two places. One of the bolting studs is offset, so that the flywheel can be attached to the crankshaft flange in only one position.
- b. A steel starter ring gear is shrunk onto the rim of the flywheel.

### **14. PISTONS.**

- a. Pistons are ground their full length to permit close fitting. The top of the piston forms the "floor" of the combustion chamber and is designed to mix the air with the fuel spray.
- b. To add strength, rigidity and cooling area, the head of each piston is cast with radial ribs on the inside and is connected to the piston pin bosses by vertical struts. The ribbed head is cooled from the inside by lubricating oil forced from a spray jet in the top of the connecting rod (fig. 10).
- c. Two bronze-line bushings with helical oil passage grooves are pressed into the piston to provide a bearing surface for the full-floating piston pin. After the piston pin has been installed, the hole in the piston at each end of the pin is sealed with a tight steel cap which is locked in place with a spring clip. Thus lubricating oil in the piston pin bushings is prevented from reaching the cylinder walls.
- d. All pistons are equally balanced.
- e. Each piston is fitted with six cast iron piston rings. Four  $\frac{1}{8}$ -inch wide, grooved compression rings are located above the pin, and two  $\frac{3}{16}$ -inch wide, three-piece special oil control rings are located near the bottom of the piston skirt.

### **15. CONNECTING RODS (figs. 7 and 9).**

- a. Each connecting rod is rifle-drilled for lubrication of the piston pin and has an oil spray jet for cooling of the piston head. Bearing caps are serviced only as part of the rod assembly.
- b. The lower end of the connecting rod oil passage contains an orifice which meters oil to the piston end of the rod. The crankpin



ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 7—Side Sectional View of LC Engine

RA PD 11140


# ENGINE

- |   |  |
|---|--|
| 1—Vibration Damper                                      | 23—Cam   |
| 2—Air Heater Cover                                      | 24—Camshaft Bearing (Thrust) (Plain on LA)         |
| 3—Handhole Cover  | 25—Camshaft Gear                                   |
| 4—Camshaft Bearing (Plain) (Thrust on LA)               | 26—Idler Gear                                      |
| 5—Camshaft  | 27—Flywheel  |
| 6—Fan Drive Gear Train                                  | 28—Clutch Pressure Plate                           |
| 7—Fan Assembly  | 29—Clutch Spring                                   |
| 8—Thermostat Housing                                    | 30—Clutch Release Bearing                          |
| 9—Exhaust Manifold                                      | 31—Engine Drive Gear                               |
| 10—Water Outlet Manifold                                | 32—Transfer Gear Housing                           |
| 11—Injector Control Tube and Bracket Assembly           | 33—Clutch Housing                                  |
| 12—Injector Assembly                                    | 34—Engine Drive Shaft                              |
| 13—Exhaust Valve Spring                                 | 35—Flywheel Housing                                |
| 14—Exhaust Valves                                       | 36—Crankshaft Gear                                 |
| 15—Sectional View of Piston and Connecting Rod Assembly | 37—Oil Pan   |
| 16—Cylinder Liner                                       | 38—Cylinder Air Inlet Port                         |
| 17—Valve Rocker Cover                                   | 39—Cylinder Wall                                   |
| 18—Fuel Pipe  | 40—Main Bearing                                    |
| 19—Exhaust and Injector Rocker Arm Assemblies           | 41—Connecting Rod Bearing                          |
| 20—Push Rods  | 42—Lubricating Oil Pump Assembly (figs. 10 and 11) |
| 21—Lifter Bracket Assembly                              | 43—Cylinder Block                                  |
| 22—Cam Follower   | 44—Lubricating Oil Pump Gear Train                 |
|   | 45—Crankshaft                                      |

RA PD 11140A

**Nomenclature for Figure 7—Side Sectional View of LC Engine**

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



RA PD 11141

Figure 8—Crankshaft

## **ENGINE**

bearings do not require shim adjustments. The upper and lower halves of the connecting rod bearing shells are not identical and therefore are not interchangeable, but they are replaceable.

c. The upper connecting rod bearing shells are grooved midway between the bearing edges part way up from the outer end of each bearing. An oil hole through the shell is located at one end of the groove. The lower shell has an oil groove in line with that of the upper shell which circles the shell from end to end. These grooves maintain a continuous contact with the oil holes in the crankpins, thereby providing a constant supply of cooling oil through the rifle-drilled connecting rod to the piston pin bearings and the spray jet.

### **16. GEAR TRAIN (fig. 64).**

a. A completely enclosed train of four helical gears is located at the front end of the engine. The crankshaft gear drives the idler gear which in turn drives the camshaft gear on the LC engine and the balancer shaft gear on the LA engine. The camshaft gear and balancer shaft gear mesh and run at the same speed as the crankshaft gear.

b. The camshaft and balancer shaft gears are keyed to their respective shafts, each gear being held securely against a shoulder on the shaft by a lock nut. Balancer and camshaft gears are helically cut; that is, the teeth, instead of being cut straight across the gear, are cut at an angle. Although the camshaft and balancer shaft may be placed on either side of the cylinder block, the right-hand helical gear always remains on the right side of the block and the left-hand gear on the left side, as established from the driver's seat.

c. The idler gear is fitted with two flanged bushings, and rotates on a hollow hub, which is bolted through the end plate to the cylinder block. A dummy hub or spacer and dowel is used to cover the opening in the cylinder block end plate on the other side of the engine.

d. The crankshaft gears as well as the idler gears are identical for both engines.

e. An auxiliary drive (blower drive gear) on the blower side of the engine transmits power to a shaft which drives the blower, governor, water pump and fuel pump. **NOTE:** The blower drive gear for the LA engine has a right-hand helix; on the LC engine the gear has a left-hand helix. The gears, therefore, are not interchangeable.

### **17. CAMSHAFT AND BALANCE SHAFT.**

a. The camshaft is located in the top of the cylinder block and has two end bearings and five intermediate bearings. The two halves of each intermediate bearing are held together by two spring retainers and the complete bearing is locked into place by a set screw in the top of

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 9 — Cross-Sectional View of 6046 Power Plant

ENGINE

- |                                     |   |
|-------------------------------------|---|
| 1—Oil Cooler Adapter                | 15—Push Rod                             |
| 2—Oil Cooler                        | 16—Section of Piston and Connecting Rod |
| 3—Blower Housing                    | 17—Air Box                              |
| 4—Blower Rotors                     | 18—Solenoid Air Inlet Control           |
| 5—Air Cleaner                       | 19—Air Inlet Housing                    |
| 6—Secondary Fuel Filter             | 20—Connecting Rod Bearing Shell         |
| 7—Camshaft                          | 21—Crankshaft                           |
| 8—Rocker Arm                        | 22—Main Bearing Shell                   |
| 9—Injector                          | 23—Lubricating Oil Pump Assembly        |
| 10—Injector Control Rack Tube Lever | 24—Lubricating Oil Pump Driven Gear     |
| 11—Water Outlet Manifold            | 25—Air Heater                           |
| 12—Exhaust Manifold                 | 26—Air Heater Fuel Pipe                 |
| 13—Balancer Shaft                   | 27—Clutch Shift Levers                  |
| 14—Valve Rocker Cover               |   |

RA PD 11142A

*Nomenclature for Figure 9—Cross-Sectional View of 6046 Power Plant*

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

the cylinder block. The bearing at the flanged end of the camshaft absorbs the drive thrust. Thrust is taken at the front end of LA engines and at the rear end of LC engines.

b. The balancer shaft is parallel to the camshaft in the top of the cylinder block. The balancer shaft, like the camshaft, has bearings at each end, but has no intermediate bearings. Counterweighted gears located outside the cylinder block front end plate are attached to the camshaft and balancer shaft. Balance weights are attached to each shaft outside the end plate.

c. The camshaft and balancer shaft end bearings are lubricated through four vertical oil passages in the cylinder block which connect with the main oil gallery. Camshaft intermediate bearings are lubricated by oil from the hollow camshaft (fig. 10).

**18. ENGINE GEAR TRAIN TIMING.**

When the engine is properly timed, the markings on the gears of the gear train will be perfectly lined up. The letter O on the camshaft gear will line up with the letter O on the balancer shaft gear, and the two L marks on the idler gear will line up with the L on the balancer or camshaft gear and the L on the crankshaft gear (fig. 63).

**19. ENGINE BALANCE.**

a. Rotating and reciprocating forces are completely balanced. The crankshaft and connecting rods are balanced by the counterweights on the crankshaft checks.

b. The unbalancing force of the end pistons (it tends to rock the engine from end to end) is counteracted by an arrangement of rotating counterweights which produce a force equal and opposite to that produced by the end pistons.

c. The balance weights at the front end of the engine are integral with the camshaft and balancer shaft drive gears. The weights at the rear end consist of eccentric slugs, one of which is integral with the fan drive gear.

**20. CYLINDER HEAD.**

a. The cylinder head can be removed from the engine as an assembly and contains cam followers, guides, rocker arms, injectors, and valves. The head is held to the cylinder block by 14 studs and nuts.

b. A fuel injector, two exhaust valves and three rocker arms for each cylinder are located in the head. One rocker arm operates the injector plunger; the other two operate the exhaust valves (figs. 7 and 9).

c. Exhaust valve seats are pressed into the cylinder head.

## ENGINE

d. To provide sufficient cooling, each fuel injector is inserted into a thin-walled copper tube passing through the water space in the cylinder head. The lower end of the copper tube is pressed into the cylinder head and spun over; the upper end is flanged and sealed against the cylinder head. The spun-over lower end and sealed upper end prevent any water leaks around the copper tube.

e. The two exhaust passages from each cylinder lead through a single port to the exhaust manifold. The exhaust passages, exhaust valve seats, and injector seats are completely surrounded by water.

f. A flat, laminated gasket between the cylinder head and the top of the cylinder block seals compression. A composition gasket around the outer rim of the head seals against oil leaks. The top of each cylinder head is completely enclosed by the valve rocker cover, which is held in place by bolts fitted with hand knobs, and is sealed against leakage by a gasket.

### 21. VALVE AND INJECTOR OPERATING MECHANISM.

a. Three rocker arms are provided for each cylinder. The two outer arms operate the exhaust valves and the center one the fuel injector. Each rocker arm group operates on a shaft supported by two brackets. A single bolt fastens each bracket securely to the top of the cylinder head. The removal of these two bolts permits raising the rocker arms, providing access to the fuel injector and the valve springs.

b. The injector end of each injector rocker arm is fitted with a hardened ball stud and a ball seat which form a universal joint. The ball and seat transmit the rocker arm motion to the fuel injector. The valve end of each exhaust valve rocker arm has a cylindrical surface which bears directly on the end of the valve stem. Each rocker arm is operated from the camshaft through a short push rod and a cam follower.

c. Contact between each cam follower and the camshaft is effected by a steel roller located at the bottom of the cam follower and equipped with a needle bearing. A cam follower guide is provided for each set of three cam followers. This guide, located on the bottom of the cylinder head, keeps the cam follower rollers in line with the camshaft and also serves as a retainer during assembly and disassembly. A coil spring located inside the hollow cam follower holds the follower against the camshaft and is held in place by a retaining washer and wire locking ring.

d. Exhaust valve stem guides are pressed into the cylinder head and then reamed for the desired valve fit.



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

e. A straight cylindrical valve spring is held in place by a retainer and tapered two-piece seat lock.

f. The valve-operating mechanism is lubricated from a longitudinal oil passage on the camshaft side of the cylinder head connecting with a main oil gallery in the cylinder block (figs. 4 and 11). Oil from this passage enters the hollow rocker arm shafts through the rocker shaft brackets. Excess oil from the rocker arms lubricates the valve ends, injector and injector rack gear, and drains to the cam pockets in the cylinder head from which the cams are lubricated (figs. 10 and 11).

**22. LUBRICATION SYSTEM (figs. 10 and 11).**

**NOTE:** Identical numbers are used in figures 10 and 11 where the same part is identified in both figures.

a. The lubrication system of the engine can be traced by following the solid black lines shown on the accompanying figures 10 and 11. The lubricating oil supply for the power plant is kept in two seven-gallon tanks which are located on either side of the power plant in the engine compartment of the tank. A dry sump lubricating system is used with a gear-type oil pump which is supported on the two rear main bearing caps. The complete pump assembly combines three sets of gears and forms three pumps—one pressure pump (8, fig. 11) and two scavenging pumps (9 and 10, fig. 11). The pressure pump draws oil from the external supply tank through the inlet pipe (9 or 12, fig. 10) and forces it under pressure through the oil cooler (14, fig. 10) to the main oil gallery (16, figs. 10 and 11) in the cylinder block. The two scavenging pumps (front and rear) draw the used oil from the two engine oil pan sumps and force it back to the external oil tank through the outlet pipe (5 or 10, fig. 10). This combination scavenging and pressure system permits operation of the engine up to a 35-degree angle in any direction without interfering with the lubrication system. The oil pump in each engine is driven from the crankshaft by a gear train consisting of the crankshaft gear, an idler gear (6, figs. 10 and 11) and the oil pump driving gear (7, figs. 10 and 11).

b. The system is protected by a spring-loaded pressure relief valve incorporated in the pump body. This allows excess oil to be bypassed to the scavenging end of the pump. In addition, an oil pressure regulator valve, attached to the front of the cylinder block on the oil pan bolt flange, maintains oil pressure at a constant level.

c. Lubricating oil is filtered by two filters of the replaceable element type—one for each engine. These are mounted in the center of the filter panel of the tank above the front of the engines. Oil entering the filter is bled off the oil gallery in the cylinder block, forced through the filter element, and returned directly to the engine crankcase.

## **ENGINE**

d. The oil cooler has a double function. It not only cools the hot engine oil but, by means of a shut-off temperature control in the cooling unit, provides a means of rapidly raising the oil temperature during the warm-up period. After engine warm-up, oil is cooled by water from the cooling system which is piped to the cooler housing and completely surrounds the cooling unit. Hot oil enters the cooling unit at the bottom, flows through the inside passages and is discharged at the top into a vertical passage in the cylinder block. Oil pumped to the oil cooler is passed directly from the pump to the engine lubrication system by means of a valve (13, fig. 10) in the oil cooler adapter (15, fig. 10), whenever the pressure at the oil cooler inlet becomes approximately 40 pounds greater than the pressure of the cooler outlet. The valve in the cooler prevents excessive oil pressure from developing within the cooler.

e. As shown in figures 10 and 11 the oil delivered to the main oil galleries (16, figs. 10 and 11) in the cylinder block is forced under pressure through oil passages in the crankshaft to main bearings (4, figs. 10 and 11) and to the connecting rod bearings (3, figs. 10 and 11), connecting rods (2, figs. 10 and 11) and pistons (1, figs. 10 and 11). Oil is forced up to the balancer shaft (20, fig. 10) and camshaft bearings (18, fig. 10). An oil passage through the camshaft conducts oil to the intermediate bearings. Cams are lubricated by oil collected in the camshaft pocket (23, figs. 10 and 11). Some oil from the camshaft lubrication provides lubrication for the gear train (15, fig. 11). A longitudinal oil passage (21, figs. 10 and 11) above the main oil gallery feeds oil to the rocker arm (19, figs. 10 and 11), valve guide (17, fig. 11) and cam follower assemblies (22, figs. 10 and 11). Oil is also fed to an oil reservoir (17, fig. 10) in the blower housing to lubricate the blower drive shaft bearings and governor weight housing. A special oil tube carries oil to the fan drive gear train (24, fig. 11). Oil is fed from the rear of the engine gallery to the blower drive support bearing by an oil pipe.


f. The oil pan is in a single piece and can be drained by the removal of the drain plugs at the bottom of each sump.

### **23. AIR INTAKE SYSTEM.**

a. The blower supplies the fresh air needed for combustion and scavenging, through the action of two hollow rotors, each with three helical lobes. The rotors revolve with very close clearances in the blower housing which is bolted to the side of the engine.

b. Air entering the blower inlet from the air cleaner is picked up by the lobes and carried to the discharge side of the blower. This air sweeps through the cylinder liner intake ports when the pistons are at the bottom of their stroke.

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



RA PD 11143

Figure 10—Cross-Sectional Diagram of Lubrication System

ENGINE

- |  |                                    |
|--|------------------------------------|
| *1—Oil Spray to Crown of Piston              | 13—Oil Cooler Relief Valve         |
| *2—Oil Passage in Connecting Rod             | 14—Oil Cooler                      |
| *3—Oil Passage in Connecting Rod Bearing     | 15—Oil Cooler Adapter              |
| *4—Oil Passage in Main Bearing               | *16—Main Oil Gallery               |
| 5—Oil Outlet to External Tank Model LC 24M   | 17—Oil Reservoir in Blower Housing |
| *6—Oil Pump Idler Gear                       | *18—Camshaft Oil Passage           |
| *7—Oil Pump Driving Gear                     | *19—Rocker Arm Lubrication         |
| 8—Oil Pump Relief Valve                      | 20—Balancer Shaft Lubrication      |
| 9—Oil Inlet from External Tank Model LC 24M  | *21—Upper Oil Gallery              |
| 10—Oil Outlet to External Tank Model LA 24M  | *22—Cam Follower Lubrication       |
| *11—Scavenging Pump Screen                   | *23—Camshaft Oil Pocket            |
| 12—Oil Inlet from External Tank Model LA 24M |                                    |

\*Also identified (same number) in figure 11. RA PD 11143A

Nomenclature for Figure 10—Cross-Sectional Diagram of Lubrication System

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 11—Side Sectional Diagram of Lubrication System

ENGINE

- \*1—Oil Spray to Crown of Piston
- \*2—Oil Passage in Connecting Rod
- \*3—Oil Passage in Connecting Rod Bearing
- \*4—Oil Passage in Main Bearing
- 5—Drain Plug for Rear Sump
- \*6—Oil Pump Idler Gear
- \*7—Oil Pump Driving Gear
- 8—Oil Pressure Pump
- 9—Rear Scavenging Pump
- 10—Front Scavenging Pump
- \*11—Scavenging Pump Screen
- \*12—Scavenging Pump Inlet Pipe
- 13—Drain Plug for Front Sump
- 14—Oil Regulator Valve
- 15—Gear Train Lubrication
- \*16—Main Oil Gallery
- 17—Valve Guide Lubrication
- \*18—Camshaft Oil Passage
- \*19—Rocker Arm Lubrication
- 20—Connector for Fan Drive Oil Tube
- \*21—Upper Oil Gallery
- \*22—Cam Follower Lubrication
- \*23—Camshaft Oil Pocket
- 24—Fan Drive Gear Train Lubrication

\*Also identified (same number) in figure 10. RA PD 11144A

Nomenclature for Figure 11—Side Sectional Diagram of Lubrication System

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

c. Two matched gears on the drive end of the rotor shafts space the rotor lobes with a slight clearance. Because the rotors do not touch each other at any time, they require no lubrication. Seals prevent air leakage at the ends of the rotors, and also keep the oil used for lubricating the timing gears and rotor shaft bearings from entering the rotor compartment. The upper rotor is driven at 1.94 times engine speed by the blower drive shaft. The lower rotor is driven at the same speed by the gears. A flexible coupling in the blower drive shaft prevents torque reaction. Each rotor is supported on the doweled end plates of the blower housing by ball bearings at the front and rear.

d. The blower gears and bearings as well as the governor and water pump drive are lubricated by oil which drains from the camshaft oil pockets (fig. 10). A slinger on the governor end of the lower rotor throws oil into the governor weight and housing assembly. Surplus oil passes from the blower to the oil pan through drilled holes in the cylinder block.

## **24. FUEL SYSTEM.**

**NOTE:** The fuel system includes the fuel pump, injectors, filters, manifolds, and connecting lines.


### **a. Fuel Injector.**

(1) To secure combustion, a small quantity of accurately metered, finely atomized fuel must be mixed, at the end of the compression stroke, with the charge of air which has been forced into the cylinder by the blower. This is accomplished by a high-pressure fuel injection device (figs. 12 and 13).

(2) Before injection can be effected, the fuel pressure must be higher than that of the air charge in the combustion chamber. The fuel injectors for each cylinder create a sufficiently high pressure before atomization and injection of the fuel.

(3) The injectors are mounted in the cylinder head with their spray tips projecting slightly below the top of the inside surface of the combustion chambers. A clamp, bolted to the cylinder head and fitting with a machined recess in each side of the injector body, holds the injector in place in a water-cooled copper tube which passes through the cylinder head (fig. 14). Injectors must always be firmly seated when installed, in order to eliminate the possibility of leakage and pressure loss.


(4) Fuel oil is supplied to the injector at a pressure of about 25 pounds per square inch at maximum engine speed, and enters the injector body at the top through the filter cap (19, fig. 12). After passing through the filter (22, fig. 12) in the inlet passage, the fuel oil fills the high-pressure cylinder (32, fig. 12) and fuel cavity (29, fig. 12)



**Figure 12—Cutaway of Fuel Injector**



ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



RA PD 11148

Figure 13—Cutaway of Fuel Injector Mounting

## ENGINE

between the bushing (28, fig. 12) and the spill deflector (5, fig. 12). Also see figure 11. The plunger operates up and down in its bushing, the bore of which is connected to the fuel supply in the fuel cavity by the funnel-shaped upper and lower ports (6 and 31, fig. 12).

(5) The motion of the injector rocker arm is transmitted to the plunger by the follower (18, fig. 12) which bears against the plunger spring (16, fig. 12). In addition to this motion, the plunger is rotated, in operation, around its axis by the gear (13, fig. 12) which is in mesh with the rack assembly (12 and 25, fig. 12). On the downward travel of the injector plunger, the metered amount of fuel is forced through the flat check valve and against the spherical check valve in the valve and seat assembly. When sufficient fuel pressure is built up, the spherical check valve is lifted off its seat and the fuel is forced through orifices in the spray tip (33, fig. 12) and atomized in the combustion chamber. The check valve prevents air leakage from the combustion chamber into the fuel system if the valve is accidentally held open by a small particle of dirt, and thus allows the injector to continue to operate until the dirt works through the valve. On the return upward movement of the plunger, the high-pressure cylinder is again filled with fuel oil through the lower port. Injector parts are finely machined; extreme care should be exercised, in repair and replacement, in order to maintain proper injector operation and timing.

(6) The fuel injector outlet opening, which returns the excess fuel oil supplied by the fuel pump, is directly adjacent to the inlet opening (fig. 14) and is protected against dirt or other foreign matter by a fine filter element, exactly like the one on the inlet side.

(7) Each injector rack assembly is connected by a detachable joint to a lever on a common control tube, which, in turn, is linked to the governor and throttle (fig. 13). These levers can be rotated on the rack control tube by two adjusting screws, thus permitting a uniform setting of all injector racks.

### b. Fuel Oil Pump.

(1) The fuel oil pump is the positive displacement vane type having a capacity of approximately 40 gallons per hour at 2,000 revolutions per minute. The pump is bolted to the front end of the blower housing and driven from the lower blower rotor shaft through a U-shaped universal joint. Oil seals—one facing the blower and one facing the fuel pump—maintain the fuel oil pressure and prevent lubricating oil seepage into the fuel pump from the blower.

(2) A relief valve in the cover of the pump connects the inlet and outlet ports and opens at a pressure of approximately 60 pounds per square inch. This valve normally does not open, since its purpose is to

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



Figure 14—Injector and Injector Hole Tube

## **ENGINE**

relieve excessive pump pressure if any of the fuel lines or filters become plugged and build up an extremely high pressure in the pump. When the valve opens, fuel passes from the discharge side to the suction side of the pump.

### **c. Fuel Oil Filters.**

Although injector parts are protected by the two small filters adjacent to the injector body, these filters are not intended for separation of foreign matter from the fuel. Primary and secondary fuel filters are supplied with each engine to remove solid impurities in the fuel which could damage the engine. The primary filter is a cleanable element type and is installed in the fuel supply line between the fuel pump and the fuel supply tank. It is mounted on a filter panel with the lubricating oil filters and the air heater coils. The secondary filter is a replaceable element type connected into the fuel pump-to-inlet manifold line (fig. 9). The secondary filter is mounted on the outer side of the cylinder head.

## **25. GOVERNOR.**

The maximum speed at which the engine can be run, as well as the speed at which the engine is idled, is controlled by a governor mounted at the rear of the blower. The two governors of the power plant operate independently and therefore must be adjusted carefully to assure the best operation of both engines.

### **a. Type.**

(1) The governor is a mechanical type with two high-speed and two low-speed weights located in the governor weight housing. Each set of weights has a fixed stop for the high- and low-speed positions. High- and low-speed springs operate in conjunction with the weights. The high-speed spring operates in conjunction with the high-speed weights to limit the maximum engine speed; the low-speed spring operates in conjunction with both the low- and high-speed weights to control the engine idling speed. The two sets of weights are carried on a horizontal shaft inside the governor weight housing. The weight carrier shaft is mounted on a ball bearing at one end and is driven from the upper rotor shaft of the blower at the other end.

(2) The blower end of the governor weight shaft is serrated and engages with corresponding serrations inside the upper rotor. The operating shaft transmits the motion of the governor weights to the control tube and on to the injector racks. The operating shaft has a yoke fixed at the lower end, an operating lever fixed at the upper end and a high- and low-speed governing spring with suitable adjustments. The oper-

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

ating shaft is mounted on ball bearings at the upper and lower end. The governing action of the weights is transmitted to the operating shaft through a movable riser on the weight carrier shaft and the yoke on the lower end of the operating shaft. This action is, in turn, transmitted to the injector control shaft by means of the operating and differential levers on the upper end of the operating shaft. The cover assembly is a carrier for the throttle control cam and the throttle control lever.

**b. Lubrication.**

The lower portion of the governor is lubricated from a slinger attached to the rear end of the blower rotor shaft. This slinger dips into a well of oil in the blower end cover and throws oil into the governor weight housing. The upper portion of the governor, including the operating shaft bearings and the control mechanism, is lubricated partly by splash from the oil slinger on the weight carrier shaft and partly by return oil through the governor housing from the cylinder head.

**c. Operation.** The governor controls the maximum speed of the engine at approximately 2,100 revolutions per minute under full load, which corresponds to 2,200 revolutions per minute at no load with the engine running free. The governor also controls low speeds up to about 350 revolutions per minute. The upper limit of the low-speed governing range is reached when a projection on the low-speed weight, on the side of the pin opposite the main part of the weight, comes in contact with the weight carrier and stops. Intermediate-speed control is entirely manual. When the speed of rotation of the weights becomes high enough so that the force on the high-speed weights is sufficient to overcome the preload on the high-speed spring, maximum speed control is effected. When the pin on the throttle control lever is held fixed, as in the idle or full throttle positions, the governing action from either the low- or high-speed weights causes the long end of the control lever, which is connected to the injector racks, to regulate the speed of the engine. Under these conditions the injector is governor-controlled.

**26. COOLING SYSTEM.**

**a.** Cooling of the engine is accomplished by water circulation through the cylinder block and cylinder head by a centrifugal pump mounted on the rear end of the blower and driven by the lower blower rotor shaft through a coupling.

**b.** A fan forces air through the radiator core, thus lowering the temperature of the water while it passes from the top to the bottom of the core. The water pump draws the cooled liquid from the radiator and through the oil cooler housing, discharging it into the lower part of the

## **ENGINE**

cylinder block. Openings in the water jacket around the cylinder bores connect with corresponding openings in the cylinder head. The liquid then circulates around the valves and fuel injectors. A water outlet manifold bolted to the cylinder head discharges the cooling water back into the radiator.

c. The water temperature in the engine is automatically controlled by two bypass-type thermostats mounted in the water outlet manifold. The thermostats begin to open at approximately 158 F and are fully open at 185 F. Before the thermostats begin to open, water circulation is restricted to the cylinder block, cylinder head and oil cooler only, bypassing the radiator through a tube which connects the water outlet manifold to the water inlet. After the thermostats begin to open, and until they are fully open (185 F), water circulation takes place through both the bypass tube and the radiator. After the thermostats have opened fully, water circulation takes place through the radiator and engine only—no circulation taking place through the bypass tube. Before the thermostats begin to open (during the warm-up period of the engine), the lubricating oil passing through the oil cooler is rapidly warmed by the warm water recirculation. Engine lubrication is positive at all times, regardless of outside temperatures. Also, by means of bypass circulation, normal engine operating temperatures are reached with a minimum warm-up period. Since the water pump ball bearing is the shielded type and filled with lubricant when assembled, no further lubrication is necessary.

## **27. TABULATED DATA.**

### **a. Specifications of Model 6046 Power Plant.**

#### **(1) ENGINE, GENERAL.**

Engine models	671LA24M and 671LC24M
Type	2 stroke cycle, in-line
Number of cylinders, each engine	6
Bore	4 1/4-in.
Stroke	5 in.
Total displacement, each engine	425 cu in.
Direction of rotation	Counterclockwise
Speed range	350-2,100 rpm
Maximum engine speed, full load	2,100 rpm
Maximum engine speed, no load	2,200 rpm
Hp, max. at 2,100 rpm at gear transfer driven shaft	375

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**
**TABULATED DATA—Continued**

Compression ratio (nominal)	16 to 1
Compression pressure at 1,000 rpm	500 lb per sq in.
Firing order	1, 4, 2, 6, 3, 5
Location of No. 1 cylinder	Nearest cylinder to fan
Injector pump	Unit injector combined with plunger and spray nozzle for each cylinder
Injector nozzle type	Multiple orifice
Injector pressure	Up to 20,000 lb per sq in.
(2) CYLINDER LINER.	
Diameter, inside	4.2492 to 4.2507 in.
Clearance, liner with block	Slip fit
(3) PISTONS.	
Piston material	Malleable iron—tin plated or parco lubrite
Piston length	6.00 in.
Piston pin length	3.725 in.
(4) PISTON RINGS.	
Number of compression rings	4
Thickness	$\frac{1}{8}$ -in.
Number of oil rings	2
Thickness	$\frac{3}{16}$ -in.—3 piece
(5) CONNECTING RODS.	
Connecting rod material	Chrome-molybdenum steel
Length	10.125 in.
Weight, complete	6.8 lb.
(6) EXHAUST VALVES.	
Exhaust valve arrangement	2 overhead per cylinder
Exhaust valve material	Silchrome steel
Exhaust valve lift	0.375 in.
Angle, valve seat	45°
Exhaust valve seat width	0.078 ( $\frac{5}{64}$ ) in.
Exhaust valve seat inserts	Heat-treated chrome-molybde- num steel castings—replace- able
Diameter, head	1 $\frac{9}{16}$ -in.
(7) LUBRICATING OIL PUMP.	
Lubricating oil pump	Gear-drive, 3 section—one pres- sure and 2 scavenging bodies
Capacity	Dry sump—for use with ex- terior supply tank

**ENGINE****TABULATED DATA—Continued**

- |  |  |
|--|--|
| (8) <b>BLOWER.</b>   |  |
| Blower, type   | 3-lobed, helical   |
| Blower, rpm  | 1.94 times engine speed  |
| Blower drive   | Gears from flywheel end of engine                                  |
| (9) <b>CRANKPIN BEARING.</b>                               |  |
| Material   | Copper-lead, steel-backed, precision-type                          |
| Length   | 1.780 in.  |
| Diameter   | 2.750 in.  |
| Total projected area                                       | 29.37 sq in.   |
| (10) <b>CRANKSHAFT AND MAIN BEARINGS.</b>                  |  |
| (a) <b>Crankshaft</b>                                      |  |
| Material   | High-carbon, manganese steel, tocco hardened                       |
| Over-all length  | 46 $\frac{1}{16}$ -in.   |
| (b) <b>Crankshaft main bearing</b>                         |  |
| Material   | Copper-lead, steel-backed, precision-type                          |
| Thrust bearing, front main                                 | Bronze—split-type  |
| Length, shell only   | 1.125 in.  |
| Number per engine  | 7  |
| Total projected area                                       | 27.56 sq in.   |
| (11) <b>INJECTOR.</b>                                      |  |
| Timing gage height   | 1.460 in.  |
| (12) <b>FUEL PUMP.</b>                                     |  |
| Type   | Rotating-vane  |
| Capacity, at 2,000 engine rpm at 50 lb per sq in. pressure | 35 gal per hr  |
| (13) <b>LUBRICATING OIL COOLER.</b>                        |  |
| Description  | Oil-to-water type, built into engine oil and water system—12 plate |
| (14) <b>POWER TRANSFER.</b>                                |  |
| Clutch   | 2—16 in., dry plate  |
| Power transfer unit  | Helical gears  |
| Driven shaft rpm   | 1.19 times engine speed  |



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**TABULATED DATA—Continued**

**(15) COOLING SYSTEM.**

Cooling fans	2—gear-driven
rpm	2.20 times engine speed
Diameter	20 in.
Cooling water capacity, complete power plant	29 gal

**(16) ELECTRICAL SYSTEM.**

Battery charging generator	24-volt, 1,200 watts
rpm	1.94 times engine speed
Starting motor	24-volt, solenoid operated

**(17) OIL BATH AIR CLEANERS.**

Total oil capacity cleaners	7½ qt
-----------------------------	-------

**(18) WEIGHTS.**

Weight of power plant	4,340 lb
Weight of radiators	292 lb
Weight of filter panel	60 lb
Weight of voltage and current regulator	10 lb
Weight of propeller shaft	59 lb
Weight of fan shrouds	36 lb
Weight of exhaust mufflers	58 lb
Total weight as installed	4,855 lb

**b. Noninterchangeable Parts on Model 6046 Power Plant.**

Air heater inlet tube—upper to lower junction plate  
Air inlet housing assembly  
Air shut-down valve spring  
Balance weight cover  
Blower assembly  
Blower drive gear  
Blower drive shaft  
Blower drive shaft ring  
Cylinder head vent  
Exhaust manifold  
Exhaust manifold elbow  
Fan assembly  
Flywheel housing assembly  
Flywheel housing small hole cover (Model 671LA24M engine  
only)  
Fuel pump assembly  
Fuel pump drip shield  
Fuel pump inlet tube—upper junction plate to fuel pump

ENGINE

TABULATED DATA—Continued

- Fuel pump to secondary fuel filter tube
- Generator assembly (Model 671LC24M engine only)
- Governor assembly
- Governor control cam
- Governor control housing
- Governor cover assembly
- Governor cover and lever assembly
- Governor operating shaft assembly
- Governor throttle shaft assembly
- Injector and governor control tube assembly
- Injector and governor control tube and bracket assembly
- Lower junction plate assembly
- Lube oil pressure gage tube
- Oil cooler adapter assembly
- Oil cooler housing
- Oil pressure pump outlet pipe
- Radiator assembly
- Secondary fuel filter to manifold tube
- Starting motor assembly
- Starting motor center bearing attaching bolt
- Starting motor center bearing attaching plate
- Starting motor center bearing attaching washer
- Starting motor drive housing
- Upper junction plate assembly
- Water bypass tube
- Water pump assembly
- Water pump body assembly
- Water pump body cover

28. REFERENCE TO TM 9-753.

Many second echelon operations described in TM 9-753 are often done by ordnance maintenance personnel who should refer to the using troop technical manual for information.

29. ECHELON BREAKDOWN OF MAINTENANCE OPERATIONS.

a. Tabulated Breakdown.

(1) ENGINE	Echelon	
	3	4
Balancer shaft and bearings, replace .....		x
Camshaft and bearings, replace .....		x
Connecting rod and bearings, replace .....	x	
Crankshaft assembly, replace .....		x
Crankshaft assembly, rebuild .....		x

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

	<b>Echelon 3</b>	<b>4</b>
Cylinder head assembly, repair	x	
Cylinder head assembly, rebuild		x
Cylinder block assembly, replace		x
Cylinder block assembly, rebuild		x
Cylinder liner, replace	x	
Engine assembly, rebuild		x
Flywheel and housing, replace	x	
Governor assembly, repair	x	
Governor assembly, rebuild		x
Main bearings, replace		x
Piston assembly, replace	x	
Rocker arm assembly, repair	x	
Rocker arm assembly, rebuild		x
Timing gears, replace	x	
Vibration damper assembly, replace	x	
Vibration damper assembly, rebuild		x
<b>(2) AIR INTAKE SYSTEM</b>		
Air cleaner, repair	x	
Air heater, repair	x	
Air heater, rebuild		x
Blower assembly, repair	x	
Blower assembly, rebuild		x
<b>(3) COOLING SYSTEM</b>		
Fan assembly, repair	x	
Fan assembly, rebuild		x
Fan gears, replace	x	
Radiators, repair	x	
Radiators, rebuild		x
Water expansion tank, repair	x	
Water pump, repair	x	
Water pump, rebuild		x
<b>(4) ELECTRICAL SYSTEM</b>		
Air heater coil, repair	x	
Air heater coil, rebuild		x
Generator, repair	x	
Generator, rebuild		x
Solenoid shut-down, repair	x	
Solenoid shut-down, rebuild		x
Starter and starter solenoids assembly, repair	x	

## ENGINE

	Echelon	
	3	4
Starter and starter solenoids assembly, rebuild		x
Voltage and current regulator, repair	x	
Voltage and current regulator, rebuild		x
(5) FUEL SYSTEM		
Fuel oil filters, repair	x	
Fuel pump assembly, repair	x	
Fuel pump assembly, rebuild		x
Injector, repair	x	
Injector, rebuild		x
(6) LUBRICATING SYSTEM		
Oil cooler, repair	x	
Oil cooler, rebuild		x
Oil filter, repair	x	
Oil filter, rebuild		x
Oil lines, external, clean and replace	x	
Oil pan, repair	x	
Oil pump assembly, replace and repair	x	
Oil pump assembly, rebuild		x
(7) DRIVING UNITS		
Clutch assembly, repair	x	
Clutch assembly, rebuild		x
Clutch housing, replace	x	
Propeller shaft assembly, repair	x	
Propeller shaft assembly, rebuild		x
Transfer gear housing assembly, repair	x	
Transfer gear housing assembly, rebuild		x

b. Definition of words used in the list of repair jobs allocated to the various echelons.

(1) REPAIR consists of making repairs to, or replacement of the part, subassembly, or assembly which can be accomplished without completely disassembling the subassembly or assemblies and does not require heavy welding or riveting, machining, fitting, and/or alining.

(2) REPLACE consists of removing the part, subassembly, or assembly from the vehicle and replacing it with a new, reconditioned, or rebuilt part, subassembly or assembly, whichever the case may be.

(3) REBUILD consists of completely reconditioning and placing in serviceable condition any unserviceable part, subassembly or assembly of the engine or power plant including welding, riveting, machining, fitting, alining, assembling and testing.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section III**

**ENGINE TROUBLE SHOOTING**

	<b>Paragraph</b>
Scope .....	<b>30</b>
Facilities .....	<b>31</b>
Procedure .....	<b>32</b>

**30. SCOPE.**

This covers a trouble shooting inspection of the engine assembly, together with specific procedure to correct the source of trouble after it is located. Engine trouble shooting should not be confused with the 100-hour inspection.

**31. FACILITIES.**

Tools supplied the using arms personnel are sufficient for a complete trouble shooting inspection of the engine assembly. Additional tools required for service and repair are indicated in the paragraphs referred to under trouble shooting procedure (par. 32).

**32. PROCEDURE.**

TM 9-753 and TM 9-758 contain complete engine trouble shooting instructions, and should be referred to whenever trouble shooting by the ordnance maintenance personnel is necessary. When the source of trouble cannot be remedied by the using arms personnel, refer to section VI in this manual, where corrective procedure is outlined.

Section IV

REMOVAL OF ENGINE ASSEMBLY FROM TANK

	Paragraph
Removal of engine assembly from tank . . . . .	33

33. REMOVAL OF ENGINE ASSEMBLY FROM TANK.

- a. Before attempting disassembly of the engine, as outlined in Section V, the engine assembly must be removed. Detailed procedure for the removal of the engine assembly is covered in TM 9-753 and TM 9-758 which should be referred to for this operation.
- b. The clutch shifter shafts on the early production of these vehicles are equipped with lubrication fittings at both ends. Since the lower lubrication fittings are entirely inaccessible and since the bearings on the lower ends of the clutch shifter shafts require no additional lubrication for the length of time between engine removals, replace the lower fittings with pipe plugs at the next engine removal. On later production of these vehicles the lower lubrication fittings have been replaced with pipe plugs. Whenever an engine is removed from a vehicle, install a lubrication fitting, lubricate the bearing and replace the fitting with the pipe plugs.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section V**

**DISASSEMBLY OF THE ENGINE**

	<b>Paragraph</b>
Facilities .....	<b>34</b>
General precautions .....	<b>35</b>
Removal of engine transfer gear housing .....	<b>36</b>
Removal of clutch housing .....	<b>37</b>
Removal of the fan and related parts .....	<b>38</b>
Removal of air cleaner assemblies .....	<b>39</b>
Removal of oil cooler water drain valve assembly .....	<b>40</b>
Removal of LA engine from stand .....	<b>41</b>
Removal of generator .....	<b>42</b>
Removal of fuel and engine oil tubes, high-tension leads and junction plates .....	<b>43</b>
Attaching engine to rotating engine stand .....	<b>44</b>
Removal of water bypass tube .....	<b>45</b>
Removal of governor control housing .....	<b>46</b>
Removal of the cylinder head vent .....	<b>47</b>
Removal of secondary fuel filter and lines .....	<b>48</b>
Removal of the exhaust manifold .....	<b>49</b>
Removal of injector control tube and bracket assembly .....	<b>50</b>
Removal of cylinder head assembly .....	<b>51</b>
Removal of the injector .....	<b>52</b>
Removal of oil pump assembly and oil pressure regulator assembly .....	<b>53</b>
Removal of piston assembly and connecting rod assembly ..	<b>54</b>
Removal of cylinder liners .....	<b>55</b>
Removal of blower assembly and attached parts .....	<b>56</b>
Removal of the starting motor assembly .....	<b>57</b>
Removal of the oil cooler assembly .....	<b>58</b>
Removal of the clutch assembly .....	<b>59</b>
Removal of the flywheel and flywheel housing .....	<b>60</b>
Removal of fan oil pipe, tachometer drive, and balance weight cover .....	<b>61</b>
Removal of vibration damper assembly .....	<b>62</b>
Removal of crankshaft rear cover .....	<b>63</b>

DISASSEMBLY OF THE ENGINE

	Paragraph
Removal of weight and hub assembly and fan drive gear and balance weight assembly .....	64
Removal of camshaft, balancer shaft, and end bearings .....	65
Removal of the crankshaft gear, idler gear and spacer and dowel .....	66
Removal of the cylinder block end plates .....	67
Removal of the crankshaft .....	68

34. FACILITIES.


Facilities must include two engine stands—one to hold the power plant and the other to hold a single engine—a hoist, a work bench, a complete set of special tools covered in section XXIV, and a complete set of standard tools. All the tools needed for each major operation are listed at the beginning of each paragraph. The tools needed for each step in the operation are listed at the beginning of the step.

35. GENERAL PRECAUTIONS.

- a. Using care in the disassembly of the engine, or of any subassembly or accessory of the engine, will simplify the operations of inspection, servicing, and reassembly. Orderliness and cleanliness are of primary importance and must be observed at all times.
- b. Before starting to disassemble the engine, thoroughly clean the entire exterior to remove dirt, oil or other material which otherwise might get into the interior of assemblies as they are removed from the engine.
- c. All component parts of each assembly should be cleaned thoroughly as soon as disassembly is completed and before any inspections are made. Parts or assemblies not reinstalled immediately should be covered with cloth or paper covers to protect against dust or dirt.
- d. Old gaskets should be replaced with new ones, and care should be taken to see that all traces of the old gasket and shellac have been removed. Use sealing compound or fresh shellac on new gaskets whenever indicated in the manual.
- e. Use the special tools provided for the engine to remove all parts that are a tight or pressed fit. DO NOT PRY OFF ANY SUCH PARTS WITH SCREWDRIVERS OR BARS, as this may lead to damaged bearings or parts out of alinement or create difficulties in assembly.
- f. Use care in removing and handling bearings and other smooth, working surfaces, to protect them from dirt or scoring.
- g. To simplify assembly, provide sufficient room for laying out disassembled parts in order. Provide racks for valves, pistons, and connecting rods and proper receptacles for bolts, washers, and small parts.
- h. Since many of the same parts are used in both the LA and the LC engines, it is particularly important to note the location of each



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11150

**Figure 15—Front View of Power Plant**

## DISASSEMBLY OF THE ENGINE

removed part on the engine, and to keep all parts removed from the LA engine separate from the parts removed from the LC engine. Special care should be used to mark or otherwise identify all bearings and the points from which they are removed, so that they can be reinstalled in the same location. Because of the similarity of the front and rear ends of the engine block, it is important to note carefully the end from which each part is removed.

i. To eliminate the possibility of stripping threads on reassembly, note the location of National Fine-thread bolts when disassembling. This is easy to do, since all bolt holes in steel have the National Fine thread, while holes in cast iron or in aluminum are NC or National Coarse (standard) thread.

### 36. REMOVAL OF ENGINE TRANSFER GEAR HOUSING.

#### a. Equipment.

Screwdriver

Wrench, pipe

Wrench, plug, 1/2-in.

Wrench, socket, 7/16-in.

Wrench, socket, 9/16-in.

Wrench, socket, 2 3/4-in.


#### b. Procedure.

##### (1) REMOVAL OF PLUGS AND ELBOWS.

Wrench, pipe

Wrench, plug, 1/2-in.

Using a 1/2-inch plug wrench, remove the oil drain plug from the




RA PD 11151

**Figure 16—Removing Engine Drive Shaft Cover**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

COVER, CLUTCH HOUSING INSPECTION HOLE

RA PD 11152



COVER, FLYWHEEL HOUSING INSPECTION HOLE      SCREW, CAP, STARTING MOTOR

**Figure 17—Location of Flywheel Housing Inspection Hole Cover**

housing drain elbow, and drain the oil from the engine transfer gear housing. Using a pipe wrench, remove the two elbows. Using the plug wrench, remove the two plugs.

**(2) REMOVAL OF ENGINE DRIVE SHAFT COVERS (figs. 19 and 20).**

Wrench, socket,  $\frac{9}{16}$ -in.

Using a  $\frac{9}{16}$ -inch socket wrench, remove the six bolts and lock washers holding each engine drive shaft cover to the engine transfer gear housing and remove the covers.

**(3) REMOVAL OF FLYWHEEL HOUSING INSPECTION HOLE COVER (fig. 17).**

Wrench, socket,  $\frac{7}{16}$ -in.

With a  $\frac{7}{16}$ -inch socket wrench, remove the two bolts and lock washers holding the flywheel housing cover to the flywheel housing and remove the cover.

**(4) REMOVAL OF ENGINE DRIVEN SHAFT FLANGE.**


Screwdriver

Wrench, socket,  $2\frac{3}{4}$ -in.


Wrench, socket,  $\frac{9}{16}$ -in.

Holding the flywheel ring gear with a screwdriver, loosen the driven shaft nut with a  $2\frac{3}{4}$ -inch socket wrench and remove the nut (fig. 18).

# DISASSEMBLY OF THE ENGINE



**Figure 18—Removing Engine Driven Shaft Nut**



RA PD 11154

**Figure 19—Engine Transfer Gear Housing Partly Removed**


# ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71 POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2

Next, loosen slightly the two engine drive shaft nuts. Using a  $\frac{3}{16}$ -inch socket wrench, replace the drive shaft covers with one or two bolts in order to keep the drive shaft bearings clean during other operations. Pull off the driven shaft flange from the splined shaft and replace the engine drive shaft nut.

## (5) REMOVAL OF THE ENGINE TRANSFER GEAR HOUSING.

Bolts, puller (NC),  $\frac{3}{8}$ -in., four      Wrench, socket,  $\frac{3}{16}$ -in.

Using a  $\frac{3}{16}$ -inch socket wrench, remove the 24 bolts and lock washers holding the engine transfer gear housing to the clutch housing. Install four long  $\frac{3}{8}$ -inch standard (NC) thread puller bolts in the puller screw holes in the transfer gear housing (fig. 19). Turn the four bolts, giving each a few turns in sequence until the gear housing is forced off the dowel pins which are attached to the clutch housing, and lift off the transfer gear housing and gears.



**Figure 20—Front View Power Plant with Gear Housing Removed**

## 37. REMOVAL OF CLUTCH HOUSING.

### a. Equipment.

Screwdriver

Wrenches, open-end,  $\frac{7}{16}$ -in., two


Wrench, open-end,  $\frac{5}{8}$ -in.

Wrench, plug, with ratchet handle,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{3}{16}$ -in.

**DISASSEMBLY OF THE ENGINE**FITTING, CLUTCH RELEASE  
BEARING HOSECOVER, CLUTCH HOUSING  
INSPECTION HOLE

RA PD 11157



**Figure 21--Removing Clutch Housing Inspection Hole Cover**

**b. Procedure.**

**(1) REMOVAL OF THE CLUTCH SHIFTER LEVERS.**

Screwdriver

Wrench, open-end,  $\frac{5}{8}$ -in.Wrench, open-end,  $\frac{7}{16}$ -in.


(NOTE: If it is desired to remove the clutch housing and clutch assembly as a unit, the clutch shifter levers can be left on and removed later when disassembling the clutch housing.) Using a  $\frac{7}{16}$ -inch open-end wrench, remove the lubrication fittings from the clutch shifter shafts. Remove the shifter lever bolts, using a  $\frac{5}{8}$ -inch open-end wrench. Then remove the shifter levers from the shaft. If necessary, use a heavy screwdriver to pry them off.

**(2) REMOVAL OF THE TWO CLUTCH HOUSING INSPECTION HOLE COVERS (figs. 17 and 21).**

Wrenches, open-end,  $\frac{7}{16}$ -in., two

Using a  $\frac{7}{16}$ -inch open-end wrench, remove the bolts and lock washers holding each inspection hole cover to the clutch housing. Hold the clutch release bearing hose fitting coupling with a  $\frac{7}{16}$ -inch open-end wrench and remove the clutch release bearing fittings with another  $\frac{7}{16}$ -inch open-end wrench (fig. 21). Lift off the inspection hole cover and gasket and replace the fitting temporarily in the hose connection. Drop the hose into the clutch housing.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11158

**Figure 22—Removing Clutch Housing**

**(3) REMOVAL OF THE FIVE CLUTCH HOUSING PLUGS (fig. 20).**

Handle, socket,  $\frac{1}{2}$ -in.

With a  $\frac{1}{2}$ -inch drive socket handle, loosen and remove the five plugs in the clutch housing which give access to the inside clutch housing bolts.

**(4) REMOVAL OF THE CLUTCH HOUSING (figs. 20 and 22).**

Wrench, socket,  $\frac{9}{16}$ -in.

Using a  $\frac{9}{16}$ -inch socket wrench, remove all the bolts and lock washers (including those that are reached through the plug holes) holding the clutch housing to the flywheel housings. Install four of the bolts into the puller holes and turn each a few turns at a time until the clutch housing is forced off the dowel pins and away from the flywheel housings.

**38. REMOVAL OF THE FAN AND RELATED PARTS.**

**a. Equipment.**


Screwdriver

Wrench, open-end,  $\frac{1}{2}$ -in.

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{3}{4}$ -in.

DISASSEMBLY OF THE ENGINE




RA PD 11159

Figure 23—Rear View of Power Plant




**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

RA PD 11160



**Figure 24—Fan with Cover Removed**

NUT, FAN DRIVE PLATE AND HUB




COVER AND LEVER, GOVERNOR; ASSEMBLY

HOUSING, GOVERNOR CONTROL

**Figure 25—Fan Tower Showing Plate and Hub Assembly**

## DISASSEMBLY OF THE ENGINE

RA PD 11163



**Figure 26—Removing Fan Shaft**

### b. Procedure.

#### (1) REMOVAL OF FAN HUB COVER AND FAN ASSEMBLY.

Screwdriver

Wrench, socket,  $\frac{3}{4}$ -in.

Wrench, open-end,  $\frac{1}{2}$ -in.

Using a screwdriver, remove the four slotted bolts and remove the fan hub cover. Using a  $\frac{3}{4}$ -inch socket wrench, remove the bolt in the end of the fan shaft and remove the lock washer and flat washer. Using a  $\frac{1}{2}$ -inch open-end wrench, remove the six nuts and lock washers (fig. 25) that hold the fan assembly to the fan drive plate and hub assembly. Pull off the fan assembly.

#### (2) REMOVAL OF FAN SHAFT.

Wrench, open-end,  $\frac{9}{16}$ -in.

Remove four of the nuts and lock washers, holding the fan bearing and oil seal retainer to the fan tower ( $\frac{9}{16}$ -in. open-end wrench). Unhook governor lever retracting spring before removing the final nut holding the clip. Pull out the fan shaft, bringing with it the plate and hub assembly and the bearing and oil seal retainer.

### 39. REMOVAL OF AIR CLEANER ASSEMBLIES (fig. 27).

Loosen the wing bolts holding the air cleaner assemblies to the air inlet housing. Lift off the air cleaner assemblies, and plug the openings of the air cleaner mounting tubes with wooden plugs.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**40. REMOVAL OF OIL COOLER WATER DRAIN VALVE  
ASSEMBLY (fig. 27).**

**a. Equipment.**

<b>Pliers</b>	<b>Wrench, open-end, <math>\frac{1}{8}</math>-in.</b>
<b>Wrench, open-end, <math>\frac{1}{16}</math>-in.</b>	<b>Wrench, pipe</b>

**b. Procedure.**

**(1) LOOSEN CONNECTION AT UNIVERSAL JOINT.**

<b>Pliers</b>	<b>Wrench, open-end, <math>\frac{1}{8}</math>-in.</b>
---------------	---

Remove the cotter pin (pliers). Using a  $\frac{1}{8}$ -inch open-end wrench, loosen the packing gland nut until the valve, rod and universal joint assembly comes free.

**(2) REMOVAL OF BRACKET FROM GOVERNOR WEIGHT HOUSING.**

**Wrench, open-end,  $\frac{1}{16}$ -in.**

Using a  $\frac{1}{16}$ -inch open-end wrench, remove the two bolts holding the bracket to the governor weight housing cover and remove the rod and handle. Replace the two bolts on the governor weight housing cover.

**(3) REMOVAL OF ELBOW.**

**Wrench, pipe**

Using a pipe wrench, remove the elbow, and the universal joint which is attached to the elbow, from the bottom of the oil cooler housing.

**41. REMOVAL OF LA ENGINE FROM STAND.**

**a. Equipment.**

<b>Hoist, chain</b>	<b>Wrench, socket, <math>\frac{3}{4}</math>-in.</b>
<b>Wrench, open-end, <math>\frac{3}{4}</math>-in.</b>	

**b. Procedure.**

**(1) REMOVAL OF ENGINE TIE PLATE (fig. 23).**

<b>Wrench, open-end, <math>\frac{3}{4}</math>-in.</b>	<b>Wrench, socket, <math>\frac{3}{4}</math>-in.</b>
---	---

Using a  $\frac{3}{4}$ -inch open-end wrench and a  $\frac{3}{4}$ -inch socket wrench, remove the bolts and lock washers that fasten the engine tie plate to the balance weight covers of both engines. Remove the plate.

**(2) REMOVAL OF LA ENGINE FROM STAND.**

Attach the chain hoist to the front and rear engine lifter brackets and lift the engine out of the stand.

**42. REMOVAL OF GENERATOR.**

**a. Equipment.**

**Wrenches, open-end,  $\frac{9}{16}$ -in., two**

**b. Procedure.**

**NOTE:** The generator does not have to be removed in order to remove the LA engine from the stand. Before removing the LC engine, however, it is necessary to remove the generator as follows: Using two

DISASSEMBLY OF THE ENGINE





Figure 27 --Side View of Power Plant

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
 POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11165

**Figure 28—Removing LA Engine from Stand**

$\frac{9}{16}$ -inch open-end wrenches, remove the nuts and lock washers from the four through bolts holding the generator to the flywheel housing. Remove the two remaining bolts and lock washers. Then lift off the generator and remove the gasket.

**43. REMOVAL OF FUEL AND ENGINE OIL TUBES, HIGH-TENSION LEADS AND JUNCTION PLATES.**

**a. Equipment.**

Pliers

Screwdriver

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, open-end,  $\frac{9}{16}$ -in.


Wrench, open-end,  $\frac{5}{8}$ -in.

Wrench, open-end,  $\frac{3}{4}$ -in.

Wrench, socket,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.


DISASSEMBLY OF THE ENGINE



RA PD 11166

Figure 29—Side View of Power Plant

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



RA PD 11167

Figure 30—Side View of LA Engine

## DISASSEMBLY OF THE ENGINE

### h. Procedure.

#### (1) REMOVAL OF AIR HEATER COVERS (fig. 30).

Wrench, socket,  $\frac{1}{2}$ -in.

Using a  $\frac{1}{2}$ -inch socket wrench, remove the four bolts that hold the two air heater covers to the air heater bodies. Remove the covers and gaskets.

#### (2) REMOVAL OF FUEL INLET TUBES (TEE TO HEATER) (figs. 30 and 31).

Screwdriver

Wrench, open-end,  $\frac{7}{16}$ -in.

Using a screwdriver, remove the slotted-head bolts from the clips holding the fuel inlet tubes (tee to heater) to the air heater bodies. Using a  $\frac{7}{16}$ -inch open-end wrench, disconnect the couplings at both ends and remove the tubes.

#### (3) REMOVAL OF FUEL INLET TUBES (LOWER JUNCTION PLATE TO TEE) (figs. 30 and 31).

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, open-end,  $\frac{9}{16}$ -in.

Using a  $\frac{7}{16}$ -inch open-end wrench, disconnect the upper end of the fuel inlet tube (lower junction to tee) from the three-way tee (fig. 30). Using a  $\frac{7}{16}$ -inch open-end wrench and a  $\frac{9}{16}$ -inch open-end wrench, disconnect the coupling from the lower end of the tube and remove the tube.

#### (4) REMOVAL OF FUEL INLET TUBE (LOWER JUNCTION PLATE TO UPPER JUNCTION PLATE).

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

NOTE: This operation is performed on the LC engine only. LA engines do not have a lower-to-upper junction plate fuel inlet tube. Using a  $\frac{9}{16}$ -inch open-end wrench and  $\frac{5}{8}$ -inch open-end wrench, disconnect the couplings at both ends of the fuel inlet tube (lower junction plate to upper junction plate) and remove the tube.

#### (5) REMOVAL OF ENGINE OIL FILTER OUTLET TUBE (figs. 30 and 31).

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

Wrench, open-end,  $\frac{9}{16}$ -in.

Using a  $\frac{9}{16}$ -inch open-end wrench, disconnect the coupling at the lower end of the engine oil filter outlet tube (fig. 31). With a  $\frac{9}{16}$ -inch open-end wrench and a  $\frac{5}{8}$ -inch open-end wrench, disconnect the coupling at the upper end of the tube and remove the tube.

#### (6) REMOVAL OF ENGINE OIL FILTER INLET TUBE (Figs. 30 and 31).

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

Using a  $\frac{9}{16}$ -inch open-end wrench, disconnect the engine oil filter inlet tube at the two-way tee elbow. Using a  $\frac{7}{16}$ -inch open-end wrench and a  $\frac{5}{8}$ -inch open-end wrench, disconnect the tube at the upper junction plate and remove the tube.



ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 31—Side View of LA Engine

## DISASSEMBLY OF THE ENGINE

### (7) REMOVAL OF OIL PRESSURE GAGE TUBE.

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

Using a  $\frac{7}{16}$ -inch open-end wrench and a  $\frac{5}{8}$ -inch open-end wrench, disconnect the oil pressure gage tube at the lower junction plate. Disconnect the tube at the two-way tee elbow with a  $\frac{9}{16}$ -inch open-end wrench and remove the tube.

### (8) REMOVAL OF FUEL PUMP INLET TUBE (UPPER JUNCTION PLATE TO FUEL PUMP) (figs. 18 and 31).

Wrench, open-end,  $\frac{5}{8}$ -in.

Wrench, open-end,  $\frac{3}{4}$ -in.

Using a  $\frac{5}{8}$ -inch open-end wrench, remove the clip (fig. 18) holding fuel pump inlet tube (upper junction plate to fuel pump) to the flywheel housing. Using a  $\frac{3}{4}$ -inch open-end wrench, disconnect the couplings at both ends of the tube and remove the tube.

### (9) REMOVAL OF HIGH-TENSION LEADS (figs. 28, 30 and 31).

Pliers

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

With pliers remove the nuts from the insulators on the air heater bodies, disconnecting the high-tension leads. Using a  $\frac{5}{8}$ -inch open-end wrench, remove the bolt holding the two clips securing the high-tension leads. Using a  $\frac{9}{16}$ -inch socket wrench, remove the bolts from the four clips holding the high-tension leads to the flywheel housing and remove the high-tension leads (fig. 28).

### (10) REMOVAL OF THREE-WAY TEE.

Wrench, open-end,  $\frac{5}{8}$ -in.

Using a  $\frac{5}{8}$ -inch open-end wrench to remove the bolt, remove the two clips and the three-way tee.

### (11) REMOVAL OF THE UPPER AND LOWER JUNCTION PLATES (figs. 30 and 31).

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

Using a  $\frac{9}{16}$ -inch open-end wrench, remove the two nuts and lock washers holding the upper junction plate to the flywheel housing and remove the plate. Using a  $\frac{5}{8}$ -inch open-end wrench, remove the two bolts and lock washers bolting the lower junction plate to the engine block.

## 44. ATTACHING ENGINE TO ROTATING ENGINE STAND.

### a. Equipment.

Hoist, chain

Wrench, open-end,  $\frac{5}{8}$ -in.

Stand, rotating engine  
(tool KM-J-1926)

Wrench, open-end,  $1\frac{1}{2}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

### b. Procedure.

#### (1) REMOVAL OF CYLINDER BLOCK HANDHOLE COVERS (fig. 31).

Wrench, socket,  $\frac{9}{16}$ -in.

Using a  $\frac{9}{16}$ -inch socket wrench, remove the bolts, lock washers, and

# **ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71 POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

copper gaskets and remove the cylinder block handhole covers. **NOTE:** Two of the covers are located on the opposite side of the engine.

## **(2) REMOVAL OF AIR HEATER BODIES (fig. 31).**

Wrench, socket,  $\frac{11}{16}$ -in.

Using a  $\frac{11}{16}$ -inch socket wrench, remove the two bolts that hold each air heater body to the cylinder block and remove the bodies and copper gaskets.

## **(3) ATTACHING ENGINE TO ROTATING ENGINE STAND.**

Hoist, chain


Wrench, open-end,  $\frac{5}{8}$ -in.

Stand, rotating engine

Wrench, open-end,  $1\frac{1}{2}$ -in.

(tool KM-J-1926)

With the engine on the chain hoist, line up the second, third, and fourth handhole openings (from the flywheel or front end of the engine) with the holding clamps on the rotating engine stand (KM-J-1926) plate. After inserting the holding clamps through the handhole openings, turn the clamps with the handles so that the clamps bridge across the handhole openings and the engine is locked to the stand plate. Using a  $1\frac{1}{2}$ -inch open-end wrench, tighten the holding clamp locking nuts, locking the engine in place (fig. 33). Install two  $\frac{11}{16}$ -inch National Coarse-thread bolts and washers at the bottom of the plate and tighten with a  $\frac{5}{8}$ -inch open-end wrench.



RA PD 11169

**Figure 32—Rotating Engine Stand**

DISASSEMBLY OF THE ENGINE

RA PD 11170




Figure 33—LA Engine Mounted on Stand

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**45. REMOVAL OF WATER BYPASS TUBE (figs. 23 and 34).**

**a. Equipment.**

Wrench, open-end, 1½-in.

Wrench, socket, ⅜-in.

**b. Procedure.**

Using a ⅜-inch socket wrench, remove the two bolts and lock washers holding the two water bypass tube clips to the cylinder block end plate. Remove the two bolts and lock washers holding the lower end of the tube to the oil cooler housing. Using a 1½-inch open-end wrench, remove the nut holding the upper end of the tube to the upper elbow and remove the water bypass tube and gaskets. Using a ⅜-inch socket wrench, remove the two bolts and lock washers holding the upper elbow to the thermostat housing.

**46. REMOVAL OF GOVERNOR CONTROL HOUSING.**

**a. Equipment.**

Screwdriver

Wrench, open-end, ½-in.

Wrench, open-end, ⅜-in.

**b. Procedure.**

**(1) REMOVAL OF ROCKER ARM COVER (fig. 33).**

Loosen the four rocker arm cover bolts and lift off the rocker arm cover.

**(2) REMOVAL OF GOVERNOR CONTROL HOUSING (figs. 25 and 35).**

Screwdriver

Wrench, open-end, ⅞-in.

Using a screwdriver, remove the four bolts and lock washers from the governor cover and lever assembly. Lift off the cover and lever assembly and the gasket. Remove the cotter pin from the link pin holding the governor control link to the injector control rack tube (fig. 35). Remove the link pin, freeing the upper end of the governor control link. Remove the retainer spring and flat washer from the differential lever and pin assembly and lift out the governor control link. Replace the flat washer and retainer spring on the differential lever and pin assembly. Using a ⅞-inch open-end wrench, remove the four bolts and lock washers from the weight housing cover and lift off the cover (fig. 27). Next, using a ⅞-inch open-end wrench, remove the bolts holding the governor assembly to the cylinder head. Lift off the governor control housing from the governor weight housing assembly dowel pins and remove the gasket.

**47. REMOVAL OF THE CYLINDER HEAD VENT (fig. 33).**


**a. Equipment.**

Wrench, socket, ⅞-in.

**b. Procedure.**

Using a ⅞-inch socket wrench, remove the four bolts and lock washers

# DISASSEMBLY OF THE ENGINE



RA PD 11171

Figure 34—LA Engine, Rear End

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2





Figure 35—Removing Governor Control Link

SCREW AND NUT, PART OF BUFFER SCREW  
AND SPRING ASSEMBLY  
SPRING RETAINER  
RA PD 11172

## DISASSEMBLY OF THE ENGINE

BOLT, GOVERNOR TO CYLINDER HEAD

RA PD 11174



**Figure 36—Removing Governor Control Housing**

that hold the vent to the cylinder head and flywheel housing. Lift off the vent and the two gaskets.

### 48. REMOVAL OF SECONDARY FUEL FILTER AND LINES.

#### a. Equipment.

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, open-end,  $1\frac{1}{8}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

#### b. Procedure.

(1) REMOVAL OF FUEL PUMP TO SECONDARY FUEL FILTER TUBE AND CLIP (fig. 28).

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

Using a  $\frac{5}{8}$ -inch open-end wrench, remove the couplings from both ends of the tube. Next, using a  $\frac{9}{16}$ -inch open-end wrench, remove the nut and lock washer from the blower drive cover and remove the clip and tube.

(2) REMOVAL OF THE SECONDARY FUEL FILTER ELEMENT AND SHELL (fig. 28).

Wrench, open-end,  $1\frac{1}{8}$ -in.

Using a  $1\frac{1}{8}$ -inch open-end wrench at point "A," remove the center stud



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

assembly and remove the element, gasket and shell from the secondary fuel filter.

(3) **REMOVAL OF FUEL FILTER TO LOWER FUEL MANIFOLD TUBE** (fig. 28).

Wrench, open-end,  $\frac{5}{8}$ -in.

Using a  $\frac{5}{8}$ -inch open-end wrench, remove the coupling from the secondary fuel filter cover and the lower fuel manifold and remove the fuel filter to lower manifold tube.

(4) **REMOVAL OF SECONDARY FUEL FILTER COVER.**

Wrench, open-end,  $\frac{9}{16}$ -in.

Using a  $\frac{9}{16}$ -inch open-end wrench, remove the two bolts, lock washers, and flat washers holding the filter cover to the cylinder head and remove the cover.

**49. REMOVAL OF THE EXHAUST MANIFOLD** (fig. 30).

a. **Equipment.**

Wrench, socket,  $\frac{5}{8}$ -in.

b. **Procedure.**

Using a  $\frac{5}{8}$ -inch socket wrench, remove the nuts and washers holding the exhaust manifold to the cylinder head. Lift up and remove the manifold. Remove the three manifold gaskets.

**50. REMOVAL OF INJECTOR CONTROL TUBE AND BRACKET ASSEMBLY** (fig. 38).

a. **Equipment.**

Wrench, socket, with universal handle,  $\frac{7}{8}$ -in.

b. **Procedure.**

Using the  $\frac{7}{8}$ -inch socket wrench with universal handle, remove the four bolts and lock washers holding the brackets which fasten the injector control tube and bracket assembly to the cylinder head. Lift out the tube and bracket assembly.

**51. REMOVAL OF CYLINDER HEAD ASSEMBLY.**

a. **Equipment.**

Hoist, chain

Wrench, socket, with extension  
handle,  $\frac{1\frac{1}{2}}$ -in.

Wrench, open-end,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{5}{8}$ -in.

b. **Procedure.**

(1) **DISCONNECT FUEL PIPES AT FUEL CONNECTOR** (fig. 37).

Using a  $\frac{1}{2}$ -inch open-end wrench, detach the 12 fuel pipes from the fuel connector and nut assemblies. Loosen the 12 fuel pipes on the injector side and swing them away to gain access to the cylinder head nuts.

DISASSEMBLY OF THE ENGINE





Figure 37 -Cylinder Head with Rocker Arm Cover Removed

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**TUBE AND BRACKET, INJECTOR;  
AND GOVERNOR CONTROL  
ASSEMBLY**



RA PD 11176

NUT, COUPLING —  
PART OF FUEL PIPE ASSEMBLY

**Figure 38—Removing Injector Control Tube and Bracket Assembly**

(2) REMOVE CYLINDER HEAD (fig. 39).

Wrench, socket,  $\frac{5}{8}$ -in.

Wrench, socket, with extension  
handle,  $\frac{1}{2}$ -in.

Using the  $\frac{5}{8}$ -inch socket wrench, remove the four bolts holding the engine lifter brackets to the flywheel housing at one end and the balance weight cover at the other end (fig. 37). Do not remove the bolts holding the lifter bracket to the cylinder head. Next, using the  $\frac{1}{2}$ -inch socket wrench with extension handle, remove the cylinder head nuts, starting with the end pairs and working in toward the center. Remove the cylinder head, hooking the chain hoist into the engine lifter brackets (fig. 40). When placing the head on a bench, place it on wooden blocks so as not to damage the cam followers on the bottom of the head.

**52. REMOVAL OF THE INJECTOR (figs. 41 and 42).**

**a. Equipment.**

Tool KM-J-1227

Wrench, socket,  $\frac{9}{16}$ -in.


Wrench, open-end,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{3}{4}$ -in.


**b. Procedure.** (NOTE: The injector assembly can be removed without removing the cylinder head.) Using a  $\frac{1}{2}$ -inch open-end wrench, disconnect the fuel pipes at the injector side of the engine and loosen

## DISASSEMBLY OF THE ENGINE

RA PD 11177




**Figure 39—Removing Cylinder Head Nuts**



**Figure 40—Removing Cylinder Head**


ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



RA PD 11179

Figure 41—Top View of Cylinder Head

## DISASSEMBLY OF THE ENGINE



**Figure 42—Removal of Injector Assembly**

them at the fuel connectors. Using a  $\frac{3}{4}$ -inch socket wrench, remove the two rocker arm bracket bolts. Lift off the rocker arm brackets and slide out the rocker arm shaft and plug assembly. Push back the three rocker arms. Next, using a  $\frac{9}{16}$ -inch socket wrench, remove the injector clamp nut, washer, and clamp and pry out the injector with tool KM-J-1227. Remove remaining five injectors in the same manner. For disassembly, servicing, and reassembly of the injector, see section XII.

### 53. REMOVAL OF OIL PUMP ASSEMBLY AND OIL PRESSURE REGULATOR ASSEMBLY.

#### a. Equipment.

Pliers, cutting

Wrench, box,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, socket, 1-in.

#### b. Procedure.


##### (1) REMOVAL OF OIL PAN DRAIN PLUGS (fig. 43).

Wrench, socket, 1-in.

While the engine is in a horizontal position on the stand, remove the two oil pan drain plugs and gaskets, in order to drain out any oil left in the oil pan. Inspect the threads and plug gaskets before replacing the plugs in the pan (see figure 43 for location of plugs).

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

RA PD 11180



**Figure 43—LA Engine, Bottom View**

## DISASSEMBLY OF THE ENGINE

(2) REMOVAL OF THE OIL INLET AND OUTLET ELBOWS AND THE OIL PAN (fig. 43).

Wrench, socket,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

Turn engine on stand to a vertical position. Using a  $\frac{9}{16}$ -inch socket wrench, remove the four bolts and lock washers that hold the inlet and outlet elbows to the oil pan. Lift off the elbows and gaskets.

(3) REMOVAL OF OIL PAN.

Wrench, socket,  $\frac{1}{2}$ -in.

Using a  $\frac{1}{2}$ -inch socket wrench, remove all the bolts and lock washers that hold the oil pan to the engine crankcase. Lift off the oil pan. Remove the oil pan gasket.

(4) REMOVAL OF THE OIL PUMP ASSEMBLY (fig. 44).

Pliers, cutting

Wrench, socket,  $\frac{1}{2}$ -in.

Wrench, box,  $\frac{9}{16}$ -in.

Using a  $\frac{1}{2}$ -inch socket wrench, remove the two bolts and lock washers that hold the pressure pump outlet pipe to the cylinder block. Using a  $\frac{9}{16}$ -inch box wrench, remove the clip bolt which holds the scavenging pump inlet pipe to the bearing cap. With a pair of cutting pliers, cut and remove the locking wire from the bolts which hold the oil pump assembly to the number 1 and number 2 main bearing caps; and using a  $\frac{9}{16}$ -inch box wrench, remove the four bolts. Lift off the oil pump assembly.

(5) REMOVAL OF THE OIL PRESSURE REGULATOR ASSEMBLY (fig. 44).

Wrench, socket,  $\frac{1}{2}$ -in.

Using a  $\frac{1}{2}$ -inch socket wrench, remove the two bolts and lock washers that hold the oil pressure regulator to the cylinder block.

## 54. REMOVAL OF PISTON ASSEMBLY AND CONNECTING ROD ASSEMBLY.

### a. Equipment.

Hammer

Screwdriver

Pliers, side cutting

Wrench, socket,  $\frac{1}{4}$ -in.

### b. Procedure.

(1) REMOVAL OF CONNECTING ROD BEARINGS (figs. 44 and 45).


Pliers, side-cutting

Wrench, socket,  $\frac{1}{4}$ -in.

Using a pair of side-cutting pliers, remove the cotter pins from the connecting rod nuts. Using an  $\frac{1}{4}$ -inch socket wrench, remove the two connecting rod nuts. Remove the connecting rod bearing cap and the lower connecting rod bearing shell. Remove the upper connecting rod bearing shell by pushing it from the side opposite the tang and lifting it out from the bottom (fig. 45).




**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



**Figure 44—Engine, Bottom View with Oil Pan Removed**

## DISASSEMBLY OF THE ENGINE



**Figure 45—Removing Upper Connecting Rod Bearing**

### (2) REMOVAL OF PISTON ASSEMBLY AND CONNECTING ROD ASSEMBLY.

Hammer

Knife or scraper

(NOTE: Pistons can be removed more easily if the accumulated carbon is scraped from around the top of the cylinder. A knife or scraper can be used for this purpose.) Using the end of a hammer handle, push the connecting rod up into the cylinder, forcing the piston out at the top, and lift out the piston and connecting rod assemblies. After removing each piston and connecting rod assembly, reassemble the bearings, bearing caps, and cap nuts so as to keep all the caps and bearings together on their respective connecting rods. NOTE: All the bearing caps and the connecting rods are numbered on the blower side of the engine and they should be assembled with these numbers corresponding and installed so that the numbers face the blower side of the engine.

### 55. REMOVAL OF CYLINDER LINERS (figs. 46 and 47).

#### a. Equipment.

Hammer


Tool KM-J-1918

#### b. Procedure.

Install the tool KM-J-1918 in the liner by sliding the base down through the liner and bringing it back up until it seats on the bottom of

**TM 9-1750G**  
**55**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11184

**Figure 46—Method of Attaching Cylinder Liner Tool**

DISASSEMBLY OF THE ENGINE

RA PD 11185





Figure 47 – Removing Cylinder Liner

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

the liner. Then push the spring-loaded top plate down tightly against the top of the liner (fig. 46). Strike the sliding hammer upward against the nut at the top of the tool (fig. 47) driving the liner up and out of the engine block. Remove the tool from the liner by pressing the spring knob on the plate and pushing the tool down far enough to tilt the bottom lever so that it can be withdrawn.



SHAFT, BLOWER DRIVE

RA PD 11184

**Figure 48—Removing Blower Drive Shaft**

**56. REMOVAL OF BLOWER ASSEMBLY AND ATTACHED PARTS (figs. 27, 48 and 49).**

**a. Equipment.**

Screwdriver

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, open-end,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.


Wrench, socket,  $\frac{5}{8}$ -in.

**b. Procedure.**

**(1) REMOVAL OF FLYWHEEL HOUSING SMALL HOLE COVER AND BLOWER DRIVE SHAFT.**

Wrench, socket,  $\frac{3}{16}$ -in.

To remove the flywheel housing small hole cover (fig. 15), use a  $\frac{3}{16}$ -inch socket wrench and remove the four nuts, lock washers and through bolts as well as the two bolts and washers that hold the cover



RA PD 11187

**Figure 49 - Blower Assembly, Including Accessories**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

to the flywheel housing. Remove the cover. In removing one of the through bolts, the bracket holding the fuel pump drip shield is released. Note that the small hole cover is on the LA engine only and that the generator is located in its place on the LC engine. Pull out the blower drive shaft (fig. 48).

**(2) DISCONNECT THE WATER PUMP (fig. 27).**

Screwdriver

Wrench, socket, 1/2-in.

Wrench open-end, 7/16-in.

Using a screwdriver, loosen the hose clamp on the water pump inlet seal between the water pump inlet elbow and the oil cooler assembly. Using a 7/16-inch open-end wrench, remove the two couplings on the ends of the water pump drain tube and remove the tube. Using a 1/2-inch socket wrench, remove the two bolts and lock washers that hold the water pump outlet packing flange to the cylinder block.

**(3) REMOVAL OF BLOWER AND ATTACHED PARTS (figs. 44 and 49).**

Wrench, socket, 5/8-in.

Using a 5/8-inch socket wrench, remove the eight bolts and flat washers that hold the blower assembly to the cylinder block (fig. 44). Move the blower assembly with the water pump assembly, governor weight and housing assembly, air inlet housing and fuel pump assembly forward and off the blower drive gear support (fig. 49). Remove the blower assembly gasket.

**(4) REMOVAL OF THE WATER PUMP ASSEMBLY.**

Wrench, open-end, 1/2-in.

Using a 1/2-inch open-end wrench, remove the three bolts that hold the water pump assembly to the blower assembly and remove the water pump and gasket.

**(5) REMOVAL OF THE FUEL PUMP ASSEMBLY.**

Wrench, open-end, 1/2-in.

Using a 1/2-inch open-end wrench, remove the three bolts that hold the fuel pump assembly to the blower assembly and remove the fuel pump and gasket.

**(6) REMOVAL OF THE GOVERNOR WEIGHT AND HOUSING ASSEMBLY.**

Wrench, open-end, 1/2-in.

Using a 1/2-inch open-end wrench, remove the six bolts that hold the governor weight and housing assembly to the blower assembly and remove the governor weight and housing and gasket.

**(7) REMOVAL OF THE BLOWER DRIVE GEAR SUPPORT ASSEMBLY.**

Wrench, open-end, 7/16-in.


Wrench, socket, 9/16-in.

Using a 7/16-inch open-end wrench, remove the couplings on the blower drive bearing oil pipe and remove the pipe. Next, using a 9/16-inch socket wrench, remove the two bolts and lock washers that hold the blower

**DISASSEMBLY OF THE ENGINE**

PIPE, BLOWER DRIVE  
BEARING OIL

SUPPORT, BLOWER DRIVE  
GEAR; ASSEMBLY



**Figure 50—Blower Drive Gear Support**

RA PD 11186



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

drive gear support assembly to the cylinder block rear end plate and lift off the assembly and gasket.

**57. REMOVAL OF THE STARTING MOTOR ASSEMBLY (fig. 17).**

**a. Equipment.**

Wrench, socket, and extension,  $\frac{7}{8}$ -in.

**b. Procedure.**

Using a  $\frac{7}{8}$ -inch socket wrench and extension, remove the three volts and lock washers that hold the starting motor assembly to the flywheel housing. Lift off the starting motor.

**58. REMOVAL OF THE OIL COOLER ASSEMBLY.**

**a. Equipment.**

Wrench, open-end,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{1}{2}$ -in.


**b. Procedure.**

**(1) REMOVAL OF OIL COOLER HOUSING (fig. 27).**

Wrench, open-end,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{1}{2}$ -in.

Using a  $\frac{1}{2}$ -inch socket wrench, remove the six through bolts and lock washers from the front of the oil cooler housing. Remove the two bolts



**Figure 51—Removing Oil Cooler Adapter**


## DISASSEMBLY OF THE ENGINE

and lock washers from the back of the oil cooler adapter—one at the top and one at the bottom—using a 1/2-inch open-end wrench. Lift off the oil cooler housing and gasket.

### (2) REMOVAL OF THE OIL COOLER ADAPTER.

Wrench, socket, 1/8-in.

Using a 1/8-inch socket wrench (fig. 51), remove the six bolts and lock washers that hold the oil cooler adapter to the cylinder block. Lift off the adapter and gasket.



**Figure 52—Removing Clutch Cover Plate**

## 59. REMOVAL OF THE CLUTCH ASSEMBLY.

### a. Equipment.

Tool KM-J-1914

Wrench, socket, 1/2-in.

### b. Procedure.

#### (1) REMOVAL OF CLUTCH COVER PLATE (figs. 52 and 53).

Wrench, socket, 1/2-in.

Using a 1/2-inch socket wrench, remove the twelve bolts and lock washers that hold the clutch cover plate to the flywheel (fig. 52). Lift off the cover plate and then remove the clutch spring with release bearing sleeve, the clutch pressure plate and the clutch driven disk assembly. If 1/8-inch compression shims were in place between the clutch driven disk and the flywheel, these should be removed.

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 53—Clutch Disk Assembly

(2) REMOVAL OF THE CLUTCH PILOT BEARING.

Tool KM-J-1914

Using tool KM-J-1914, remove the clutch pilot bearing (fig. 54).

60. REMOVAL OF THE FLYWHEEL AND FLYWHEEL HOUSING.

a. Equipment.

Hammer, soft

Pliers, side-cutting

Tool KM-J-1904

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{5}{8}$ -in.

Wrench, socket,  $\frac{3}{4}$ -in.

Wrench, socket,  $\frac{13}{16}$ -in.

b. Procedure.

(1) REMOVAL OF FLYWHEEL.

Pliers, side-cutting

Tool KM-J-1904

Wrench, socket,  $\frac{5}{8}$ -in.

Wrench, socket,  $\frac{13}{16}$ -in.

Using side-cutting pliers, cut and remove the locking wires on the six flywheel bolts. Using a  $\frac{13}{16}$ -inch socket wrench, remove the bolts. Next, install the two puller tools KM-J-1904 and turn each one a few turns at a time to force the flywheel off the crankshaft flange and the dowel pins (fig. 56). Lift out the flywheel and remove the two puller tools. Remove the clutch pilot bearing grease baffle.

DISASSEMBLY OF THE ENGINE




Figure 54—Removing Clutch Pilot Bearing




Figure 55—Removing Flywheel Bolts

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 56—Removing Flywheel





Figure 57—Flywheel Housing

DISASSEMBLY OF THE ENGINE



RA PD 11196

Figure 58—Engine Block, Blower Side with Blower Removed

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**


**(2) REMOVAL OF THE FLYWHEEL HOUSING.**

Hammer, soft

Wrench, socket,  $\frac{3}{4}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

Using a  $\frac{3}{4}$ -inch socket wrench, remove the six large bolts and lock washers from the inside of the housing. Next, using a  $\frac{9}{16}$ -inch socket wrench, remove the six small bolts from the inside of the housing. Then, using a  $\frac{9}{16}$ -inch socket wrench, remove the remaining through bolts, washers, and nuts that hold the housing to the cylinder block end plate (fig. 58). Then remove the two short bolts from the other side of the housing. Loosen the housing from the end plate with a soft hammer and lift it off the dowel pins



**Figure 59—Removal of Tachometer Drive**

**1. REMOVAL OF FAN OIL PIPE, TACHOMETER DRIVE, AND  
BALANCE WEIGHT COVER.**

**a. Equipment.**

Tool KM-J-1917

Wrench, open-end,  $\frac{5}{8}$ -in.

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, socket,  $\frac{1}{2}$ -in.

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

## DISASSEMBLY OF THE ENGINE

### **h. Procedure.**

#### **(1) REMOVAL OF FAN OIL PIPE (fig. 58).**

Wrench, open-end,  $\frac{7}{16}$ -in.

With a  $\frac{7}{16}$ -inch open-end wrench, remove the couplings from both ends of the fan oil pipe and remove the pipe.

#### **(2) REMOVAL OF TACHOMETER DRIVE (fig. 64).**

Tool KM-J-1917

Wrench, open-end,  $\frac{5}{8}$ -in.

Thread the tool KM-J-1917 onto the tachometer drive shaft and tighten the puller bolts to remove the drive from the balancer shaft.


#### **(3) REMOVAL OF BALANCE WEIGHT COVER (figs. 34 and 58).**

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{1}{2}$ -in.

Using a  $\frac{9}{16}$ -inch open-end wrench and  $\frac{9}{16}$ -inch socket wrench, remove all the bolts and lock washers from the outside of the balance weight cover. Using a  $\frac{1}{2}$ -inch socket wrench, remove the one bolt and lock washer from the other side of the cover (directly below the fan tower) (fig. 58). Lift off the cover.



RA PD 11197

**Figure 60—Vibration Damper Rear Cone Partly Removed**



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**62. REMOVAL OF VIBRATION DAMPER ASSEMBLY.**

**a. Equipment.**

Hammer, lead

Screwdrivers, two

Tool KM-J-1905

Wrench, socket,  $1\frac{5}{8}$ -in.

**b. Procedure.**

**(1) REMOVAL OF REAR CONE.**

Hammer, lead


Wrench, socket,  $1\frac{5}{8}$ -in.

Hold crankshaft from rotating and remove the vibration damper retainer bolt and cone retainer ( $1\frac{5}{8}$ -in. socket wrench). Remove the two Woodruff keys at the same time. Using a lead hammer, hit the front of the vibration damper assembly sharply near the edge in order to loosen the rear cone (fig. 60). Remove cone by using two screwdrivers, being careful not to scratch or mar the cone.

**(2) REMOVAL OF VIBRATION DAMPER.**

Tool KM-J-1905

Pull damper off by hand or use tool KM-J-1905 if damper fits tightly (fig. 61).



RA PD 11198

**Figure 61—Removing Vibration Damper with Tool KM-J-1905**

### DISASSEMBLY OF THE ENGINE




Figure 62—LA Engine with Balance Weight Cover Removed

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**(3) REMOVAL OF FRONT CONE.**

Screwdrivers, two

Pry out the Woodruff key with a screwdriver and remove the front cone using the two screwdrivers if necessary (fig. 62). **NOTE:** No Woodruff key is used after engine No. 6-71, 11399. It is not required and may be removed from prior units on overhaul.

**63. REMOVAL OF CRANKSHAFT REAR COVER (fig. 62).**

**a. Equipment.**


Hammer, soft

Wrench, socket,  $\frac{3}{4}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

**b. Procedure.**

Using a  $\frac{9}{16}$ -inch socket wrench, remove the three bolts and lock washers from the top of the crankshaft rear cover assembly. Next, using a  $\frac{3}{4}$ -inch socket wrench, remove the two long and the two short bolts and lock washers from the bottom part of the cover. Knock the cover loose with a soft hammer and remove it from the dowel pins, taking with it the engine rear support bracket. Remove the crankshaft oil slinger.



**Figure 63—Removing Rear Weight and Hub Assembly**

## DISASSEMBLY OF THE ENGINE

### 64. REMOVAL OF WEIGHT AND HUB ASSEMBLY AND FAN DRIVE GEAR AND BALANCE WEIGHT ASSEMBLY.

#### a. Equipment.

Tool KM-J-1931	Wrench, socket, 1½-in.
Wrench, open-end, $\frac{9}{16}$ -in.	

#### b. Procedure.

##### (1) REMOVAL OF FRONT WEIGHT AND HUB ASSEMBLY (figs. 62 and 63).

Tool KM-J-1931	Wrench, socket, 1½-in.
Wrench, open-end, $\frac{9}{16}$ -in.	

Using a 1½-inch socket wrench, loosen the shaft nuts on the rear end of the camshaft and the rear end of the balancer shaft. Using tool KM-J-1931, remove the rear weight and hub assembly (fig. 63).

##### (2) REMOVAL OF FAN DRIVE GEAR AND BALANCE WEIGHT ASSEMBLY.

Tool KM-J-1931	Wrench, socket, 1½-in.
Wrench, open-end, $\frac{9}{16}$ -in.	

Using tool KM-J-1931, remove the fan drive gear and balance weight assembly in the same manner.

### 65. REMOVAL OF CAMSHAFT, BALANCER SHAFT, AND END BEARINGS.

#### a. Equipment.

Block, wooden	Wrench, socket, $\frac{9}{16}$ -in.
Screwdriver	Wrench, socket, 1½-in.

#### b. Procedure.

##### (1) REMOVAL OF THE CAMSHAFT (figs. 65 and 66).

Block, wooden	Wrench, socket, $\frac{9}{16}$ -in.
Screwdriver	Wrench, socket, 1½-in.


Place a wooden block between the camshaft gear and balancer shaft gear to keep them from turning. Loosen the camshaft gear nut, using a 1½-inch socket wrench. Rotate the camshaft until the access hole in the camshaft gear is over one of the three bolts holding the end bearing to the cylinder block. Using a  $\frac{9}{16}$ -inch socket wrench, remove the three bolts and lock washers through the access hole in the gear (fig. 65). Using a screwdriver, remove from the top of the cylinder block the fillister-head bolts which hold the five camshaft intermediate bearings in position. Pull out the camshaft from the gear end (fig. 66).

##### (2) REMOVAL OF THE BALANCER SHAFT.

Wrench, socket, $\frac{9}{16}$ -in.	Wrench, socket, 1½-in.
-------------------------------------	------------------------

Remove the three end bearing bolts and the balancer shaft. Follow the procedure given in step (1) of this paragraph.

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



RA PD 11201

Figure 64—Timing Gear Train

DISASSEMBLY OF THE ENGINE




Figure 65—Removing Camshaft Bearing Bolt





Figure 66—Removing Camshaft

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



**Figure 67 — Camshaft and Balancer Shaft End Bearings**

(3) REMOVAL OF CAMSHAFT AND BALANCER SHAFT END BEARINGS FROM REAR END PLATE (fig. 67).

Wrench, socket,  $\frac{9}{16}$ -in.

Remove the six bolts which hold the camshaft end bearings and balancer shaft end bearing to the rear of the cylinder block ( $\frac{9}{16}$ -in. socket wrench). Remove the bearings. (NOTE: On the LA engine the two front bearings are grooved (thrust) bearings and the rear bearings are plain. On the LC engine, the front bearings are plain and the rear bearings are grooved.) Then carefully remove the two shafts from the cylinder block.

**66. REMOVAL OF THE CRANKSHAFT GEAR, IDLER GEAR AND SPACER AND DOWEL.**

**a. Equipment.**

Bolts, puller,  $\frac{1}{16}$ -in., NF, two

Wrench, socket,  $\frac{3}{4}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

**b. Procedure.**

(1) REMOVAL OF BOLTS AND OIL SLINGER FROM CRANKSHAFT GEAR (fig. 64).

Wrench, socket,  $\frac{9}{16}$ -in.

Using a  $\frac{9}{16}$ -inch socket wrench, remove the six bolts and lock washers

## DISASSEMBLY OF THE ENGINE

that hold the crankshaft gear oil slinger and the crankshaft gear to the crankshaft flange and remove the oil slinger.

### (2) REMOVAL OF CRANKSHAFT GEAR (fig. 68).


Bolts, puller,  $\frac{1}{8}$ -in., NF, two

Insert the two  $\frac{1}{8}$ -inch (National Fine) puller bolts in the crankshaft gear puller holes and turn them in alternately until the gear is forced away from the crankshaft flange. Lift off the gear and remove the puller bolts.

### (3) REMOVAL OF THE IDLER GEAR (fig. 68).

Wrench, socket,  $\frac{3}{4}$ -in.

Using a  $\frac{3}{4}$ -inch socket wrench, remove the bolt and lock washer that hold the idler gear assembly to the cylinder block. Remove the idler gear hub and dowel and lift off the idler gear. Lift off the spacer.



**Figure 68—Removing Crankshaft Gear**

### (4) REMOVAL OF THE IDLER GEAR HOLE SPACER AND DOWEL ASSEMBLY (figs. 64 and 65).

Wrench, socket,  $\frac{3}{4}$ -in.

Using a  $\frac{3}{4}$ -inch socket wrench, remove the bolt and lock washer that hold the idler gear hole spacer and dowel assembly to the cylinder block and lift off the spacer and dowel.



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**67. REMOVAL OF THE CYLINDER BLOCK END PLATES.**

**a. Equipment.**

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{3}{4}$ -in.

**b. Procedure.**

(1) Using a  $\frac{9}{16}$ -inch socket wrench, remove the six bolts and lock washers that hold the cylinder block front end plate to the block. Lift off the end plate and gasket from the dowel pins (near the bottom of the block).

**(2) REMOVAL OF FRONT AIR BOX DRAIN CLEANER.**

Pull out the front air box drain cleaner from the cored air passage tube in the end of the cylinder block (fig. 69).

**(3) REMOVAL OF CYLINDER BLOCK REAR END PLATE (fig. 62).**

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{3}{4}$ -in.

Using a  $\frac{9}{16}$ -inch socket wrench, remove the five small bolts and lock washers holding the rear end plate to the cylinder block. Using a  $\frac{3}{4}$ -inch socket wrench, remove the two larger bolts and lock washers holding the end plate to the cylinder block and lift the end plate off the two dowel pins near the bottom of the block and remove the gasket.

**(4) REMOVAL OF REAR AIR BOX DRAIN CLEANER.**

Pull out the rear air box drain cleaner from the air passage tube in the end of the cylinder block.

**68. REMOVAL OF THE CRANKSHAFT.**

**a. Equipment.**

Pliers, side-cutting

Tool KM-J-1472

Screwdriver

Wrench, socket,  $\frac{1}{2}$ -in.

**b. Procedure.**

**(1) REMOVAL OF MAIN BEARING CAPS (figs. 44, 45, 70 and 71).**

Pliers, side-cutting


Wrench, socket,  $\frac{1}{2}$ -in.

Tool KM-J-1472

Using a pair of side-cutting pliers, remove the cotter pins from the 14 main bearing cap nuts (fig. 44). Using a  $\frac{1}{2}$ -inch socket wrench, remove the nuts. Using the main bearing cap nuts, attach the lifting tool KM-J-1472 and pull out the main bearing caps with lower shells by driving the hammer of the tool against the head (fig. 70).

(2) **NOTE:** For clarity in showing the use of tool KM-J-1472, the crankshaft has been omitted in figure 70 but is removed in the next

DISASSEMBLY OF THE ENGINE




**Figure 69—Cylinder Block with Front End Plate Removed**

RA PD 11207


**TM 9-1750G**  
**68**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

TOOL KM - J-1472



**Figure 70—Pulling Main Bearing Caps**



**Figure 71—Removing Front Main Bearing Cap and Thrust Washers**

DISASSEMBLY OF THE ENGINE




Figure 72—Cylinder Block Showing Upper Main Bearing Shells

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

step. The front main bearing has two thrust washers on each side (fig. 71).

**(3) REMOVAL OF CRANKSHAFT.**

Lift out the crankshaft.

**(4) REMOVAL OF UPPER MAIN BEARING SHELLS.**

Screwdriver.

Using a screwdriver, push the upper main bearing shells part way around and lift them out. **NOTE:** Upper and lower main bearing shells are not marked and should be identified for reassembling in motor unless replaced with new shells. This can be done by marking shells on the back for corresponding crankshaft journal. Scratch the number on the back of the bearing with a sharp-pointed tool.

Section VI

DISASSEMBLY, INSPECTION, SERVICE, REPAIR,  
AND ASSEMBLY OF SUBASSEMBLIES

	Paragraph
General .....	69
Cylinder liners .....	70
Crankshaft inspection .....	71
Flywheel ring gear .....	72
Main bearings .....	73
Disassembly of the piston and connecting rod assembly .....	74
Pistons .....	75
Piston rings .....	76
Connecting rod inspection and service .....	77
Assembly of the piston and connecting rod assembly .....	78
Disassembly of the cylinder head .....	79
Removal of water outlet manifold .....	80
Removal of engine lifter brackets .....	81
Removal of the valves .....	82
Removal of the fuel manifolds .....	83
Removal of the valve lifter assemblies .....	84
Removal of the injector hole tubes .....	85
Inspection and removal of valve guides .....	86
Inspection and removal of the exhaust valve inserts .....	87
Inspection and cleaning of cylinder head .....	88
Installation and reaming of valve guides .....	89
Installation of exhaust valve seat inserts .....	90
Grinding valve seats .....	91
Installation of injector hole tube .....	92
Inspection and reassembly of exhaust valve and injector rocker arm assemblies .....	93
Assembly of cylinder head and related assemblies .....	94
Disassembly of the oil pump .....	95
Assembly of the oil pump assembly .....	96
Disassembly of the water outlet manifold and thermostat as- sembly .....	97
Inspection and service of thermostat assembly .....	98
Inspection and service of water drain valve .....	99
Assembly of the water outlet manifold and thermostat assembly .....	100
Disassembly of the fan shaft assembly .....	101
Inspection and service of fan shaft assembly .....	102
Assembly of the fan shaft assembly .....	103
Removal and installation of fan bushing .....	104

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

	<b>Paragraph</b>
Disassembly of the camshaft assembly . . . . .	105
Inspection of camshaft assembly . . . . .	106
Assembly of the camshaft assembly . . . . .	107
Disassembly of fan drive gear and balance weight assembly . .	108
Inspection of fan drive gear and balance weight assembly . . . .	109
Assembly of fan drive gear and balance weight assembly . . . .	110
Disassembly of the blower drive gear, hub and support . . . . .	111
Inspection and service of the blower drive gear, hub and support	112
Assembly of the blower drive gear, hub and support . . . . .	113
Disassembly of the weight and hub assembly . . . . .	114
Inspection and service of the weight and hub assembly . . . . .	115
Assembly of the weight and hub assembly . . . . .	116
Disassembly of the balancer shaft assembly . . . . .	117
Inspection of the balancer shaft assembly . . . . .	118
Assembly of the balancer shaft assembly . . . . .	119
Disassembly of the balance weight cover assembly containing the fan idler gears . . . . .	120
Inspection and service of the balance weight cover and fan idler gears . . . . .	121
Assembly of the balance weight cover and fan idler gears . . . .	122
Disassembly of the oil pressure regulator valve assembly . . . .	123
Inspection and service of the oil pressure regulator valve as- sembly . . . . .	124
Assembly of the oil pressure regulator valve assembly . . . . .	125
Removal of the oil pump driving gear from crankshaft . . . . .	126
Inspection of the oil pump driving gear . . . . .	127
Installation of the crankshaft oil pump driving gear . . . . .	128
Disassembly of the crankshaft rear cover . . . . .	129
Inspection and service of the crankshaft rear cover . . . . .	130
Assembly of the crankshaft rear cover assembly . . . . .	131
Inspection of the idler gear assembly . . . . .	132
Inspection of crankshaft gear and oil slinger . . . . .	133
Inspection and service of cylinder block . . . . .	134
Disassembly, inspection, and service of secondary fuel filter . .	135
Assembly of secondary fuel filter . . . . .	136
Disassembly of air cleaner assemblies . . . . .	137
Inspection and service of air cleaner assemblies . . . . .	138
Assembly of air cleaner assemblies . . . . .	139

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**

**69. GENERAL.**

a. In making repairs and replacements on a Diesel engine, much of the experience gained from repairing gasoline engines can be used to advantage. Therefore, this section includes brief descriptions of inspection, service and repair of components also common to gasoline engines, with more space devoted to components peculiar to Diesel engines.

b. The disassembly, inspection, service repair, and assembly of accessories and other units such as blower, injector, governor, etc., are covered separately in sections VIII to XVIII, inclusive. All other engine parts and assemblies are covered in this section.

c. The removal of components from the engine and their installation on the engine are not included in this section, since they are covered in section V, "Disassembly of the engine," and in section VII, "Assembly of the engine." This section is confined to the tear-down, inspection, service, repair, and build-up of basic engine assemblies or parts.

**70. CYLINDER LINERS.**

Liners should be replaced when worn and new pistons should be installed. The inside diameter of the liner must measure 4.2492 to 4.2507 inches. It must be limited to 0.001-inch out-of-round and 0.001-inch taper. Only standard size liners and pistons are available as new parts. Follow the procedure outlined in paragraph 55 for removal and in paragraph 158 for installation.

**71. CRANKSHAFT INSPECTION.**

a. When a crankshaft has been removed, a thorough inspection should be made before the shaft is again installed in the engine. Such a check should include the following steps:

(1) Blow out all oil passages with air.

(2) Measure main bearing and connecting rod journals. If journals have worn out-of-round, the diameter of journals should be measured at several places to find the minimum diameter. The maximum variation between the average diameter of main journals should not exceed 0.003 inch; maximum out-of-round for crankpins and main journals should not exceed 0.005 inch; maximum taper should not exceed 0.003 inch for crankpins and 0.002 inch for main journals.

b. If crankshaft journals do not show signs of scoring, overheating or abnormal wear, it will be unnecessary to remove the crankshaft. Necessary correction can be made by changing the worn half of bearing shells.

c. In operation, loose main bearings will be evidenced by a drop in oil pressure or by excessive oil leaks when oil is forced through the gallery with compressed air. The clearance between main and connecting rod bearing shells and crankshaft journals should be 0.002 to 0.004 inch



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

and should not exceed 0.008 inch. Measure bearing shells with a micrometer and check journal diameters in several of them as journals may have worn out-of-round. If the measurements show unusual clearances and shells show only wear, replace bearing shells. If crankshaft journals are excessively worn, a new crankshaft should be installed.


d. If crankshaft journals show signs of overheating or are badly scored, then crankshaft must be replaced.

**72. FLYWHEEL RING GEAR.**

The gear should be examined for broken teeth. If replacement is necessary, break off the old ring, first weakening a section of it by grinding a notch, and then tapping firmly with a hammer. When installing a new ring, observe the following rules:

a. The ring gear is shrunk onto the flywheel by uniformly heating the gear to 450 F (red heat visible in the dark) and then placing it in position on the flywheel when the flywheel is at room temperature. The ring gear is installed so that the chamfered ends of the gear teeth face the crankshaft side.

b. The ring gear should not be heated too highly as this will destroy the original strength of the metal. On the other hand, it must be heated sufficiently to expand the ring so that it will slip over the flywheel.



**Figure 73—Removing Piston Ring and Piston Pin Lock**

## DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY OF SUBASSEMBLIES

### 73. MAIN BEARINGS.

a. Main bearing caps should be examined for chipping, pitting, scoring or overheating. Checking of bearing clearance is done when the crankshaft is being installed in the engine block. See paragraph 146.

b. The thrust washers on the front main bearing should be examined for wear, and, if necessary, replaced with new ones.

### 74. DISASSEMBLY OF THE PISTON AND CONNECTING ROD ASSEMBLY (fig. 73).

a. **Equipment.** The following is a list of tools needed for the disassembly of the piston and connecting rod assembly.

Pliers, small-nosed

Spreader, ring

Screwdriver

Tool KM-J-1513

b. **Procedure.**

(1) Remove the top compression ring by spreading it with a ring spreader (fig. 73); then slide off the top of the piston. To avoid breakage, care must be taken not to overstress piston rings by spreading ends more than necessary to slip off the piston. Remove the number 2, number 3 and number 4 compression rings in the same manner.

(2) Following the same procedure, remove the upper and lower halves of each of the two bottom oil control rings, sliding them off the bottom of the piston. Then remove the ring expanders from the two bottom oil ring grooves. **NOTE:** The oil rings are made in three parts—the ring expander and the upper and lower halves of the ring.

(3) Remove one of the piston pin lock rings, using a screwdriver and small-nosed pliers (figs. 73 and 74). Remove the piston pin retainer. This may be done with a suction cup.

(4) Pull out the piston pin, tapping the piston on a wooden block if necessary.

(5) Draw out the connecting rod assembly.

(6) Remove the two nuts holding the connecting rod cap to the rod and then remove the connecting rod bearing cap, lower bearing shell, and the upper bearing shell from the connecting rod.

(7) Identify bearings if they are to be retained for future use by marking the number of the crankshaft journal on the back with a pointed tool. **NOTE:** Keep pistons, rods, and bearings for each cylinder in a set so that they can be reassembled in the same order.

### 75. PISTONS.

a. **Piston Inspection.**

(1) Since gummy deposits on piston walls and ring grooves are not

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 74—Components of Piston and Connecting Rod Assembly

## DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY OF SUBASSEMBLIES

always easily removed with SOLVENT, dry cleaning, these parts may be cleaned by using a standard cleaner and then blown off with dry compressed air, if necessary. Piston skirt, piston rings, ring grooves, and piston bushings should be thoroughly inspected after cleaning.

(2) If the tin coating is worn off in spots, a careful examination should be made for score marks or other indications of lack of proper piston clearance. **NOTE:** The upper part of the piston (above the upper compression ring) is not coated and does not touch the cylinder liner.

(3) A badly scored piston should not be used, especially if scored in thrust area.

(4) The piston head should be absolutely clean on the outside as well as on the cooling ribs on the under side. Any thick coating of carbon on parts indicates failure of cooling oil supply, and necessitates cleaning of the orifice at the lower end of the connecting rod, the spray jet at the upper end of the connecting rod, and the oil passage in the connecting rod.

### b. Fitting Pistons.

(1) Measurements of pistons and bore for pistons in cylinder liners should be taken at room temperature (70 F).

(2) Measurements should be taken on the piston skirt, both along and across the piston pin. See paragraph 313 for clearances.

(3) Cylinder bores should be measured with a gage, both along and across the bore, throughout the entire length of the cylinder liner.

(4) Clearance of the piston in the bore may be checked across pin by using 1/2-inch wide feeler ribbon between the piston and the cylinder liner. With a 0.006-inch clearance between piston and liner, a 0.005-inch feeler may be pulled quite freely.

## 76. PISTON RINGS.

### a. Ring Inspection.

(1) Rings should be inspected for free fit in grooves, side clearance, and wear. Presence of original tool marks and tin plating in grooves of compression rings indicates absence of wear.

(2) New piston rings should always be used with new pistons; furthermore, if the engine has been in service for some time, even though the same pistons are again used, it is advisable to use new rings.

### b. Fitting Rings.

(1) To fit the piston rings, first insert the ring in the bore and slide the piston into the bore on top of the ring. This will make the ring parallel to the top of the cylinder block. With the ring in this position, measure the gap between the ends of the ring with a feeler gage.

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2





Figure 75—Sectional View of Piston and Rings

RA PD 11236

## DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY OF SUBASSEMBLIES

(2) The gap of compression rings is from 0.020 to 0.025 inch and that of oil control rings from 0.010 to 0.020 inch. Gap may be widened by using a thin, flat, fine mill file.

(3) Oil rings are three-piece type, and should be placed in grooves (fig. 75) with the beveled edge of the upper piece at the top and the scraper edges of both parts pointing down. This is important to control piston lubrication properly.



**Figure 76—Installing Connecting Rod Bushing**

### 77. CONNECTING ROD INSPECTION AND SERVICE.

#### a. Equipment.

Fixture KM-J-1686

Tool KM-J-1513

Hammer

b. Procedure. On complete overhauls, connecting rod bushings should be replaced when wear exceeds 0.006 inch. Otherwise, wear up to 0.010 inch is permissible. To replace them, proceed as follows:

(1) Drive out the old bushings with a hammer and special tool KM-J-1513.

(2) Then put the new bushings in place and drive into position, using tool KM-J-1513 (fig. 76). NOTE: On some early models of the 6046 power plant, solid bushings were used in pistons and connecting


**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

rods. However, on more recent models, split bushings should be installed in the connecting rods with the joint toward the top of the connecting rod. Split piston bushings should have the joint at the bottom, directed away from the piston head. These bushings, however, are not available as separate parts, but are serviced only with the piston.

ROD, CONNECTING;  
ASSEMBLY

REAMER

FIXTURE KM-J-1686



RA PD 11247

**Figure 77—Reaming Connecting Rod Bushing**

(3) Next, put the rod and new bushings in fixture KM-J-1686 and ream out (fig. 77), using reamers from 1.5015 to 1.5020 inches in diameter, until the recommended piston pin clearance of 0.0025 to 0.0032 inch is obtained.

**c. Inspect and Check Connecting Rod Bearings Before Reinstalling.**

(1) Connecting rod bearing load is on the upper half of the shell only. Any wear, therefore, will show on the upper half of the shell. Examine for scoring, chipping, cracking or signs of overheating. The backs of bearing shells should also be inspected for any bright spots. Bright spots on the backs of shells will indicate that shells have been moving in their supports and are unfit for further use. If any of these conditions are noted, the lower half of the shell must also be changed.

(2) Connecting rod bearing shells are furnished in standard size.

## **DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY OF SUBASSEMBLIES**

If check shows that clearance between rod bearing shells and crankshaft journals is excessive, install new shells.

### **78. ASSEMBLY OF THE PISTON AND CONNECTING ROD ASSEMBLY (figs. 73, 74 and 75).**

a. Install the upper bearing shells in the connecting rod. **NOTE:** Upper bearings have two oil holes and are grooved only from the split to the holes. It is important that the proper bearing be installed; otherwise piston cooling will be affected.

b. Install the lower bearings in the connecting rod caps. **NOTE:** The lower bearings have no oil holes but have a continuous oil groove.

c. Place the connecting rod inside the piston with the numbered side of the connecting rod in line with the numbered side of the piston head.

d. Oil and install the piston pin. Install the piston pin retainer and lock ring. **NOTE:** New rings have already been fitted on the piston (par. 76 b) and the pistons fitted to the cylinder liners (par. 75 b).

### **79. DISASSEMBLY OF THE CYLINDER HEAD.**

The cylinder head, as removed from the engine according to directions in section IV, paragraph 51, includes a number of important assemblies and accessories which must be removed before the head itself can be inspected and serviced. Paragraphs 80 through 94, which follow, cover the disassembly, inspection, service, and reassembly of the cylinder head and its components.

### **80. REMOVAL OF WATER OUTLET MANIFOLD.**

#### **a. Equipment.**

Wrench, open-end,  $\frac{9}{16}$ -in.

#### **b. Procedure (fig. 78).**

(1) Using a  $\frac{9}{16}$ -inch open-end wrench, remove the 12 nuts and lock washers holding the water outlet manifold to the cylinder head.

(2) Lift off the manifold and remove the six manifold gaskets.

### **81. REMOVAL OF ENGINE LIFTER BRACKETS.**

#### **a. Equipment.**

Wrench, socket,  $\frac{5}{8}$ -in.

#### **b. Procedure (fig. 78).**

(1) Inspect the section of the gasket that is between the bracket and the flywheel housing. If it is damaged, it will be necessary to remove the bracket and replace it. Otherwise the two bolts holding each lifter to the cylinder head should be merely loosened, so that the brackets will not interfere with reinstallation of the cylinder head.

(2) Using a  $\frac{5}{8}$ -inch socket wrench, loosen or remove the bolts, and remove the brackets and the gasket.



ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2






Figure 78 — Removing Water Outlet Manifold

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



**Figure 79—Compressing Valve Spring to Release Valve Spring Seat Lock**



**Figure 80—Valve Spring Seat Assembly**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**82. REMOVAL OF THE VALVES.**

**a. Equipment.**

Board

Compressor, valve spring tool  
KM-J-1227

**b. Procedure (figs. 79 and 80).**

(1) Put a board one inch thick under the cylinder head, covering the valve heads in order to hold the valves in place when compressing the valve springs.

(2) Install one of the rocker arm support bolts through the collar and the lever parts of tool KM-J-1227 (fig. 79). The bolts serve as a fulcrum.

(3) Using the tool, depress the valve spring (fig. 79), and while holding the spring compressed, remove the two halves of the valve spring seat lock.

(4) Release the valve compressor tool, lift off the valve spring cap and the valve spring, and remove the valve spring seat pin and seat (fig. 80). Repeat the same operations for the other valves.


(5) Before turning the cylinder head on its side to remove the valves, first remove the fuel manifolds as indicated in the following paragraph.

**83. REMOVAL OF THE FUEL MANIFOLDS.**

**a. Equipment.**

Wrench, socket,  $\frac{5}{16}$ -in.

Wrench, special socket,  $\frac{5}{8}$ -in.



**Figure 81 — Removing Connector and Nut Assembly**

RA PD 11245

MANIFOLD, LOWER FUEL

MANIFOLD, UPPER FUEL





Figure 82—Removal of Upper and Lower Fuel Manifolds


**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11243

**Figure 83—Component Parts of Rocker Arm, Push Rod, and Cam Follower Assemblies**

DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES




*Figure 84—Cam Follower Guides*

RA PD 11244

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2

FOLLOWER, CAM, ASSEMBLY



**Figure 85—Cam Follower Assembly**

RA PD 11242

**b. Procedure** (figs. 81 and 82).

(1) Loosen the fuel connector lock nuts, using a  $\frac{5}{8}$ -inch special socket wrench (fig. 81).

(2) Using a  $\frac{7}{16}$ -inch socket wrench, unscrew the 12 fuel connector and nut assemblies, and remove them.

(3) Pull off the two fuel manifolds (fig. 82).

**84. REMOVAL OF THE VALVE LIFTER ASSEMBLIES.**

**a. Equipment.**

Pliers, long-nosed

Wrench, socket,  $\frac{7}{16}$ -in.


**b. Procedure** (figs. 83, 84, 85 and 86).

(1) Turn the cylinder head on its side and remove the exhaust valves (fig. 84). Place the valves in a suitable rack so that they can be replaced in the same holes if valve seat inserts are not to be replaced.

(2) Using a  $\frac{7}{16}$ -inch socket wrench, remove the two bolts and lock washers holding the cam follower guide to the cylinder head (fig. 84). Remove the guide.

(3) Pull out the cam follower assemblies (fig. 85).

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



**Figure 86—Removing Push Rod Spring Seat Retainer**

(4) Turn the cylinder head back to its former position, and using long-nosed pliers, pull out the push rod spring seat retainer that holds the upper push rod spring seat in place (fig. 86).

(5) Lift out the rocker arm and push rod assemblies.

**85. REMOVAL OF THE INJECTOR HOLE TUBES.**

**a. Equipment.**

Hammer

Tool KM-J-1891

**b. Procedure** (figs. 87 and 88). **NOTE:** It is not always necessary to remove injector hole tubes. However, if inspection reveals damage or evidence of leakage, the tubes should be removed from the cylinder head. (Removal of injectors is described in paragraph 52.)


(1) Put one half of tool KM-J-1891 in place in the injector hole tube (fig. 87) and screw it into tube two or three turns.

(2) Drive the other half of tool KM-J-1891, with a hammer, up through the bottom of the injector hole and against the mating half, thus driving the tube out of the cylinder head (fig. 88).

(3) For installation of new tubes, see paragraph 92.



ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




TOOL KM-J-1891

TUBE, INJECTOR HOLE

RA PD 11226

**Figure 87—Injector Hole Tube Removal Tool in Place**




TOOL KM-J-1891

RA PD 11227

**Figure 88—Removing Injector Hole Tube**

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



RA PD 11229

**Figure 89—Removing Valve Guide**

**86. INSPECTION AND REMOVAL OF VALVE GUIDES.**

**a. Equipment.**

Hammer

Tool KM-J-1233

**b. Procedure (fig. 90).**

- (1) Using valve guide cleaning tool, remove carbon from all valve guides.
- (2) Inspect guides. Those showing wear or out-of-round should be replaced when clearance exceeds 0.003 inch.
- (3) Using special tool KM-J-1233, drive out each worn guide (fig. 89).
- (4) For installation and reaming of new guides, see paragraph 89.

**87. INSPECTION AND REMOVAL OF THE EXHAUST VALVE  
INSERTS.**


**a. Equipment.**

Tool KM-J-1641-A

**b. Procedure (fig. 90).**

- (1) Inspect exhaust valve inserts. Any which show excessive pitting, warping, or wear should be replaced, as indicated by the following steps:
  - (a) Place tool KM-J-1641-A over one of the exhaust valve inserts and lower the jaws so that they are just under the insert.

**POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2  
ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71**



**Figure 90—Removing Exhaust Valve Insert**

(b) Expand the jaws under the insert as far as possible by turning the center nut while holding the collet from turning.

(c) After tightening the center nut, turn the handles until the insert is forced out of the cylinder head. Repeat operations on any remaining inserts needing replacement.

(2) To install new inserts, see paragraph 90.

**88. INSPECTION AND CLEANING OF CYLINDER HEAD.**

**a. Equipment.**

Air, compressed

Wrench, square-plug socket,  $\frac{3}{8}$ -in.

Tank, cleaning

**b. Procedure.**

(1) Remove the plugs from each end of the oil passage cylinder head.


(2) Wash the cylinder head thoroughly, flushing out all passages.

(3) Clean out the passages with compressed air.

(4) Replace the plugs.

(5) Inspect the cylinder head for cracks between the injector hole tubes and the exhaust valve inserts.

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



RA PD 11231

**Figure 91 – Installing Valve Guide**

(6) Inspect the water passages for evidence of scale. Scale may cause overheating, and should be removed.

(7) Examine the water outlet plug fuse for evidence of overheating which would cause the center of the plug to melt. Replace the plug if necessary. This plug is located on the side of the cylinder head just below the second water passage leading to the water manifold.

**89. INSTALLATION AND REAMING OF VALVE GUIDES.**

**a. Equipment.**

Hammer

Tool KM-J-129-2

Tool KM-J-1233


Tool KM-341

**b. Procedure (figs. 91 and 92).**

(1) Install the valve guide into the cylinder head from the bottom, being sure that the chamfered end is up, to provide an oil reservoir for the valve stem. Drive guide into place with tool KM-J-1233, installing the special spacer provided on the tool, in order to position the guide accurately (fig. 91).

(2) Install and drive in all remaining guides to be replaced, following the same procedure.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



**Figure 92—Reaming Valve Guides**

(3) Ream new valve guides to size, using roughing reamer tool KM-.341.

(4) Smooth inside diameter of guides, using finish reamer KM-J-129-2 (fig. 92).

**90. INSTALLATION OF EXHAUST VALVE SEAT INSERTS.**

**a. Equipment.**

Air, compressed


Tool, KM-J-1641-A

**b. Procedure** (fig. 93). **NOTE:** Particular care must be exercised when installing exhaust valve seat inserts, since they must be started in place true in the counterbore in the cylinder head, and must seat perfectly against the bottom and sides of the bore when completely installed.

(1) Using compressed air, remove all traces of dirt or dust from the cylinder head and particularly from the counterbores for the inserts.

(2) If facilities are available, the cylinder head should be immersed in water of approximately 200 F for 30 minutes. Then the head should be removed and the valve inserts installed while it is still hot. It may be necessary to cool the inserts in dry ice to facilitate installation.

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



RA PD 11239

**Figure 93—Installing Exhaust Valve Insert**

(3) Install the insert in the counterbore, valve or tapered side up. Inspect its position carefully to be sure that it is true.

(4) Insert the pilot end of the driver tool, which is part of set KM-J-1641-A, into the valve guide, and drive the insert down tight into the counterbore (fig. 93).

(5) Grind valve seats as directed in the following paragraph.

**91. GRINDING VALVE SEATS.**

**a. Equipment.**

Gage, testing

Tool, lapping

Tool, grinding

**b. Procedure.**

(1) In reconditioning valve seats, insert the valve grinding tool over the valve seat to be ground. Grind the seats to a smooth, even finish. Care should be taken not to grind more than is necessary to seat the valves properly. Standard width for valve seats is  $\frac{3}{4}$ -inch with an angle of 45 degrees. When sparks appear on the full circumference of the valve seat insert, the seat should be inspected for proper width.

(2) A testing gage should be used to check the concentricity of valve seats after the grinding operation has been completed. Variations should not exceed 0.001 inch.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

(3) After grinding and testing the seats, valves should be put in place and lapped to perfect seats with a lapping tool. After lapping, contact between seats and valves may be checked by wiping a thin film of Prussian blue on the valve. Rotate valve in seat and inspect seat for even presence of Prussian blue.

**92. INSTALLATION OF INJECTOR HOLE TUBE.****a. Equipment.**

Compound, cutting

Tool KM-J-1231-A

Hammer

Vise

Tool KM-J-1229

b. Procedure (figs. 94 and 95). To install an injector hole tube in the cylinder head, proceed as follows:

(1) Insert the rubber seal ring into the counterbore or countersunk part of the cylinder head at the opening for the injector hole tube and insert the injector hole tube through the ring and into position in the cylinder head. The flange at the upper end of the tube will seat on the rubber ring and into the counterbore when the tube is in position.

(2) Holding the cylinder head right side up, insert tool KM-J-1229 into the tube, and drive the tube into position (fig. 94, operation 1).

(3) Support the driving tool in the jaws of a vise, with the small end up. Then lay the cylinder head over the tool, slide the flaring tool KM-J-1229 down over the small end of the driver tool, and flare the lower end of the tube into the cylinder head (fig. 94, operation 2). After flaring, again strike the driving tool with a hammer and repeat the flaring operation. This will seat the tube properly. The first flaring may drive the tube back slightly and allow end play between the tube and the cylinder head, unless the operation is repeated.


(4) The injector tube must be reamed after installation to receive the injector body nut and spray tip and for good seating of the bevel on the lower end of the injector nut. The first operation is performed by inserting tool KM-J-1231-A (fig. 95, operation 1), thus reaming the lower end to the proper size for the injector spray tip and the upper end to the proper size for the injector nut.

(5) The second reaming operation is accomplished by installing tool KM-J-1231-A (fig. 95, operation 2). Set the tool fixture on the cylinder head with the hole in the tool body over the rocker shaft bracket hole and the feed screw directly overhanging the center of the reamer. Tighten only the feed screw finger. Use a cutting compound made of half kerosene and half oil, and ream the seat. Check the depth of the


**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**

TOOL KM - J-1229

OPERATION 1



OPERATION 2



RA PD 11488

**Figure 94—Installing Injector Hole Tube (Operations 1 and 2)**



ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 95—Reaming Injector Hole Tube (Operations 1 and 2)

## DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY OF SUBASSEMBLIES

cut by installing an injector assembly from time to time until the shoulder of the spray tip is flush with the bottom of the head. Use a straightedge to determine flushness. NOTE: Installation of injectors is outlined in paragraph 161.

### 93. INSPECTION AND REASSEMBLY OF EXHAUST VALVE AND INJECTOR ROCKER ARM ASSEMBLIES (fig. 83).

The procedure for the inspection and reassembly of the valve and injector operating mechanism assemblies is as follows:

- a. Inspect rocker arm shafts for wear and smoothness.
- b. Clean out oil holes.
- c. Inspect the exhaust valve arm assemblies, checking bushings and radius at the valve contact for wear and smoothness.
- d. Inspect injector arm assemblies, bushings, and ball and seal assemblies for wear and smoothness.
- e. Inspect surfaces of push rod bottom seats for smoothness and wear.
- f. Inspect springs and check free length. Free length should be  $2\frac{3}{4}$  inches. NOTE: If it is necessary to replace a spring, loosen the lock nut just below the clevis on the rocker arm, remove the push rod, and slide the upper seat and spring off the rod.
- g. Oil the rocker shafts and install the rocker arms. Each shaft takes an exhaust valve rocker arm assembly, one injector rocker arm assembly and one exhaust valve rocker arm assembly.
- h. Install brackets on each end of the rocker shafts.
- i. Clean the oil holes in the bolts and install the bolts in the brackets and shafts.
- j. After cleaning the cam followers, inspect all parts for wear, scuff marks, or scoring. See that the cam rollers rotate smoothly and freely on their bearings. If cam rollers, bearings or pins are loose, or if there is more than 0.005-inch radial movement of the roller, install a new follower assembly.

### 94. ASSEMBLY OF CYLINDER HEAD AND RELATED ASSEMBLIES.

#### a. Equipment.

Air, compressed	Wrench, deep socket, $\frac{7}{16}$ -in.
Board, 1-in.	Wrench, deep socket, $\frac{5}{8}$ -in.
Tool KM-J-1227	Wrench, open-end, $\frac{9}{16}$ -in.

#### b. Procedure (figs. 79, 80 and 86).

(1) With the cylinder head on its side, install the 12 exhaust valves. NOTE: Put a few drops of oil in each valve guide or on the stem of each valve before installing.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

- (2) Place a 1-inch board across the valve heads and turn the cylinder head right side up.
- (3) Install the exhaust valve spring seat so that the pin pilots in the hole in the cylinder block (fig. 80).
- (4) Install the exhaust valve springs, turning the spring so that the end of the coil is against the pin on the valve spring seat. Install the caps. The caps are notched to rest against the end of the upper coil of the spring.
- (5) With tool KM-J-1227, depress the spring caps and exhaust valve springs, and install the spring exhaust valve locks (fig. 79).
- (6) With rocker arm and push rod assemblies inspected, lubricated, and reassembled as in paragraph 104, install the assemblies into the cylinder head.
- (7) Install the push rod spring retainer (fig. 86).
- (8) Insert the bolts approximately three turns into the cylinder head to hold the rocker arm shaft brackets.
- (9) Blow out the upper and lower fuel manifolds with compressed air, and install the manifolds in the cylinder head.
- (10) Install a washer on each fuel connector and nut assembly, and install the connector and nut assemblies into the cylinder head. Tighten the connector using a  $\frac{7}{16}$ -inch deep socket wrench and lock nut with a  $\frac{5}{8}$ -inch deep socket wrench (fig. 81).
- (11) Turn the cylinder head on side and oil and install the cam followers with the oil holes next to the side of the cylinder head (fig. 85).
- (12) Using a  $\frac{7}{16}$ -inch socket wrench, install the six follower assembly guides (fig. 84).
- (13) Turn the cylinder head upright and shellac six new water manifold gaskets into place.
- (14) Install the water outlet manifold on the cylinder head, and using a  $\frac{9}{16}$ -inch open-end wrench, install and tighten the 12 nuts and lock washers holding the manifold to the cylinder head.
- (15) If lifter brackets were removed, shellac a new gasket into place and, using a  $\frac{5}{8}$ -inch socket wrench, install the lifter bracket on the cylinder head.

**95. DISASSEMBLY OF THE OIL PUMP.****a. Equipment.**

Cutters, side  
Hammer  
Hammer, soft  
Press, arbor  
Screwdriver  
Tool KM-J-1931

Tool KM-J-1935  
Tool, puller  
Wrench, open-end,  $\frac{3}{4}$ -in.  
Wrench, socket,  $\frac{7}{16}$ -in.  
Wrench, socket,  $\frac{1}{2}$ -in.  
Wrench, socket,  $1\frac{1}{4}$ -in.

## DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY OF SUBASSEMBLIES

### b. Procedure (figs. 96, 97 and 98).

(1) Using a 1/2-inch socket wrench, remove the two bolts (34, fig. 96) and lock washers holding the scavenging pump inlet screen (33) to the rear scavenging pump body (17). Remove the screen.

(2) Remove the other scavenging pump inlet screen (1) by removing the two bolts (2), lock washers and flat washers, using a 1/8-inch socket wrench.

(3) Using a 1/2-inch socket wrench, remove the two bolts (35) and lock washers holding the pressure pump outlet pipe (36) to the pressure pump body (22). Remove the pipe. Remove the gasket.

(4) Using a 1/2-inch socket wrench, remove the four bolts (6) and lock washers holding the scavenging pump outlet elbow (7) to the pump bodies (9) and (17). Remove the elbow (7). Remove the gasket (8).

(5) Using a 1/2-inch socket wrench, remove the two bolts (25) and lock washers holding the pressure pump inlet elbow (24) to the pump body (22). Remove the inlet. Remove the gasket (23).

(6) Using a 1/2-inch socket wrench, remove the two bolts (11) and lock washers holding the scavenging pump inlet pipe (4) to body (9).

(7) Using a 1/2-inch socket wrench, remove the four through bolts (5) and lock washers from the front scavenging pump body (9).

(8) Tap off the front scavenging pump body (9), using a soft hammer, and remove the oil pump driven gear (13) from the front scavenging body.

(9) Using a 1/2-inch socket wrench, remove the two bolts (43) and lock washers holding the pressure pump pad cover (42) to the pump body (22). Remove the cover, then the gasket (41).

(10) Using a 1 1/4-inch socket wrench, remove the two valve plugs (26 and 38) and copper asbestos gaskets (27 and 39) from the pressure pump.

(11) Remove the valve spring (pressure pump) (28). Push out the valve (29).

(12) Pull off the oil pump driven gear (32) that is mounted on the oil pump drive shaft (31), using tool KM-J-1931 and a 3/4-inch open-end wrench (figs. 96 and 97).

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 96—Component and Related Parts of Oil Pump Assembly

DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES


COMPONENT AND RELATED PARTS OF OIL PUMP ASSEMBLY

Number	Item	Number	Item
1	Screen, Scavenging Pump Inlet	23	Gasket, Pressure Pump Inlet Elbow
2	Bolt, Scavenging Pump Inlet Screen	24	Elbow, Pressure Pump Inlet
3	Clip, Scavenging Pump Inlet Pipe	25	Bolt, Pressure Pump Inlet Elbow
4	Pipe, Scavenging Pump Inlet	26	Plug, Pressure Pump Valve
5	Bolt, Pump Bodies	27	Gasket, Copper Asbestos, Pressure Pump Valve Plug
6	Bolt, Scavenging Pump Outlet Elbow	28	Spring, Valve, Pressure Pump
7	Elbow, Scavenging Pump Outlet	29	Valve, Pressure Pump
8	Gasket, Scavenging Pump Outlet	30	Key, Woodruff
9	Body, Front Scavenging Pump	31	Shaft, Oil Pump Drive
10	Pin, Dowel	32	Gear, Oil Pump Driven (Mounted on Oil Pump Drive Shaft)
11	Bolt, Scavenging Pump Inlet Pipe (To Pump)	33	Screen, Scavenging Pump Inlet
12	Gear, Oil Pump Drive	34	Bolt, Scavenging Pump Inlet Screen
13	Gear, Oil Pump Driven—Assembly	35	Bolt, Pressure Pump Outlet Pipe (To Pump)
14	Spacer (Between Front and Rear Scavenging Bodies)	36	Pipe, Pressure Pump Outlet (Model LA24M Engine)
15	Gear, Oil Pump Drive	37	Bolt, Pressure Pump Outlet Pipe (To Block)
16	Gear, Oil Pump Driven—Assembly	38	Plug, Pressure Pump Valve
17	Body, Rear Scavenging Pump	39	Gasket, Copper Asbestos, Pressure Pump Valve Plug
18	Pin, Dowel	40	Gasket, Pressure Pump Outlet Pipe (To Block)
19	Shaft, Oil Pump Driven	41	Gasket, Pressure Pump Pad Cover
20	Gear, Oil Pump Drive	42	Cover, Pressure Pump Pad
21	Gear, Oil Pump Driven—Assembly	43	Bolt, Pressure Pump Pad Cover
22	Body, Pressure Pump		

RA PD 11283A

Nomenclature for Figure 96—Component and Related Parts of Oil Pump Assembly

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11250

**Figure 97—Removing Oil Pump Driven Gear**

(13) Using side cutters, pull out the Woodruff key (30) under the oil pump driven gear (32).

(14) Pry off the oil pump drive gear (12) (front scavenging body) with a screwdriver.

(15) Pull out the two Woodruff keys (30) from the oil pump drive shaft (31), using side cutters.

(16) Pull off the spacer (14).


(17) Remove the oil pump driven gear (16) from the driven shaft (19). Pry off the oil pump drive gear (15) (rear scavenging body) and remove the next two Woodruff keys (30) from the drive shaft (31).

(18) With a hammer, tap the oil pump drive shaft end to force the the rear scavenging pump body (17) away from the pressure pump body (22).

(19) Pull off the oil pump driven gear (21) (pressure pump body).

(20) Press off the oil pump drive gear (20) (pressure pump body), using tool KM-J-1919 and a 1½-inch socket wrench (fig. 98).

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



RA PD 11249

**Figure 98—Removing Oil Pump Drive Gear**



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

(21) The driven shaft is pressed into the pressure pump body and can be inspected without removal.

(22) Inspect and service oil pump assembly as follows:

(a) Wash all parts in SOLVENT, dry cleaning.

(b) Examine the teeth of the oil pump drive and driven gears. If gear teeth are scored or excessively worn, the gear or gears should be replaced with new ones. If the oil pump driven gear (32) is replaced, the oil pump idler gear, mounted on the crankshaft front cover, and the oil pump driving gear, mounted on the crankshaft, must be replaced. See paragraphs 126, 129 and 131 for replacement of these gears. NOTE: Each oil pump driven gear is listed as an assembly and includes a bushing. Oil pump drive gears do not include a bushing.

(c) If the oil pump driven shaft shows wear, it should be pressed out (arbor press) and replaced with a new shaft.

(d) If the pressure pump body or cover is scored or damaged in any way, it should be replaced with new parts.

(e) For efficient oil pump pressure, driven gears should have a free running fit but with no perceptible looseness on the shaft. Drive gears have a pressed fit.

(f) Inspect the relief valve assembly for wear, and replace defective parts.

(g) All other parts—elbows, pipes, screens and bolts—should be examined for cracks, chips and other wear. Defective parts should be replaced with new ones. NOTE: The parts receiving the most wear are the gears. If the oil has been kept clean, wear of these parts will be very slow. However, if dirt and sludge have accumulated in the lubricating system, oil pump gear wear may become rather pronounced in a comparatively short time. Badly worn pump parts will result in low engine oil pressure. The oil pump, as well as other wearing parts of the engine, should be protected against abuse by careful use of lubricating oils.

**96. ASSEMBLY OF THE OIL PUMP ASSEMBLY.****a. Equipment.**

Gage, feeler, 0.005-in.

Hammer, soft

Tool, KM-J-1903

Tool KM-J-1919

Wrench, socket,  $\frac{7}{16}$ -in.


Wrench, socket,  $\frac{1}{2}$ -in.

Wrench, socket,  $1\frac{1}{4}$ -in.

**b. Procedure (figs. 96 and 99).**

(1) Install the one Woodruff key nearest to the center of the oil pump drive shaft and press the oil pump drive gear on the oil pump drive shaft over the key using tool KM-J-1919 (fig. 99) to space gear properly from the drive end of the shaft.

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



RA PD 11240

**Figure 99—Installing Oil Pump Drive Gear On Oil Pump Drive Shaft**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

(2) Place the oil pump driven gear (21, fig. 96) on the oil pump driven shaft (19) and slip into the pressure pump body (22).

(3) Slip the oil pump drive shaft (31) and gear (20) into the pressure pump body (22) so that the drive and driven gears mesh.

(4) Install the rear scavenging pump body (17) on the oil pump drive shaft (31) and driven shaft (19) over the dowel pins (18).

(5) Install the next two Woodruff keys (30) on the oil pump drive shaft (31) inside the rear scavenging pump body (17).

(6) Press the oil pump drive gear (15) (rear scavenging body) on the drive shaft (31) inside the rear scavenging pump body (17) over the keys.

(7) Push the oil pump driven gear (16) (rear scavenging pump body) onto the driven shaft (19) and into the rear scavenging pump body (17) to mesh with the drive gear (15).

(8) Put on the oil pump spacer (14).

(9) Install the next two Woodruff keys on the drive shaft (31). Install the oil pump drive gear (12) (front scavenging pump body). Install the oil pump driven gear (13) (front scavenging pump body) on the driven shaft (19) so that it meshes with the drive gear.

(10) Install the front scavenging pump body (9), using a ½-inch socket wrench to install the four through bolts (5) and lock washers which hold the front scavenging pump body (9), the rear scavenging pump body (17), and the pressure pump body (22) together.


(11) Install a Woodruff key at the drive end of the oil pump drive shaft (31) and press on the oil pump driven gear (32), using a soft hammer and tool KM-J-1903. See figure 100 for the proper installation procedure. The oil pump drive shaft (31) should be supported opposite the drive end while pressing on the oil pump driven gear. Press the gear on the shaft, using a 0.005-inch feeler gage between the pump body and the gear for end clearance. Rotate the drive shaft to see that all gears turn freely.

(12) Install the valve (29) (pressure pump) in the pressure pump body (22) on the inlet side. Install the valve spring (28) (pressure pump) into the recess in the valve (29) (pressure pump). Using a 1¼-inch socket wrench, install the two valve plugs (26 and 38) (pressure pump) and copper asbestos gaskets (27 and 39).

(13) Install a new pressure pump pad cover gasket with the cover (41) on the pressure pump body, using a ½-inch socket wrench to tighten the two bolts (43) and lock washers holding the cover to the pump body.

(14) Install the pressure pump inlet elbow gasket (new) (23) and elbow (24) on the pressure pump body (22), using a ½-inch socket

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



RA PD 11251

**Figure 100—Installing Oil Pump Driven Gear**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

wrench to tighten the two bolts (25) and lock washers holding the elbow (24) to the body (22).

(15) Install the scavenging pump elbow gasket (new) and elbow (7) on the front and rear scavenging pump bodies (9 and 17), using a 1/2-inch socket wrench to tighten the four bolts (6) and lock washers holding the elbow to the bodies.

(16) Install the pressure pump outlet pipe (36) and new gasket on the pressure pump body, using a 1/2-inch socket wrench to tighten the two bolts (35) and lock washers (35) holding the pipe to the body.

(17) Install the scavenging pump inlet pipe (4) and new gasket to the front scavenging body (9), using a 1/2-inch socket wrench to tighten the two bolts (11) and lock washers holding the pipe to the body.

(18) Install the scavenging pump inlet screen (1), using a 7/8-inch socket wrench to tighten the two bolts (2), lock washers and flat washers.

(19) Install the scavenging pump inlet screen (33) to the rear scavenging pump body (17), using a 1/2-inch socket wrench to tighten the two bolts (34) and lock washers holding the screen to the body.

**97. DISASSEMBLY OF THE WATER OUTLET MANIFOLD AND  
THERMOSTAT ASSEMBLY.**

**a. Equipment.**

Wrench, open-end, 9/16-in.

Wrench, socket, 9/16-in.

Wrench, open-end, 5/8-in.

**b. Procedure (fig. 101).**

(1) Using a 9/16-inch socket wrench, remove the four bolts and lock washers holding the thermostat housing to the water outlet manifold. Remove the housing.

(2) Remove the thermostat seals and the housing gasket from the housing.

(3) Remove the thermostats from the manifold.

(4) Using a 9/16-inch open-end wrench, remove the bolts and washers holding the thermostat housing cover to the housing. Remove the cover and the gasket.


(5) Using a 5/8-inch open-end wrench, remove the drain valve and handle, and inspect the valve and seat.

**98. INSPECTION AND SERVICE OF THERMOSTAT ASSEMBLY.**

Inspect and service thermostat assembly as follows:

a. Examine thermostat seals for evidence of leakage, replacing seals if necessary.

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



RA PD 11252

**Figure 101—Component and Related Parts of Water Outlet  
Manifold and Thermostat Assembly**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

b. Immerse thermostats in hot water and check to see whether valves open properly. Thermostat should start to open at 158 F and should be fully open at 185 F. Check with thermometer in hot water.

c. Examine water outlet manifold thoroughly for cracks or other damage.

**99. INSPECTION AND SERVICE OF WATER DRAIN VALVE.**

Valve, nipples, and elbow should be cleaned of all dirt, washed, and blown out with compressed air. To do this, the lower nipple and the elbow should be removed from the valve, and the nipple at the oil cooler should be removed from the oil cooler and the elbow. When reassembling, the packing gland nut holding the rod to the valve should be repacked.

**100. ASSEMBLY OF THE WATER OUTLET MANIFOLD AND  
THERMOSTAT ASSEMBLY.**

**a. Equipment.**

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

**b. Procedure (fig. 101).**

(1) Install the thermostats in the water outlet manifold with the stamped ribs of the thermostats along the manifold.

(2) Install the thermostat seals inside the thermostat housing.

(3) Install a new gasket between the housing and the manifold.

(4) Screw in the four bolts and lock washers holding the housing to the manifold, using a  $\frac{9}{16}$ -inch socket wrench to tighten the bolts.

(5) Install the thermostat housing cover and new gasket, using a  $\frac{9}{16}$ -inch open-end wrench to tighten the bolts and washers holding the cover to the housing.

(6) Using a  $\frac{5}{8}$ -inch open-end wrench, install the thermostat housing drain valve into the housing.

**101. DISASSEMBLY OF THE FAN SHAFT ASSEMBLY.**

**a. Equipment.**

Hammer, soft

Tool KM-J-1919

Press, arbor

Vise

Puller, clear

Wrench, open-end,  $\frac{1}{2}$ -in.

Screwdriver


Wrench, open-end,  $\frac{3}{4}$ -in.

Tool KM-J-943-A

**b. Procedure (figs. 102, 103 and 104).**

(1) Using a  $\frac{3}{4}$ -inch open-end wrench, remove the bolt from the end of the fan shaft. Remove the lock washer and flat washer.

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**




RA PD 11452

**Figure 102—Removing Fan Shaft Bearing, Spacer and Gear**



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11454

**Figure 103—Removing Oil Seal from Retainer**

(2) Using tool KM-J-1919 in the vise (fig. 102) remove the gear, short spacer, and bearing from the fan shaft.

(3) Remove the Woodruff key and the long spacer.

(4) Turn the fan shaft upside down in the vise and remove the fan bearing and oil seal retainer and the fan drive plate and hub assembly, using tool KM-J-1919.

(5) Pull out the fan bearing oil seal from the retainer with the seal puller tool KM-J-943-A (fig. 103).

(6) Pry out the fan bearing and oil seal lock ring with a screwdriver.


(7) Knock out the fan shaft front bearing, using a soft hammer.

## **102. INSPECTION AND SERVICE OF FAN SHAFT ASSEMBLY.**

Inspection and service of fan shaft assembly should be made as follows:

- a. Inspect the fan shaft gear teeth for wear.
- b. Wash out bearings and inspect for smoothness and wear.
- c. Inspect fan shaft at oil seal for smoothness.
- d. Inspect fan hub rubber mounting for wear or failures.

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR AND ASSEMBLY  
OF SUBASSEMBLIES.**



**Figure 104—Removing Fan Bearing and Oil Seal Lock Ring**

RA PD-13800

**ORDNANCE MAINTENANCE-GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2****103. ASSEMBLY OF THE FAN SHAFT ASSEMBLY.****a. Equipment.**

Press, arbor

Vise

Tool KM-J-1912

Wrench, open-end, 1/2-in.

Tool KM-J-1919

Wrench, open-end, 3/4-in.

**b. Procedure (figs. 102, 103 and 104).**

(1) Insert the bearing into the bore of the retainer and install lock ring. Using tool KM-J-1912, drive the oil seal into the bearing retainer flush with the end of the retainer. The oil seal must be placed so that the leather faces the bearing.

(2) With the arbor press or tool KM-J-1919, install the fan drive plate and hub assembly, and the fan bearing and oil seal retainer on the fan shaft.

(3) Install the long spacer and Woodruff key and press on the gear.

(4) Install the short spacer and bearing.

(5) Install the flat washer, lock washer and bolt while holding the gear clamped in a vise. Tighten the bolt with a 3/4-inch open-end wrench.

**104. REMOVAL AND INSTALLATION OF FAN BUSHING.****a. Equipment.**

Hammer, soft

Puller, bushing (or driving  
tool)

Tool, burnishing

**b. Procedure.**

(1) To remove bushings, use a bushing puller anchored on the fan hub or drive out with a driving tool and soft hammer.

(2) To install bushings, place the fan hub on a bench and drive in until they are seated flush with the outside of the fan hub.

(3) After installation, new bushings very often must be burnished to permit rotation of the fan without binding. Use a standard burnishing tool, testing the work frequently until the fan hub rotates freely on the shaft.

**105. DISASSEMBLY OF THE CAMSHAFT ASSEMBLY.****a. Equipment.**

Screwdriver

Wrench, socket, 1/2-in.


Tool KM-J-1902

Wrench, socket, 1 1/2-in.

**b. Procedure (figs. 105 and 106).** NOTE: The camshaft has already been removed from the engine and the rear end bearing has been removed.

(1) Using a screwdriver, pry off the two lock rings holding each intermediate camshaft bearing in place.

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



RA PD 11220

**Figure 105—Removing Camshaft Gear**

- (2) Remove the bearings.
- (3) Remove the special nut that locks on the camshaft gear (fig. 106).
- (4) Using a  $\frac{1}{2}$ -inch socket wrench, install the special gear puller KM-J-1902 by screwing the gear puller to the gear with the four bolts which screw into the four holes on the bosses on the front of the camshaft gear (fig. 105).

(5) Pull off the gear by turning the center screw with a  $1\frac{1}{2}$ -inch socket wrench. Use a screwdriver to keep the tool from turning. Remove the puller tool from the camshaft gear by unscrewing the four hold-on bolts with a  $\frac{1}{2}$ -inch socket wrench.


(6) Remove the grooved end bearing (thrust) from the camshaft.  
**NOTE:** On the LA engine the camshaft thrust bearing (grooved) is on the front end (gear end) of the shaft, while on the LC engine the thrust bearing is on the rear end of the shaft since camshafts are turned end for end for correct timing.

**106. INSPECTION OF CAMSHAFT ASSEMBLY.**

Inspect camshaft and plug assembly as follows:

- a. After all parts have been cleaned with SOLVENT, dry cleaning,

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



RA PD 11219

Figure 106—Components of Camshaft Assembly and Related Parts

## DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY OF SUBASSEMBLIES

and dried by air, inspect all bearings and journals for good bearing surfaces and wear. Also inspect Woodruff keys before replacing parts.

h. Radial clearance on camshaft and bearings is from 0.0015 to 0.003 inch. Radial clearance on camshaft intermediate bearings is from 0.0025 to 0.0040 inch. End clearance for the thrust bearing is from 0.008 to 0.012 inch.

c. If any bearings show scoring or are worn so that clearances exceed 0.002 inch, install new bearings. Only standard bearings are available.

d. Examine cam surfaces for wear or scoring. A shaft with scored cams should be replaced.

e. Oil is fed through hollow camshaft to its intermediate bearings; therefore, all oil holes should be examined in both shaft and bearings. Sludge accumulations, which might restrict oil flow, should be removed.

f. Inspect camshaft gear teeth for wear, and thrust bearing face for smoothness.

### 107. ASSEMBLY OF THE CAMSHAFT ASSEMBLY.

#### a. Equipment.

Tool KM-J-1903

Wrench, socket, 1½-in.

#### b. Procedure (figs. 106 and 107).

(1) Oil and install the grooved end bearing, being sure that the grooved (thrust) bearing is on the front (gear end) of the camshaft on the LA engine, and on the rear end of the camshaft on the LC engine. The thrust bearing is slightly longer than the plain bearing.

(2) Oil and install the intermediate camshaft bearings.

(3) Using a screwdriver, install the two lock rings, locking each intermediate camshaft bearing in place.

(4) Install the camshaft gear, making sure beforehand that the Woodruff key is properly installed in the camshaft. Drive the camshaft gear on with tool KM-J-1903 (fig. 107).

(5) Using a 1½-inch socket wrench, install the special nut that holds on the camshaft gear. The nut is the self-locking type.

### 108. DISASSEMBLY OF FAN DRIVE GEAR AND BALANCE WEIGHT ASSEMBLY.


#### a. Equipment.

Wrench, socket,  $\frac{9}{16}$ -in.

b. Procedure (figs. 62 and 108). NOTE: In figure 108 the fan drive gear and balance weight assembly is completely disassembled, and the self-locking nut which holds the assembly to the fan shaft does not appear.

(1) Using a  $\frac{9}{16}$ -inch socket wrench, remove the three bolts and lock

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



**Figure 107—Installing Camshaft Gear On Camshaft and Plug Assembly**

DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES




Figure 108—Component and Related Parts of Fan Drive Gear and Balance Weight Assembly

RA PD 11284



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

washers, the fan drive gear spring retainers, and the fan drive gear spring holding the fan drive gear to the balance weight.

(2) Remove the balance weight.

(3) Drive out the three fan drive spring spacers holding the spring packs in place and remove the spring packs and fan drive gear spring seats.

**109. INSPECTION OF FAN DRIVE GEAR AND BALANCE  
WEIGHT ASSEMBLY.**

a. Inspect the fan drive gear springs, spring seats, and spring spacer for wear.

b. Inspect the gear teeth and balance weight bushing.

c. Inspect the balance weight hub for smoothness.

d. Replace all worn or otherwise faulty parts.

**110. ASSEMBLY OF FAN DRIVE GEAR AND BALANCE  
WEIGHT ASSEMBLY.**

a. Equipment.

Gage, feeler, 0.005-in.

Wrench, socket,  $\frac{9}{16}$ -in.

b. Procedure (fig. 108).

(1) Install the balance weight, being sure that the bushing is free on the balance weight hub. Oil all working parts.

(2) Install the three pairs of spring packs, the spring seats and the three spacers.

(3) Using a  $\frac{9}{16}$ -inch socket wrench, install the three bolts, lock washers and retainers, and attach the fan drive gear to the balance weight. NOTE: When assembling the fan drive gear and balance weight assembly, use a 0.005-inch feeler gage to check clearance between the weight and the gear.

**111. DISASSEMBLY OF THE BLOWER DRIVE GEAR, HUB  
AND SUPPORT.**

a. Equipment.

Hammer

Vise

Hammer, soft

Wrench, socket,  $\frac{1}{2}$ -in.


Screwdriver

Wrench, socket,  $1\frac{7}{8}$ -in.

b. Procedure (figs. 109 and 110).

(1) Set the assembly in a vise with soft copper jaw liners with the gear end down.

DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES



1. NUT, SPECIAL

2. WASHER, LOCK, EXTERNAL TOOTH

3. WASHER, THRUST

4. PACKING, BLOWER DRIVE COVER

5. ELBOW

6. SUPPORT, BLOWER DRIVE GEAR; ASSEMBLY

7. GASKET, BLOWER DRIVE GEAR SUPPORT

8. HUB, BLOWER DRIVE GEAR

9. BALL, LOCK
10. GEAR, BLOWER DRIVE — L.H. HELIX (ILLUS.)

11. GEAR, BLOWER DRIVE — R.H. HELIX

12. SUPPORT, BLOWER DRIVE COUPLING

13. SEAT, BLOWER DRIVE COUPLING SPRING

14. SPRING, BLOWER DRIVE COUPLING

15. CAM, BLOWER DRIVE COUPLING

16. RETAINER, BLOWER DRIVE COUPLING

17. WASHER, LOCK

18. BOLT

RA PD 11256

Figure 109—Component Parts of Blower Drive Gear, Hub and Support


**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

(2) Turn down the fingers on the external tooth lock washer (2) with a screwdriver and hammer.

(3) With a 1 $\frac{7}{8}$ -inch socket wrench, loosen and remove the special nut (1). Remove the lock washer (2), the thrust washer (3), and the blower drive gear hub ball (9) (figs. 109 and 110).

(4) Remove the blower drive gear support assembly (6). Remove the blower drive gear support gasket (7) from the back of the support if necessary.

(5) Loosen the vise and turn the blower drive gear support assembly (7) over, with the blower drive coupling support (11) on top.



RA PD 11258

**Figure 110—Blower Drive Gear Support Assembly with Washer, Thrust Washer, Special Lock and Nut Removed**

(6) Using a  $\frac{1}{2}$ -inch socket wrench, remove the six bolts (17) and lock washers holding the assembly together.

(7) Remove the blower drive coupling retainer (15), and the blower drive coupling support (11).

(8) Remove the blower drive gear (10) from the blower drive gear hub (8), forcing the gear off with a soft hammer if necessary.

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**


(9) Push the blower drive coupling cam out of the blower drive coupling spring seats (12) and the blower drive coupling spring (13).

(10) Remove the blower drive coupling spring (12), the four blower drive coupling spring seats (11), and the blower drive cover packing (4) from the support.

**112. INSPECTION AND SERVICE OF THE BLOWER DRIVE  
GEAR, HUB AND SUPPORT.**

Clean and inspect parts, replacing where needed. Proceed as follows:

- a. Wash all parts.
- b. Examine the bearing in the support for wear, checking thrust faces and diameter. If wear is excessive, replace the support assembly.
- c. Examine the thrust face of the thrust washer for wear or score.



**Figure 111—Using Pilot Tool to Install Blower Drive Coupling Cam**

- d. Examine the blower drive gear hub for wear on the shaft and on the thrust face.
- e. Examine the gear teeth for chipping or wear.
- f. Examine the spring and spring seats for wear.
- g. Examine the cam for wear or flat spots.
- h. Blow out the oil holes in the support.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**113. ASSEMBLY OF THE BLOWER DRIVE GEAR, HUB AND  
SUPPORT.**

**a. Equipment.**

Gage, feeler

Hammer, soft

Screwdriver

Tool KM-J-1471

Vise


Wrench, socket, 1/2-in.

Wrench, socket, 1 7/8-in.

**b. Procedure (figs. 109, 110, 111 and 112).**

(1) Put the spring seats (11) and springs (12) in place in the blower drive coupling support (11). Install the cam on the pilot of tool KM-J-1471 (fig. 111). Using the tapered shaft of the tool to spread the springs, install the cam and remove the tool.

(2) With a soft hammer, drive the gear (10) on the pilot of the hub (8), lining up the bolt holes on the hub flange and the gear.




RA PD 11260

**Figure 112—Checking Clearance of Thrust Washer on Blower Drive  
Support Assembly**

(3) Install the blower drive coupling support (11).

(4) Install the blower drive coupling retainer (15) and the six bolts and lock washers (17) and (16).

DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES



RA PD 11261

Figure 113—Component Parts of Weight and Hub Assembly

## **TM 9-1750G**

**113-115**

### **ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71 POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

(5) Holding the assembly in a vise, use a  $\frac{1}{2}$ -inch socket wrench to tighten the six bolts and lock washers (17) and (16) holding the blower drive coupling support (11) to the hub (8).

(6) Reverse the support in the vise and install the hub into the blower drive gear support assembly (6).

(7) Install the ball lock (9) (fig. 110).

(8) Install the thrust washer (3) over the ball. Install the external tooth lock washer (2) and the special nut (1), using a  $1\frac{7}{8}$ -inch socket wrench to tighten. Turn down the fingers on the lock washer (2).

(9) Using a feeler gage (fig. 112), check the thrust washer clearance. Clearance tolerances are from 0.003 to 0.006 inch.

(10) Install the blower drive cover packing (4) in the groove on the support. Shellac a new gasket to the support.

(11) Insert a blower drive shaft in the spline to see if the cam of the blower drive coupling rotates freely. The cam must not bind on the retainer.

#### **114. DISASSEMBLY OF THE WEIGHT AND HUB ASSEMBLY.**

##### **a. Equipment.**

Hammer, soft

Wrench, socket,  $\frac{3}{16}$ -in.

**b. Procedure** (figs. 62 and 113). **NOTE:** In figure 113 the self-locking nut has been removed, and the assembly has been removed from the shaft.

(1) Remove the cotter pin from the locking nut which locks the bolt holding the entire assembly together. Using a  $\frac{3}{16}$ -inch socket wrench, remove the nut.

(2) Remove, in order, the balance weight hub, the balance weight, and the spring retainer from the bolt.

(3) With a soft hammer, drive out the spacer from the balance weight and remove the springs.

#### **115. INSPECTION AND SERVICE OF THE WEIGHT AND HUB ASSEMBLY.**


Inspection and service of the weight and hub assembly are performed as follows:

**a.** Inspect spring for wear. Note that springs are furnished in two thicknesses. If it is necessary to replace the spring packs, keep the total pack thickness to 0.225 minus 0.002 inch.

**b.** Inspect spacer for wear.

**c.** Inspect balance weight bushing and balance weight hub for smoothness and wear.

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



RA PD 11263

**Figure 114—Checking Clearance in Weight and Hub Assembly**



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**116. ASSEMBLY OF THE WEIGHT AND HUB ASSEMBLY.**

**a. Equipment.**

Gage, feeler, 0.005-in.

Wrench, socket,  $\frac{9}{16}$ -in.

Hammer, soft.

**b. Procedure (figs. 113 and 114).**

(1) Install the springs and the spacer in the balance weight, driving them into place with a soft hammer.

(2) Install the balance weight hub in the balance weight. Oil all working parts. See that the bushing moves freely on the hub.

(3) Install the spring retainer on the bolt and insert the bolt through the assembly. Using a  $\frac{9}{16}$ -inch socket wrench, install the nut and tighten the entire assembly. Install the cotter pin. **NOTE:** When the assembly is tightened, there should be approximately 0.005-inch clearance between the weight and hub, which can be checked with a feeler gage. This can be done after installation on the engine (fig. 114).

**117. DISASSEMBLY OF THE BALANCER SHAFT ASSEMBLY.**

**a. Equipment.**

Cutters, side

Wrench, socket, 1½-in.

Tool KM-J-1902

**b. Procedure (fig. 115).** **NOTE:** The balancer shaft has been removed from the engine and the rear end bearing has been removed.

(1) Using a 1½-inch socket wrench, remove the self-locking nut holding the balancer shaft gear to the balancer shaft.


(2) Using the gear puller tool KM-J-1902, pull the gear from the shaft. See figure 105, "Removing Camshaft Gear," for proper use of the tool.

(3) Slide off the front end bearings. **NOTE:** On the LA engine the balance shaft thrust bearing (grooved) is on the front end (gear end) of the shaft, while on the LC engine the thrust bearing is on the rear end of the shaft. Balance shaft is turned end for end to agree with camshaft regarding thrust.

**118. INSPECTION OF THE BALANCER SHAFT ASSEMBLY.**

Inspect all parts for wear and make necessary replacements. Radial clearance and end clearance of bearing is the same as for the camshaft (par. 106 b).

DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES



RA PD 11264

Figure 115--Component and Related Parts of Balancer Shaft Assembly

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**119. ASSEMBLY OF THE BALANCER SHAFT ASSEMBLY.**

**a. Equipment.**


**Tool KM-J-1903**

**Wrench, socket, 1½-in.**

**b. Procedure (fig. 115).**

(1) Oil and install the front end bearing. NOTE: Be sure that the thrust bearing (grooved) is on the front end (gear end) of the shaft on the LA engine, and on the rear end of the shaft on the LC engine. Install Woodruff key. Using tool KM-J-1903 (fig. 107), drive the balancer shaft gear on the shaft, making sure beforehand that the Woodruff key is properly installed in the shaft.

(2) Using a 1½-inch socket wrench, install the self-locking nut holding the balancer shaft gear to the balancer shaft.



RA PD 11266

**Figure 116—Removing Fan Idler Gear Shafts from Balance Weight Cover**

**120. DISASSEMBLY OF THE BALANCE WEIGHT COVER  
ASSEMBLY CONTAINING THE FAN IDLER GEARS.**


**a. Equipment.**

**Wrench, open-end, 1-in.**

**Wrench, socket, ½-in.**

**b. Procedure (fig. 116).**

DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES



RA PD 11267

Figure 117 —Components of Oil Pressure Regulator Assembly

**TM 9-1750G**  
**120-124**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71**  
**POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

(1) Using a 1/2-inch socket wrench, remove the bolts and lock washers on the two small fan idler shaft end plates, noting that each plate has a rib on the back which holds the fan shafts in place and keeps them from turning. Note in figure 116 that these plates have already been removed.

(2) Remove the gear inspection plug, using a 1-inch open-end wrench.

(3) Install a 3/8-inch bolt, National Fine, in the shaft holes and pull out the gear shafts, removing the gears at the back at the same time (fig. 116).

**121. INSPECTION AND SERVICE OF THE BALANCE WEIGHT COVER AND FAN IDLER GEARS.**

Inspect gears, gear bushings and gear shafts and make necessary replacements. Clean gear bushing oil feed holes.

**122. ASSEMBLY OF THE BALANCE WEIGHT COVER AND FAN IDLER GEARS.**

**a. Equipment.**

Wrench, open-end, 1-in.

Wrench, socket, 1/2-in.

**b. Procedure (fig. 116).**

(1) Oil and install the two gear shafts and gears in the balance weight cover.

(2) Using a 1-inch open-end wrench, install the gear inspection plug.

(3) Using a 1/2-inch socket wrench, install the bolts and lock washers on the two small fan shaft cover plates, being sure that each cover plate rib is properly installed in the slot on the shaft.

**123. DISASSEMBLY OF THE OIL PRESSURE REGULATOR VALVE ASSEMBLY.**

**a. Equipment.**

Wrench, open-end, 1-in.

**b. Procedure (fig. 117).**

(1) Using a 1-inch open-end wrench, remove the oil pressure regulator plug.

(2) Pull out the oil pressure regulator spring.

(3) Pull out the oil pressure regulator valve with the open end first.

**124. INSPECTION AND SERVICE OF THE OIL PRESSURE REGULATOR VALVE ASSEMBLY.**

Inspect and service the assembly as follows:

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**

- a. Inspect the seat of the valve for wear and check the outside surface for smoothness.
- b. Inspect the spring. Free length should be approximately  $2\frac{3}{4}$  inches.
- c. Inspect the oil pressure regulator body for cracks or improper seating.
- d. Make any necessary replacements.


**125. ASSEMBLY OF THE OIL PRESSURE REGULATOR VALVE  
ASSEMBLY.**

**a. Equipment.**

Wrench, open-end, 1-in.

**b. Procedure (fig. 117).**

- (1) Install the valve with the open end out. The valve should move up and down freely in the body.
- (2) Install the spring.
- (3) Using a 1-inch open-end wrench, install the plug.



RA PD 11268

**Figure 118—Removing Oil Pump Driving Gear**

**126. REMOVAL OF THE OIL PUMP DRIVING GEAR FROM  
CRANKSHAFT.**

**a. Equipment.**

Tool KM-J-1931


**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**b. Procedure (fig. 118).**

Pull off the oil pump driving gear, using tool KM-J-1931 (fig. 118).

**127. INSPECTION OF THE OIL PUMP DRIVING GEAR.**

Inspect the gear for uneven wear, broken or chipped teeth. If damaged, replace with a new gear. **NOTE:** This gear must be replaced if the oil pump driven gear mounted on the pump drive shaft (32, fig. 96) was replaced.



RA PD 11269

**Figure 119—Installing Oil Pump Driving Gear**

**128. INSTALLATION OF THE CRANKSHAFT OIL PUMP  
DRIVING GEAR.**

**a. Equipment.**

Hammer, soft

Tool KM-J-1935

**b. Procedure (fig. 119).**

Using tool KM-J-1935 and a soft hammer, drive on the oil pump driving gear with the countersunk side of the gear toward the crankshaft journal (fig. 119).

DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES

RA PD 11270




Figure 120—Components of Crankshaft Rear Cover



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**129. DISASSEMBLY OF THE CRANKSHAFT REAR COVER.**

**a. Equipment.**

Tool, oil seal remover

Wrench, socket,  $\frac{3}{4}$ -in.

**b. Procedure (fig. 120).**

(1) Using a  $\frac{3}{4}$ -inch socket wrench, remove the oil pump drive idler gear shaft nut and the lock washer, and remove the gear and shaft.

**NOTE:** The flat surface of the shaft is installed at the top of the assembly to catch oil.

(2) Using a  $\frac{3}{4}$ -inch socket wrench, remove the two bolts and lock washers holding the engine rear support bracket to the crankshaft rear cover and remove the bracket.

**130. INSPECTION AND SERVICE OF THE CRANKSHAFT REAR COVER.**

Inspect the oil seal, leaving it in the cover unless replacement is necessary. Inspect gear teeth and bushing for wear. Clean oil hole. Inspect shaft bushing surface for smoothness. Check shaft fit in gear. Make any necessary replacements. **NOTE:** The oil pump drive idler gear must be replaced if the oil pump driven gear mounted on the pump drive shaft (32, fig. 96) was replaced.

**131. ASSEMBLY OF THE CRANKSHAFT REAR COVER ASSEMBLY.**

**a. Equipment.**

Wrench, socket,  $\frac{3}{4}$ -in.

**b. Procedure (fig. 120).**

(1) Using a  $\frac{3}{4}$ -inch socket wrench, install the two bolts and lock washers holding the engine rear support bracket to the crankshaft rear cover.

(2) Install the shaft and oil pump drive idler gear. **NOTE:** There is a flat spot on the shaft to keep it from turning while it is being tightened.

(3) Using a  $\frac{3}{4}$ -inch socket wrench, install the shaft nut and lock washer.

**132. INSPECTION OF THE IDLER GEAR ASSEMBLY (fig. 121).**


Inspect the idler gear assembly as follows:

**a.** Each part of this assembly should be washed and inspected.

**b.** Inspect the journal on the gear hub for scoring, and also check the diameter.

**c.** Check the thrust face of hub.

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**



**Figure 121—Components of Idler Gear Assembly**

- d. Clean the oil feed hole in the hub.
- e. Check the inside diameter of the gear bearing for scoring.
- f. Check the clearance between the gear bearing and journal. The gear should fit smoothly on the hub without excessive end play or radial clearance. **NOTE:** Idler gear bushings are not replaceable; therefore, in case of bushing failure, the idler gear assembly must be replaced.
- g. Inspect the gear bearing thrust faces for wear and smoothness.
- h. Inspect the gear teeth.
- i. Examine the face of hub for scoring and wear. If necessary, replace worn parts.

**133. INSPECTION OF CRANKSHAFT GEAR AND OIL SLINGER**  
(fig. 64).

Follow these steps to inspect the crankshaft gear and oil slinger:

- a. Inspect gear teeth for chipping or wear.
- b. Check the oil slinger for smoothness and contact with gear. **NOTE:** Provisions are made for a tight fit between the back of the oil slinger and gear to prevent oil leakage behind the slinger. Consequently, the slinger should be free from warping, dents, or other damage.

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 122—Component Parts of Secondary Fuel Filter

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES****134. INSPECTION AND SERVICE OF CYLINDER BLOCK**  
(fig. 69).

The cylinder block should be inspected as follows:

- a. Remove all gaskets from the block.
- b. Remove both oil hole plugs from the ends of the cylinder block.
- c. Remove the fittings from each end of the block on all oil passages.
- d. Remove the air box drain fittings.
- e. Examine the core plugs for evidence of leakage, and replace them if necessary.
- f. Examine the cylinder block bores for possible cracks.
- g. Clean the block thoroughly by immersing them in a cleaning tank.

**135. DISASSEMBLY, INSPECTION, AND SERVICE OF  
SECONDARY FUEL FILTER.**

a. In removing the fuel lines it was necessary to remove the secondary fuel filter shell and cover from the cylinder head (par. 48).

b. Disassemble the rest of the assembly as follows:

(1) Remove the shell gasket from the cover for inspection.

(2) Remove and inspect the element for a plugged condition. During a long operating period the element becomes coated with gum or residue from the fuel oil. This restricts the fuel passage and necessitates replacement of the element.

(3) The filter is equipped with a gasket between the center stud nut and the shell. If it is necessary to replace this gasket, use the following steps:

(a) Remove the retaining ring on the stud and remove the stud from the shell.

(b) Replace arc gasket.

(c) Install the stud in the shell and secure with a retaining ring.

(4) Wash all parts except the element in SOLVENT, dry cleaning, and dry them with compressed air. The element must be replaced.

(5) Blow out the center stud and the elbows on the cover.


**136. ASSEMBLY OF SECONDARY FUEL FILTER (fig. 122).**

a. Replace the shell gasket in the cover if necessary.

b. If necessary, install a new filter element in the shell on the stud.

c. Until the assembly is attached to the cylinder head, replace the shell and element on the cover temporarily to protect it against dirt.

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



RA PD 11274

**Figure 123—Components of Air Cleaner**

**DISASSEMBLY, INSPECTION, SERVICE, REPAIR, AND ASSEMBLY  
OF SUBASSEMBLIES**

**137. DISASSEMBLY OF AIR CLEANER ASSEMBLIES (fig. 123).**

The air cleaner consists of a metal wool cleaning element supported inside the housing, beneath which is contained a bath of oil. Air drawn into the cleaner by the blower passes over the top of the oil bath, where the major portion of the dirt is trapped. Then it goes up through the oil-washed metal wool, where the finer remaining particles are removed before the air is drawn through the central duct to the blower. Removal of parts is as follows:

- a. Remove the wing bolt.
- b. Lift off the cover.
- c. Pull out the element.
- d. Remove the old oil.

**138. INSPECTION AND SERVICE OF AIR CLEANER  
ASSEMBLIES (fig. 123).**

The disassembled air cleaner assemblies should be inspected and serviced as follows:

- a. Wash all parts.
- b. Blow out the element with compressed air.
- c. Examine all gaskets and replace where needed.

**139. ASSEMBLY OF AIR CLEANER ASSEMBLIES (fig. 123).**

After thorough inspection and service, assemble each air cleaner assembly as follows:

a. Install the air cleaner housing and gasket in the air inlet housing mounting tube. Fill with oil of the same viscosity as that used in the engine (heavy-duty, SAE 30) to the mark indicated. (See U. S. Army Specification No. 2-104A for heavy-duty lubricants to be used.) NOTE: Do not raise oil level higher than indicated; otherwise, pull-over may result.

- b. Install the element.
- c. Install the cover.
- d. Install the wing bolt.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section VII**

**ASSEMBLY OF THE ENGINE**

	<b>Paragraph</b>
Facilities needed .....	140
General precautions .....	141
Inspection of components .....	142
Lubrication of components .....	143
Installation of cylinder block on engine stand .....	144
Installation of cylinder block end plates .....	145
Installation of the crankshaft .....	146
Installation of the crankshaft gear, idler gear, and spacer and dowel assembly .....	147
Installation of the balancer shaft, camshaft, end bearings, and tachometer drive .....	148
Installation of the weight and hub assembly and fan drive gear and balance weight assembly .....	149
Installation of the crankshaft rear cover assembly .....	150
Installation of the vibration damper assembly .....	151
Installation of the fan oil pipe and balance weight cover .....	152
Installation of the flywheel and flywheel housing .....	153
Installation of the clutch disk and the clutch assemblies .....	154
Installation of the oil cooler assembly .....	155
Installation of the starter assembly .....	156
Installation of the blower assembly and attached parts .....	157
Installation of cylinder liners .....	158
Installation of the piston and connecting rod assembly .....	159
Installation of the oil pump assembly and oil pressure regulator assembly .....	160
Installation of injectors .....	161
Installation of the cylinder head assembly .....	162
Installation of the injector control tube and bracket assembly ..	163
Installation of the exhaust manifold .....	164
Installation of the secondary fuel filter and lines .....	165
Installation of the cylinder head vent .....	166
Installation of the governor control housing assembly .....	167
Installation of the water bypass tube .....	168
Removal of the engine from the rotating stand .....	169
Installation of the air heater assemblies .....	170

## ASSEMBLY OF THE ENGINE

	Paragraph
Installation of handhole covers . . . . .	171
Installation of fuel and lubricating oil lines, high tension leads, three-way tee and junction plates . . . . .	172
Installation of the generator assembly . . . . .	173
Installation of LA engine on twin engine stand . . . . .	174
Installation of the oil cooler water drain valve assembly . . . . .	175
Installation of the six air cleaner assemblies . . . . .	176
Installation of the fan and related parts . . . . .	177
Installation of the clutch housing assembly . . . . .	178
Installation of the engine transfer gear housing . . . . .	179
Timing the engine . . . . .	180

### 140. FACILITIES NEEDED.

In addition to the tools required for disassembly of the engine, in assembling the engine it is necessary to have standard cleaning facilities plus the following special tools:

Gages, feeler	Wrench, tension
Guides, tool KM-J-1927	

### 141. GENERAL PRECAUTIONS.

In assembling the engine it is important to observe the following precautions:

a. **Install New Gaskets.** Wherever a gasket is used, a new gasket should be installed when the engine is being assembled.

b. **Fitting Parts.** Avoid forcing to make parts fit, and use special pilot tools where specified, in order to assure proper alinement of parts. Double check the proper location before installing a part.

c. **Protect All Leather Seats with the Tools Provided.**

d. **Check for Free Movement of Parts.** During the assembly, turn the engine over occasionally to check for free movement of parts. It is especially important that this be done after a moving part has been installed.

e. **Tightening Bolts.** Refer to the tension wrench table in paragraph 314 when tightening bolts with a tension wrench.

### 142. INSPECTION OF COMPONENTS.

Before assembling the engine, make sure that all parts are clean. They can be cleaned with SOLVENT, dry cleaning, or other standard cleaners. For special cleaning instructions, refer to instructions for the specific part or assembly in section VI. Install no part or subassembly unless it is new, completely rebuilt, or serviced for efficient operation. Replace all defective parts with new parts.



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**143. LUBRICATION OF COMPONENTS.**

Lubricate all moving parts with oil or grease as outlined in the assembly operation instructions which follow. This is particularly important when installing bearings, gears and bushings.

**144. INSTALLATION OF CYLINDER BLOCK ON ENGINE  
STAND.**


**a. Equipment.**

Stand, rotating engine  
(tool KM—J-1926)  
Wrench, open-end, 1/2-in.

Wrench, open-end, 1/6-in.  
Wrench, square end, 3/8-in.

**b. Procedure.**

- (1) **INSTALL CYLINDER BLOCK ON ROTATING ENGINE STAND.**  
Stand, engine rotating



**Figure 124—Installing Cylinder Block Front End Plate**

If the cylinder block has been removed from the rotating engine stand KM—J-1926, it should be placed back on, with the block turned bottom side up. This is the reverse of the position shown in figure 69.

## ASSEMBLY OF THE ENGINE

### (2) INSTALL MAIN OIL GALLERY LINE PLUGS.

Wrench, square end,  $\frac{3}{8}$ -in., or  
socket handle with  $\frac{3}{8}$ -in.  
square drive

Using a  $\frac{3}{8}$ -inch square end wrench or socket handle with  $\frac{3}{8}$ -inch square drive, install main oil gallery line plugs.

### (3) INSTALL FITTINGS.

Wrench, open-end,  $\frac{9}{16}$ -in.

Install all fittings that were removed from oil passages in the cleaning operation.

### (4) CHECK ALL PLUGS.

Check to be sure that all plugs are in place, including the cup-type plugs in the top surface of the block.


## 145. INSTALLATION OF CYLINDER BLOCK END PLATES.

### a. Equipment.

Tool, KM—J-1927

Wrench, socket,  $\frac{3}{4}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.



**Figure 125—Camshaft Bearing Being Used to Line Up Cylinder Block Front End Plate**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**b. Procedure.**

(1) **INSTALL AIR BOX DRAIN CLEANERS** (fig. 69).


Install the air box drain cleaners by hand at both ends of the block on the blower side of the engine.

(2) **INSTALL THE FRONT END PLATE** (figs. 69, 124 and 125).

Tool KM-J-1927

Wrench, socket,  $\frac{9}{16}$ -in.

With the cylinder block bottom side up on the engine stand, the front end plate on LA engines attaches to the left-hand end (when viewed from the blower side of the block). On LC engines it attaches to the



**Figure 126—Installing Cylinder Block Rear End Plate**

right-hand side. Inspect the end plates for flatness and smoothness (absence of burs) to insure a tight seal. Install the guides, using tool KM-J-1927 (fig. 124), and then install the front end plate gasket, coating the end of the cylinder block and the plate side of the gasket with standard gasket cement. Put the end plate in place on the guides (fig. 124). Install a camshaft end bearing on the blower side of the plate to serve as a guide before tightening the end plate bolts. Put the six end plate bolts and lock washers in place and tighten, using a  $\frac{9}{16}$ -inch socket wrench. Remove the guides and remove the camshaft end bearing (fig. 125).

## ASSEMBLY OF THE ENGINE

### (3) INSTALL THE REAR END PLATE (fig. 126).

Tool KM-J-1927


Wrench, socket,  $\frac{3}{4}$ -in.

Wrench, socket,  $\frac{1}{8}$ -in.

Put the rear end plate gasket in place, coating the end of the cylinder block and plate side of the gasket with standard gasket cement. This seals both sides of the gasket. Put the end plate in place on the guides, using tool KM-J-1927, and install on the dowel pins. NOTE: With the cylinder block bottom side up on the engine stand, the rear end plate on the LA engine attaches to the right-hand end (when viewed from the blower side of the block). On the LC engine, it attaches to the left-hand side. Before installing the end plate, inspect it for flatness and absence of burs, in order to ensure a good seal against the gasket. Install the six smaller bolts and the two larger bolts. Tighten the smaller bolts with a  $\frac{1}{8}$ -inch socket wrench, and tighten the two larger ones with a  $\frac{3}{4}$ -inch socket wrench.

SHELL, CRANKSHAFT MAIN BEARING UPPER

RA PD 11254



**Figure 127—Installing Crankshaft Main Bearing Shell—Upper**

## 146. INSTALLATION OF THE CRANKSHAFT.

### a. Equipment.

Gages, feeler, 0.025-in. to  
0.075-in.


Wrench, tension

Wrench, socket,  $\frac{1}{8}$ -in., with  
extension handle

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2****b. Procedure.**

(1) **INSTALL THE UPPER CRANKSHAFT MAIN BEARING SHELLS** (figs. 71 and 127).

Install the shells, with tangs in place, so that the oil hole in each shell lines up with the cylinder block oil passage (fig. 127). **NOTE:** The upper shell has a continuous groove and also an oil hole in the center.



**Figure 128—Using Tension Indicator Wrench to Tighten Nut on Crankshaft Main Bearing Cap**

(2) **INSTALL THE CRANKSHAFT** (fig. 71).

Lubricate all bearing shells with OIL, engine, heavy-duty, SAE 30. Put the crankshaft in the engine, placing the crankshaft flange at the rear of the engine.

(3) **INSTALL THE FRONT MAIN BEARING THRUST WASHERS** (fig. 71).

Install the front main bearing thrust washers so that the oil grooves are next to the crankshaft thrust facings (fig. 71). **NOTE:** Bearing caps are placed so that the numbered sides are toward the blower side of the engine.

**ASSEMBLY OF THE ENGINE****(4) INSTALL LOWER MAIN BEARING SHELLS (fig. 71).**


Wrench, socket,  $\frac{1}{8}$ -in.

Install the shells in number 7 bearing cap and put the thrust bearing halves in place on the pins in the cap (fig. 71); then assemble to the block. Install lower bearing shells in remaining bearing caps with tangs in place and assemble to block. Lower shells are plain and without oil grooves. Then install the nuts and tighten them with a  $\frac{1}{8}$ -inch socket wrench.

**(5) CHECK CRANKSHAFT END PLAY.**

Gage, feeler, 0.005-in.

Using feeler gages, check crankshaft end play at rear main bearing thrust washers. End play tolerance is 0.0025 to 0.0075 inch.



**Figure 129—Installation of Crankshaft Gear**

**(6) CHECK NUTS WITH A TENSION WRENCH (fig. 128).**

Wrench, tension

Line up the nuts so that the cotter pins can be installed, and check with a tension wrench set at 185 foot-pounds (fig. 134). **NOTE:** The crankshaft should turn freely when rotated by hand, if properly installed.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**147. INSTALLATION OF THE CRANKSHAFT GEAR, IDLER  
GEAR, AND SPACER AND DOWEL ASSEMBLY.**

**a. Equipment.**

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{3}{4}$ -in.

**b. Procedure.**

**(1) INSTALL THE CRANKSHAFT GEAR (fig. 129).**

Wrench, socket,  $\frac{9}{16}$ -in.

Install the crankshaft gear on the crankshaft with the beveled edge of the gear toward the engine. NOTE: Since one bolt hole in this gear is offset, the gear can be installed in one position only. Install the oil slinger which fits next to the gear. It also has an offset bolt hole. Install the bolts and lock washers holding the gear to the crankshaft flange, using a  $\frac{9}{16}$ -inch socket wrench to tighten the bolts. To keep the crankshaft from turning during the bolt-tightening operation, secure it with a block of wood placed between a crankshaft throw and the crankcase.

**(2) INSTALLATION OF THE IDLER GEAR (figs. 121 and 129).**

Wrench, socket,  $\frac{3}{4}$ -in.

Rotate the engine on the stand to a position where the gear train end of the block is at a 45-degree angle above the horizontal. Oil the idler gear hub and dowel, and put grease on one side of the spacer to help hold it in place on the end plate. Rotate the crankshaft gear so that the timing mark L is approximately in line with the idler gear hub hole. Place the spacer on the end plate in approximately the correct position, with the grease holding it to the plate. Set the idler gear in place, lining up the L mark on the tooth of this gear with the L mark on the crankshaft gear. Also line up the other L mark at the top of the idler gear, with the L mark on the tooth of the balancer gear on LA units or on the camshaft gear on LC units which are installed immediately following. While holding the idler gear against the end plate and spacer, line up the spacer with the hub and dowel holes in the end plate. Then install the hub and dowel, making sure that the hollow oil hole dowel pilots are in the dowel hole of the spacer and the end plate. Install the retainer bolt and lock washer, and tighten with a  $\frac{3}{4}$ -inch socket wrench.

**(3) CHECK FOR IDLER GEAR END PLAY.**

Gages, feeler, 0.003-in. to 0.006-in.

Using feeler gages, check the idler gear for end play. The idler gear end play tolerances are 0.003 to 0.006 inch.

**(4) INSTALLATION OF IDLER GEAR HOLE SPACER AND DOWEL  
ASSEMBLY (fig. 129).**

Wrench, socket,  $\frac{3}{4}$ -in.

Place the idler gear hole spacer and dowel assembly in position, with

**ASSEMBLY OF THE ENGINE**

the smaller end next to the end plate and with the dowel pin going into the dowel hole provided in the end plate. Install the center bolt and lock washer, and tighten the bolt.

**148. INSTALLATION OF THE BALANCER SHAFT, CAMSHAFT, END BEARINGS, AND TACHOMETER DRIVE.**

**a. Equipment.**

Gages, feeler, 0.005-in. to  
0.008-in.  
Screwdriver

Socket, deep, 1/2-in.  
Wrench, socket, 9/16-in.  
Wrench, socket, 1 1/2-in.

**b. Procedure.**

**(1) INSTALL PLAIN END BEARINGS (fig. 67).**

Wrench, socket, 9/16-in.

Oil the balancer and camshaft plain end bearings and install them, using a 9/16-inch socket wrench to tighten the six bolts and lock washers. They are installed at the rear or fan end on LA engines and at the front or flywheel end on LC engines.

**(2) OIL CAMSHAFT END AND INTERMEDIATE BEARINGS.**

Gages, feeler, 0.005-in. to 0.008-in.

**NOTE:** Although the camshafts are interchangeable for the LA and LC engines, the grooved (thrust) end bearing is at the front on LA models and at the rear on LC models. This position is necessary for proper engine operation. Oil the camshaft intermediate bearings and end bearings (through the oil holes), and recheck grooved (thrust) bearing end play to a tolerance of 0.005 to 0.008 inch. **NOTE:** On the LC unit the camshaft grooved (thrust) bearing end play must be checked after installation of the fan drive gear and balance weight assembly at the rear of the engine. The thrust on the LA engine is at the front end between the camshaft and camshaft gear.

**(3) INSTALL CAMSHAFT AND PLUG ASSEMBLY (fig. 66).**

Gages, feeler, 0.005-in. to  
0.008-in.

Screwdriver

Install the camshaft with the five sets of intermediate bearings, the end bearing and the camshaft gear already installed. Insert through the opening at the front end plate, and slide through until the other end comes through the rear end plate and bearing. Line up so that the five intermediate bearing bolt holes will line up with the fillister bolt holes in the top of the engine block. Install the intermediate bearing lock bolts, using a screwdriver. Oil balance shaft end bearings through oil hole. Using a feeler gage, recheck the thrust bearing end play to a



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

tolerance of 0.005 to 0.008 inch. On the LC unit the thrust bearing end play must be checked after installation of the weight and hub assembly.

**(4) INSTALL THE BALANCER SHAFT ASSEMBLY (fig. 66).**

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, socket, 1½-in.

Install the balancer shaft assembly in the cylinder block through the hole in the front end plate of the engine. Line up timing marks on the camshaft and balancer shaft gears when installing the balancer shaft assembly. Line up the balancer or camshaft gear L mark with the L mark on the idler gear. **NOTE:** Balancer and camshaft gear timing is done with the letter O. The L mark on the balancer or camshaft gear must line up with the idler gear. Screw in the six bolts and lock washers holding the camshaft and balancer shaft rear end bearings to the cylinder block, using a  $\frac{9}{16}$ -inch socket wrench to tighten the bolts securely. These bolts are installed through the access holes in the camshaft and balancer shaft timing gears (fig. 63). Rotate the gears to see that they do not bind at any point. Next, keep the gears from rotating by inserting a clean rag between the gear teeth, and with a 1½-inch socket wrench, tighten the self-locking cam and balancer shaft gear nuts.

**(5) CHECK FOR GEAR TRAIN BACKLASH.**

Gages, feeler, 0.004-in. to 0.007-in.

Check the timing marks on all gears to see that they are properly lined up. Balancer, camshaft, and crankshaft gears have 78 teeth, whereas the idler gear has 68 teeth; many revolutions of these gears may be required to check the alinement of the timing marks. Using feeler gages, check the gear train for backlash. Tolerances are 0.004 to 0.007 inch. If an indicator is available, it should be used.

**(6) INSTALL THE TACHOMETER DRIVE (fig. 64).**

Socket, deep, ½-in.

Slip a ½-inch long socket over the tachometer drive to avoid bending the oil slinger. Then tap the drive into place at the rear end of the balancer shaft.

**149. INSTALLATION OF THE WEIGHT AND HUB ASSEMBLY  
AND FAN DRIVE GEAR AND BALANCE WEIGHT  
ASSEMBLY.**

**a. Equipment.**

Wrench, socket, 1½-in.

**b. Procedure.**

**(1) INSTALL THE WEIGHT AND HUB ASSEMBLY (fig. 62).**

Wrench, socket, 1½-in.

## ASSEMBLY OF THE ENGINE

Install the weight and hub assembly on the balancer shaft with the articulated weight away from the engine, and push the assembly over the Woodruff key on the shaft. Install the self-locking nut on the end of the shaft. Hold the shaft from rotating by inserting a clean rag in the timing gear train. Tighten the nut with a 1½-inch socket wrench.

(2) INSTALL THE FAN DRIVE GEAR AND BALANCE WEIGHT ASSEMBLY (fig. 62).

Wrench, socket, 1½-in.

Install the fan drive gear and balance weight assembly on the camshaft, pushing the assembly over the key. Install the self-locking nut. Keep the shaft from rotating by inserting a clean rag in the gear train, and tighten the nut with a 1½-inch socket wrench. Check end play of the camshaft of the LC engine and the balancer shaft of the LA engine (par. 148).

### 150. INSTALLATION OF THE CRANKSHAFT REAR COVER ASSEMBLY.

#### a. Equipment.

Shellac

Wrench, socket, ¾-in.

Wrench, socket, ⅞-in.

#### b. Procedure.

(1) INSTALL GASKET AND COVER (fig. 62).

Shellac

Install a new crankshaft rear cover gasket, shellacking it to the cover and allowing the shellac to dry. Place the cover, with the gasket attached, over the dowel pins. NOTE: When installing the cover, it is necessary to place the crankshaft oil slinger between the idler gear assembly and the cover while sliding the cover over the crankshaft.

(2) INSTALL BOLTS (fig. 62).

Wrench, socket, ⅞-in.

Wrench, socket, ¾-in.

Install the three short bolts (National Fine) and lock washers at the top of the assembly, using a ⅞-inch socket wrench to tighten the bolts (fig. 62). Install the four large bolts and lock washers at the bottom of the assembly, using a ¾-inch socket wrench to tighten the bolts.

### 151. INSTALLATION OF THE VIBRATION DAMPER ASSEMBLY (figs. 60 and 62).

#### a. Equipment.

Hammer, soft

Wrench, socket, 1⅝-in.

#### b. Procedure.

(1) INSTALL FRONT CONE (fig. 62).

**TM 9-1750G**  
**151-152**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71**  
**POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

Before installing both the front and rear cones, examine them for smoothness. Check the front cone for perfect contact with the oil seal in the crankshaft rear cover.

**(2) INSTALL VIBRATION DAMPER ASSEMBLY.**

Hammer, soft.

Tap the vibration damper assembly on as far it will go, using a soft hammer.

**(3) INSTALL REAR CONE.**

Wrench, socket,  $\frac{5}{8}$ -in.

Install the rear cone so that the key slot fits over the Woodruff key on the crankshaft. Install the cone retainer bolt. Tighten the bolt with a  $\frac{5}{8}$ -inch socket wrench, holding the crankshaft from turning while doing so.

**152. INSTALLATION OF THE FAN OIL PIPE AND BALANCE WEIGHT COVER.**

**a. Equipment.**

Shellac

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, tension

**b. Procedure.**

**(1) INSTALL THE BALANCE WEIGHT COVER (figs. 34 and 58).**

Shellac

Wrench, socket,  $\frac{9}{16}$ -in.


Wrench, tension

Install a new gasket to the balance weight cover, shellacking it in place. Slide the cover on the engine and over the dowel pins. Install the bolts and lock washers holding the cover to the end plate, using a  $\frac{9}{16}$ -inch socket wrench to tighten the bolts. Check to be sure that the various sized bolts go in their proper places (fig. 34). Check all bolts with a tension wrench to 40 pounds.


**(2) INSTALL THE FAN OIL PIPE.**

Wrench, open-end,  $\frac{7}{16}$ -in.

Install the oil pipe leading from the balance weight cover to the cylinder block, using a  $\frac{7}{16}$ -inch open-end wrench to tighten the pipe (fig. 58).



**Figure 130—Inside of Flywheel Housing**



**Figure 131—Guides for Installing Flywheel**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**153. INSTALLATION OF THE FLYWHEEL AND FLYWHEEL  
HOUSING.**

**a. Equipment.**

Compound, standard sealing	Wrench, socket, $\frac{9}{16}$ -in.
Guide, KM—J-1927	Wrench, socket, $\frac{3}{4}$ -in.
Screwdriver	Wrench, socket, $\frac{1}{2}$ -in., with extension handle
Tool, KM—J-1359	Wrench, tension
Tool, KM—J-1910	

**b. Procedure.**

**(1) INSPECT OIL SEAL (fig. 130).**

Inspect the oil seal for evidence of leakage and wear, and replace if necessary. **NOTE:** If a new seal is used, soak it in oil for 30 minutes before installation. Also coat the outside of the seal housing with standard sealing compound before installing the new seal. Put grease on the end of the crankshaft where the seal makes contact.

**(2) INSTALL NEW GASKETS (fig. 130).**

Compound, sealing

Using sealing compound, install a new housing gasket and two new small gaskets inside the housing (fig. 130), after first inspecting the housing for traces of old gaskets. **NOTE:** If the engine support bracket rubber pads are worn, they should be replaced before the flywheel housing is installed.

**(3) INSTALL THE FLYWHEEL HOUSING (fig. 131).**

Guide KM—J-1927	Wrench, socket, $\frac{3}{4}$ -in.
Tool KM—J-1359	Wrench, tension.
Wrench, socket, $\frac{9}{16}$ -in.	

Apply sealing compound to the gasket surface of the end plate, idler gear hub, and spacer and dowel assembly. Place the four guides KM-J-1927 in place (fig. 131). Place the pilot tool KM-J-1359 in place (fig. 131). Install the flywheel housing, slipping it over the pilot and guides and then over the dowel pins. Install the six large bolts and lock washers on the inside of the housing, using a  $\frac{3}{4}$ -inch socket wrench to tighten the bolts; then install the six smaller bolts and lock washers on the inside of the housing. Install all remaining bolts (those holding the flywheel housing to the cylinder block rear end plate) using a  $\frac{9}{16}$ -inch socket wrench to tighten the bolts. Include the two bolts installed through the end plate into the flywheel housing. Using a tension wrench, tighten the six large bolts to 85 foot-pounds and the small bolts to 40 foot-pounds.

## ASSEMBLY OF THE ENGINE

### (4) INSTALL THE CLUTCH PILOT BEARING AND BAFFLE (fig. 55).

Tool KM—J-1910

Clean the clutch pilot bearing which was removed during the disassembly of the flywheel. Inspect it for wear and smoothness. Install the bearing with new grease, and, using tool KM—J-1910, drive it into place in the flywheel. Install the clutch pilot bearing grease baffle in the crankshaft.

### (5) INSTALL THE FLYWHEEL (fig. 55).

Screwdriver

Wrench, socket,  $\frac{1}{8}$ -in.

Wrench, socket,  $\frac{3}{4}$ -in.

Wrench, tension

Wipe off the flywheel and examine it for burs. Wipe the bolted flange of the flywheel where it pilots on the crankshaft. Set the flywheel in place on the end of the crankshaft flange and over the dowel pins. Since one bolt hole is off center, it is possible to install the flywheel in one position only. Install the six bolts, pulling the flywheel into place, and tighten them with a  $\frac{1}{8}$ -in. socket wrench. Hold the flywheel from turning, using a screwdriver between the ring gear and the housing (fig. 55). Check the bolts with a tension wrench to 180 foot-pounds. Install new locking wire on the flywheel bolts. Remove the pilot tool and the four guides.

## 154. INSTALLATION OF THE CLUTCH DISK AND THE CLUTCH ASSEMBLIES.

### a. Equipment.

Tool KM-J-1915

Wrench, socket,  $\frac{1}{2}$ -in.

### b. Procedure.

#### (1) INSTALL THE CLUTCH DISK ASSEMBLY (fig. 53).

Tool KM-J-1915


Examine the facings of the clutch disk assembly and measure for wear. If the over-all thickness of the facings is less than 0.370 inch, the shims between the clutch cover and the flywheel should be removed before replacing the clutch assembly. If the over-all thickness of the facings is less than 0.303 inch, then the clutch driven plate assembly must be replaced. It will then be necessary to replace the shims. See that the facings are free from oil or glazing. Set the disk in place (fig. 53). Insert the pilot tool KM-J-1915 through the disk and into the clutch pilot bearing, in order to hold the disk in position while the clutch assembly is being installed.

#### (2) INSTALL THE CLUTCH ASSEMBLY (fig. 132).

Wrench, socket,  $\frac{1}{2}$ -in.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

Install the clutch in place against the flywheel and install the 12 bolts and lock washers holding the assembly to the flywheel (fig. 132). A ½-inch socket wrench should be used to tighten the bolts evenly all around.



RA PD 11286

**Figure 132—Installation of Clutch Assembly Using Pilot Tool**

**155. INSTALLATION OF THE OIL COOLER ASSEMBLY.**

**a. Equipment.**

Wrench, open-end, ½-in.

Wrench, socket, ⅝-in.

Wrench, socket, ½-in.

**b. Procedure.**

**(1) INSTALL THE OIL COOLER ADAPTER (fig. 51).**

Wrench, socket, ⅝-in.

Install new adapter gaskets. Place the adapter against the engine block. Install the six bolts and lock washers holding the adapter to the engine block, using a ⅝-inch socket wrench to tighten the bolts (fig. 51). **NOTE:** Upper and lower hole bolts are ¼-inch shorter than the side hole bolts.

## ASSEMBLY OF THE ENGINE

### (2) INSTALL THE OIL COOLER ASSEMBLY (fig. 51).

Screwdriver  
Shellac

Wrench, open-end,  $\frac{1}{2}$ -in.  
Wrench, socket,  $\frac{1}{2}$ -in.

Install a new gasket on the cooler housing to oil cooler face. Install the cooler assembly in the housing. Using a new gasket, shellac it to the cooler on the side facing the adapter. Place the inlet seal and hose clamp on the cooler housing at the top. Install the cooler housing assembly to adapter, placing the water pump inlet seal over the water pump inlet elbow. Install bolt and lock washer at the top and at the bottom from the back of the assembly. Install and tighten the six through bolts and lock washers in the front of the assembly. Using a screwdriver, tighten the hose clamp seal between the cooler housing and water pump inlet.

### 156. INSTALLATION OF THE STARTER ASSEMBLY (fig. 17).

#### a. Equipment.

Wrench, socket,  $\frac{7}{8}$ -in., with extension handle

b. Procedure. Install the starter assembly in place, put on the lock washers, and tighten the three bolts holding the assembly to the flywheel housing, using a  $\frac{7}{8}$ -inch socket wrench with extension handle.

### 157. INSTALLATION OF THE BLOWER ASSEMBLY AND ATTACHED PARTS.

#### a. Equipment.

Cement, gasket	Wrench, socket, $\frac{1}{2}$ -in.
Screwdriver	Wrench, socket, $\frac{9}{16}$ -in.
Wrench, open-end, $\frac{7}{16}$ -in.	Wrench, socket, $\frac{5}{8}$ -in.
Wrench, open-end, $\frac{9}{16}$ -in.	

#### b. Procedure.

##### (1) INSTALL THE BLOWER DRIVE GEAR SUPPORT ASSEMBLY (fig. 50).

Wrench, open-end,  $\frac{7}{16}$ -in.      Wrench, socket,  $\frac{9}{16}$ -in.

Install a new gasket and the blower drive gear support assembly, securing them to the rear cylinder block end plate with the two  $\frac{3}{8}$ -inch bolts and lock washers provided for this purpose (fig. 50). A  $\frac{9}{16}$ -inch socket wrench should be used to tighten the bolts. The two bolts are located on the inside edge of the assembly, nearest the block. Do not use bolts longer than  $\frac{7}{8}$ -inch in length. Then install the blower drive bearing oil pipe between the support and the cylinder block. Use a  $\frac{7}{16}$ -inch open-end wrench to tighten the couplings on each end of the pipe.



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2****(2) INSTALL THE BLOWER GASKET**

Cement, non-hardening

Install the blower assembly gasket to the cylinder block, cementing it on with a gasket cement (use cement only on one side of the gasket).

**(3) INSTALL THE WATER PUMP OUTLET FLANGE.**

Wrench, socket,  $\frac{1}{2}$ -in.

Put new packing in the water pump outlet packing flange and install the flange, securing it to the cylinder block with the two bolts and lock washers provided for this purpose. A  $\frac{1}{2}$ -inch socket wrench should be used to tighten the bolts.

**(4) INSTALL COUPLINGS ON WATER PUMP DRAIN TUBE.**

Wrench, open-end,  $\frac{7}{16}$ -in.

Install the two couplings on the ends of the water pump drain tube (fig. 27), using a  $\frac{7}{16}$ -inch open-end wrench to tighten. Install the tube between the pump body and the oil cooler housing.

**(5) INSTALL THE BLOWER ASSEMBLY (figs. 37, 48, and 49).**

Wrench, socket,  $\frac{5}{8}$ -in.

Put a new blower drive cover packing on the blower support and apply oil to the packing. Then, placing the blower drive cover over the packing, hold the assembly firmly and aline the holes in the housing with the cylinder block. Install the eight bolts and flat washers holding the assembly to the block, using a  $\frac{5}{8}$ -inch socket wrench to tighten the bolts (figs. 37 and 49).

**(6) INSTALL THE BLOWER DRIVE SHAFT (fig. 48).**


Install the blower drive shaft by sliding it into place (fig. 48) and engaging the splines in the blower drive hub and also those in the cam of the blower drive coupling.

**(7) INSTALL THE FLYWHEEL HOUSING SMALL HOLE COVER (figs. 15 and 139).**

Wrench, socket,  $\frac{9}{16}$ -in.

Install the flywheel housing small hole cover (fig. 139). Install the four long bolts, sliding one of them through the hole in the fuel pump drip shield. Install the four nuts and lock washers on the bolts to the flywheel housing, holding the cover and the blower drive gear support assembly and using a  $\frac{9}{16}$ -inch socket wrench to tighten the bolts. Install and tighten the two shorter bolts and lock washers. **NOTE:** On the LC engine the generator is installed instead of the flywheel housing small hole cover. Directions for installing the generator are given in paragraph 173 of this section.

## ASSEMBLY OF THE ENGINE



**Figure 133—Cylinder Block Ready for Piston Installation**

### 158. INSTALLATION OF CYLINDER LINERS.

- a. Clean cylinder block liner recesses (figs. 9, 47 and 133).
- b. **Install Cylinder Liners.** Turn the engine on the stand so that the top part is up and install the liners in the cylinder block. Cylinder block bore sizes provide for a dry slip fit on the cylinder liners.

### 159. INSTALLATION OF THE PISTON AND CONNECTING ROD ASSEMBLY.

#### a. Equipment.

Compressor, ring  
Gages, feeler, 0.004-in. to  
0.012-in.  
Hammer

Rod, steel  
Wrench, socket,  $\frac{1}{8}$ -in.  
Wrench, tension

#### b. Procedure.

##### (1) LUBRICATE PARTS.


Lubricate all pistons and rings and the upper connecting rod bearing shell.

##### (2) POSITION THE CRANKSHAFT.

Rod, steel

Screws, puller

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



**RA PD 11309**

***Figure 134—Installing Piston***

## ASSEMBLY OF THE ENGINE

Select the connecting rod and piston to be installed, and turn the crankshaft with a steel rod so that the corresponding crankpin is at the bottom of the stroke. Place the steel rod between two puller screws which should be installed in the end of the crankshaft assembly.

**(3) PLACE RING COMPRESSOR TOOL IN POSITION (fig. 139).**

Tool, ring compressor

Put a ring compressor tool, with the small side facing the bottom of the piston, over the connecting rod (fig. 133). Stagger the oil ring and expander gaps, and tap the compressor tool until it is flush with the bottom of the piston.

**(4) INSTALL CONNECTING ROD AND PISTON ASSEMBLIES (figs. 133 and 134).**

Hammer

Tool, ring compressor

Insert the connecting rod in the cylinder with the upper bearing in place and with the numbered side of the rod towards the blower side of the engine (fig. 133). Place the assembly so that the ring compressor tool sits on the top of the cylinder (fig. 134). Stagger the compression ring gaps. Tap down the piston with a hammer handle, guiding the piston and rings with the other hand and continuing to drive it until the connecting rod bearing shell seats on the crankshaft. Care must be taken in tapping the assembly into place, as careless installation will result in broken rings. The connecting rod must be exactly lined up with the crankshaft journal, or damage to the crankshaft and connecting rod faces will result. Make certain that the upper bearing shell is still in place before seating the rod on the crankshaft. **NOTE:** The upper half of the bearing has two short grooves from the bearing shell edge with two oil holes that supply the piston cooling oil; the tang in the shell must engage with the notch in the rod.

**(5) INSTALL CONNECTING ROD CAP.**

Wrench, socket,  $\frac{1}{16}$ -in.

Wrench, tension

Oil the lower bearing shell and install the connecting rod cap from the bottom of the engine so that the number is toward the blower side of the engine. **NOTE:** Radial clearance of bearings is covered in paragraph 71 c. Tighten the cap nuts with an  $\frac{1}{16}$ -inch socket wrench, line up the cotter pin holes, and check the nuts with a tension wrench to 70 foot-pounds.

**(6) CHECK CONNECTING ROD SIDE CLEARANCE.**

Gages, feeler

Using feeler gages, check the connecting rod side clearance. Side clearance tolerance is 0.006 to 0.012 inch. **NOTE:** Radial clearance may

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

be checked in the same manner on the main journals. Put cotter pins in nuts. Install the remaining piston and rod assemblies in the same manner, turning the crankshaft to the proper position.

**160. INSTALLATION OF THE OIL PUMP ASSEMBLY AND OIL  
PRESSURE REGULATOR ASSEMBLY.****a. Equipment.**

Shellac

Wrench, socket,  $\frac{9}{16}$ -in.Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, socket, 1-in.

Wrench, socket,  $\frac{1}{2}$ -in.**b. Procedure.****(1) INSTALL THE OIL PUMP ASSEMBLY (fig. 44).**

Shellac

Wrench, socket,  $\frac{1}{2}$ -in.Wrench, open-end,  $\frac{9}{16}$ -in.Wrench, socket,  $\frac{9}{16}$ -in.

After turning the engine upside down on the stand, put the oil pump assembly into place. Install a new gasket, shellacking it in place. Using a  $\frac{9}{16}$ -inch socket wrench on the two bolts holding the oil pump to the number 1 cap, and using a  $\frac{9}{16}$ -inch open-end wrench on the two bolts holding the oil pump to the number 2 cap, install and tighten the four bolts. Install the locking wire in each set of bolts. Install the bolts and lock washers holding the scavenging pump inlet pipe clip to the number 5 bearing cap, using a  $\frac{9}{16}$ -inch open-end wrench to tighten the bolts. Install the two bolts and lock washers holding the pressure pump outlet pipe to the crankcase, using a  $\frac{1}{2}$ -inch socket wrench to tighten the bolts. To make the pipe fit properly, it may be necessary to loosen the two bolts on the flange attached to the pump body, which will allow the pipe to move slightly when it is assembled to the cylinder block.

**(2) INSTALL THE OIL PRESSURE REGULATOR ASSEMBLY (fig. 44).**Wrench, socket,  $\frac{1}{2}$ -in.

Install a new oil pressure regulator assembly gasket, shellacking it onto the crankcase side. After allowing time for the shellac to become tacky, install the oil pressure regulator, using a  $\frac{1}{2}$ -inch socket wrench to tighten the bolts.


**(3) INSTALL THE OIL PAN (figs. 43 and 44).**Wrench, socket,  $\frac{1}{2}$ -in.

Shellac a new gasket on the oil pan and, after the shellac has almost dried, install the pan (with connections lined up) and the attached gasket, securing them to the crankcase with the 32 bolts and lock washers, using a  $\frac{1}{2}$ -inch socket wrench to tighten the bolts. Install the drain plugs and tighten with a  $\frac{1}{2}$ -inch socket wrench.

## ASSEMBLY OF THE ENGINE

- (4) **INSTALL THE OIL PUMP INLET AND OUTLET ELBOWS** (fig. 135).  
Wrench, socket,  $\frac{9}{16}$ -in.

Install a new special cork gasket and the inlet and outlet elbow (opening to rear) to the oil pan, placing the cork inset side of the gasket next to the pan and securing the elbow and the gasket to the pan with the two bolts and lock washers, using a  $\frac{9}{16}$ -inch socket wrench to tighten the bolts. **NOTE:** There are two elbows—one on either side of the oil pan—and each is installed in the same manner.



**Figure 135—Installing Oil Pump Inlet or Outlet Elbow**

## 161. INSTALLATION OF INJECTORS.

### a. Equipment.

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, tension

### b. Procedure.

- (1) **TIP BACK ROCKER ARMS** (figs. 41 and 42).

Remove the bolts holding the rocker shaft brackets to the cylinder head. Tip back the assembly, including the valve and injection rocker arms (fig. 41). **NOTE:** This can be done even though shafts, brackets and bolts remain assembled. **CAUTION:** Do not bend push rods. Rotate the engine if shaft and brackets do not tip back easily.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**(2) INSTALL THE INJECTOR.**

**Wrench, socket,  $\frac{3}{16}$ -in.**

**Wrench, tension**

Install the injector in position so that the locating dowel on the injector will go in the locating hole in the cylinder head. Install the injector clamp. Install the special washer and the nut, tightening the nut with a  $\frac{3}{16}$ -inch socket wrench and check it to 12 to 15 foot-pounds with a tension wrench. After tightening the nut, examine the injector racks to see that they work freely. Be sure that the injector clamps do not interfere with the exhaust valve springs.

**162. INSTALLATION OF THE CYLINDER HEAD ASSEMBLY.**

**a. Equipment.**

**Cement, non-hardening**

**Wrench, socket,  $\frac{5}{8}$ -in.**

**Hoist, chain**

**Wrench, socket,  $\frac{5}{8}$ -in.**

**Wrench, box socket,  $\frac{9}{16}$ -in.**

**Wrench, tension**

**Wrench, socket,  $\frac{7}{16}$ -in.**

**b. Procedure.** Before proceeding with the installation of the cylinder head, be sure it has been inspected and assembled according to the steps outlined in section VI, paragraphs 79 to 94 inclusive. Then proceed as follows:

**(1) INSTALL NEW GASKETS**

**Cement, gasket**

**Gaskets**

Install a new head gasket and new oil gaskets on the ends and sides of the cylinder block. Coat both sides of the outer oil gasket with gasket cement. The metal gasket, however, should be assembled dry with the side marked Top outward.

**(2) INSTALL THE CYLINDER HEAD ON THE BLOCK (fig. 40).**

**Hoist, chain**

**Wrench, tension**

**Wrench, socket,  $\frac{5}{8}$ -in., with  
extension handle**

Before installing the head on the block, wipe off the cylinder head face next to the gasket. Also be sure that the bolts holding the lifter brackets to the cylinder head are loosened so that the brackets will not interfere with proper seating of the head. Using a chain hoist, install the cylinder head on the cylinder block with the exhaust port openings on the right-hand side of the engine. Using a  $\frac{5}{8}$ -inch socket wrench and extension, tighten the stud nuts securely, testing them with a tension wrench at 160 foot-pounds (cold).

**(3) TIGHTEN ENGINE LIFTER BRACKET BOLTS**

**Wrench, socket,  $\frac{7}{16}$ -in.**

## ASSEMBLY OF THE ENGINE

Tighten the four engine lifter bracket bolts with a  $\frac{7}{16}$ -inch socket wrench.

### 163. INSTALLATION OF THE INJECTOR CONTROL TUBE AND BRACKET ASSEMBLY.

#### a. Equipment.

Gage, feeler, 0.009-in.	Wrench, socket, $\frac{3}{4}$ -in.
Gage, feeler, 0.011-in.	Wrench, socket, $1\frac{5}{16}$ -in., with handle
Tool KM-J-1853	Wrench, universal socket, $\frac{7}{16}$ -in., with handle
Wrench, open-end, $\frac{5}{16}$ -in.	
Wrench, open-end, $\frac{1}{2}$ -in.	

#### b. Procedure.

##### (1) INSTALL THE CONTROL TUBE AND BRACKET ASSEMBLY (fig. 38).

Wrench, universal socket,  $\frac{7}{16}$ -in., with handle

This assembly is different for LA and LC engines. Enter each tube lever into each injector opening rack. Install the four bolts and lock washers that hold the brackets to the cylinder head. Tighten the bolts with a  $\frac{7}{16}$ -inch socket wrench. Check the assembly to see that there is no binding at any point and that the return spring at the end of the injector tube return rack is at the no fuel position. Do not bend the return spring. The standard spring should return the racks to no fuel, providing no binding exists elsewhere.


##### (2) TIME THE INJECTORS (figs. 83 and 136).

Tool KM-J-1853	Wrench, socket, $\frac{3}{4}$ -in.
Wrench, open-end, $\frac{5}{16}$ -in.	Wrench, socket, $1\frac{5}{16}$ -in., with handle
Wrench, open-end, $\frac{1}{2}$ -in.	

Tip the injector and exhaust valve rocker arm assemblies back in place. Using a  $\frac{3}{4}$ -inch socket wrench, tighten the bolts holding the rocker arm brackets to the cylinder head. Tap the injector rocker arm back and forth on the shaft to be sure there is side clearance and no binding. Clearance should be approximately 0.003 inch. Rotate the engine until the exhaust valves of the number 1 cylinder are fully open before timing the injector. Insert the small end of tool No. KM-J-1853 in the hole provided in the injector body. Set the injector timing by turning the injector rocker arm push rod assembly with a  $\frac{5}{16}$ -inch open-end wrench until the lower edge of the timing tool is just passing over and contacting the injector follower guide (fig. 136). Tighten the lock nut on the push rod, using a  $\frac{1}{2}$ -inch open-end wrench. Repeat the timing operations on the remaining five injectors, making sure to rotate the engine so that the exhaust valves on the cylinder for the injector being timed are fully open.




ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



**Figure 136—Timing the Injector**

ARM, EXHAUST VALVE ROCKER — RIGHT; ASSEMBLY

RA PD 11303



**Figure 137—Valve Tappet Adjustment**

## **ASSEMBLY OF THE ENGINE**

### **(3) VALVE LASH ADJUSTMENT.**

Gage, feeler, 0.011-in.

Gage, feeler, 0.013-in.

Correct valve lash is important. Too little clearance causes a loss of compression, missing cylinder, and eventual burning of valves and valve seats. Too much clearance between the end of the valve stem and the valve rocker arm results in noisy operation of the engine, especially in the idling range. Correct lash for all exhaust valves is 0.011 inch GO, and 0.013 inch NO GO at room temperature. Valve adjustment lash can be changed by means of the threaded upper part of push rod, which is screwed into the rocker arm clevis and locked by the lock nut. Adjustment is checked (fig. 137) without the aid of special tools. Valve lash should be taken when the injector arm is depressing the injector plunger for that particular cylinder. **CAUTION:** Whenever a push rod has been disconnected from the rocker arm clevis, the rod must be screwed back all the way into the clevis before the valve lash is checked. If this is not done, the piston may hit the head of the valve when the engine is being turned, because of the small clearance between the valves and the piston head at the piston upper position.

### **(4) INSTALL FUEL PIPES (fig. 37).**

Wrench, open-end, 1/2-in.

Blow out the fuel pipes with compressed air. Install the 12 pipes and tighten them securely with a 1/2-inch open-end wrench.

## **164. INSTALLATION OF THE EXHAUST MANIFOLD.**

### **a. Equipment.**

Wrench, socket, 5/8-in.

### **b. Procedure.**

#### **(1) INSTALL NEW GASKETS.**

Install new gaskets on the cylinder head exhaust port studs.

#### **(2) INSTALL THE EXHAUST MANIFOLD.**

Wrench, socket, 5/8-in.

Install the exhaust manifold in place, securing the gaskets and the manifold to the cylinder head with the seven flat washers and nuts, using a 5/8-inch socket wrench to tighten the bolts.

## **165. INSTALLATION OF THE SECONDARY FUEL FILTER AND LINES.**

### **a. Equipment.**

Wrench, open-end, 1 1/8-in.

Wrench, open-end, 1 1/8-in.

Wrench, open-end, 5/8-in.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**h. Procedure.**

**(1) INSTALL COVER (fig. 28).**

Wrench, open-end,  $\frac{9}{16}$ -in.

Put the secondary filter cover in place on the side of the cylinder head and install the lock washers, flat washers, and two bolts holding the cover to the cylinder head, tightening the bolts with a  $\frac{9}{16}$ -inch open-end wrench.

**(2) INSTALL THE SECONDARY FUEL FILTER TO MANIFOLD TUBE (fig. 28).**

Wrench, open-end,  $\frac{5}{8}$ -in.

Install the secondary fuel filter to manifold tube in place and tighten the couplings with a  $\frac{5}{8}$ -inch open-end wrench.

**(3) INSTALL THE SHELL.**

Wrench, open-end,  $1\frac{1}{8}$ -in.

Using a new gasket, install the filter shell, using a  $1\frac{1}{8}$ -inch open-end wrench to tighten the nut and washer.

**(4) INSTALL THE SECONDARY FUEL FILTER TO FUEL PUMP TUBE.**

Wrench, open-end,  $\frac{5}{8}$ -in.

Install the secondary fuel filter to fuel pump tube, using a  $\frac{5}{8}$ -inch open-end wrench to tighten the couplings at both ends.

**(5) INSTALL THE CLIP (fig. 28).**

Wrench, open-end,  $\frac{9}{16}$ -in.

Remove the nut and lock washer from one of the bolts holding the blower drive assembly, using a  $\frac{9}{16}$ -inch open-end wrench to loosen the nut. Install the clip holding the filter to pump tube, reinstall the lock washer and nut, and tighten the nut.

**166. INSTALLATION OF THE CYLINDER HEAD VENT (fig. 33).**

**a. Equipment.**

Wrench, socket,  $\frac{7}{16}$ -in.

**b. Procedure.** Using two new gaskets, install the cylinder head vent, securing it to the cylinder head and the flywheel housing with the four bolts and lock washers and tightening the bolts with a  $\frac{7}{16}$ -inch socket wrench.

**167. INSTALLATION OF THE GOVERNOR CONTROL HOUSING ASSEMBLY.**

**a. Equipment.**

Screwdriver

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, open-end,  $\frac{3}{8}$ -in.

**ASSEMBLY OF THE ENGINE****h. Procedure.**

(1) **INSTALL THE GOVERNOR CONTROL HOUSING TO THE WEIGHT HOUSING** (figs. 25, 27, 35 and 36).

Wrench, socket,  $\frac{7}{16}$ -in.

Install the governor control housing and the gasket on the governor weight housing assembly dowel pins, with the operating shaft fork between the thrust bearing and the weight housing end bearing. **CAUTION:** Be sure that the fork contacts the outer race of the thrust bearing and does not contact the ball race. Then install a new weight housing cover gasket, cover, and the four lock washers and long bolts that hold the control housing to the weight housing assembly. Tighten the bolts with a  $\frac{7}{16}$ -inch socket wrench.

(2) **ATTACH THE CONTROL HOUSING TO THE CYLINDER HEAD** (fig. 36).

Wrench, open-end,  $\frac{7}{16}$ -in.

Install a new gasket and tighten the control housing to the cylinder head with the two bolts and lock washers. **NOTE:** With the governor in place, first tighten the control housing bolts securely to the head and the weight housing. Then tighten the bolts attaching the weight housing to the blower end cover.

(3) **INSTALL THE GOVERNOR CONTROL LINK** (fig. 35).

Remove the retainer spring and flat washer from the governor control pin differential lever, and install the link (fig. 35). Replace the flat washer and retainer spring or clip. Insert the governor control link in the clevis of the lever. Insert the lever pin and install cotter pins.

(4) **INSTALL THE GOVERNOR COVER AND LEVER ASSEMBLY.**

Screwdriver

Using a new gasket, install the governor cover and lever assembly over the dowel pins in the control housing. Using a screwdriver, install and tighten the four screws and lock washers holding the cover and lever assembly to the governor control housing. **NOTE:** On later models of the 6046 power plant, the position of the dowel pins is changed. If the cover and lever assembly does not fit on the dowel pins, remove and discard them.

(5) **POSITION THE GOVERNOR AND THE INJECTOR CONTROL RACKS** (fig. 138).

Screwdriver

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, open-end,  $\frac{3}{8}$ -in.

**NOTE:** See that all injectors are installed in the engines and that the operating lugs on the rack control levers are engaged with the slots in the injector racks.

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2  
RA PD 11304

NUT, LOW SPEED SPRING  
ADJUSTING SCREW

SCREW, LOW SPEED SPRING  
ADJUSTING



**Figure 138—Positioning Control Racks. Engine Cold**

(a) Back out the buffer spring screw until it projects approximately  $\frac{5}{8}$  inch from the governor housing.

(b) Remove the cover from the low speed spring adjusting screw. Loosen the lock nut from the low speed spring adjusting screw (fig. 138). Using a screwdriver, turn in the low speed spring screw until it projects approximately  $\frac{1}{8}$  inch from the lock nut.

(c) Loosen the screws on the injector and governor rack control lever assemblies (fig. 138).

(d) Set the throttle control lever in the idling notch. NOTE: Although figure 138 shows the control link lever pin removed, it should not be removed until indicated in a later step.

(e) Turn in the bolt nearest the injector on the rack control lever for number 1 cylinder until the rack assembly which projects from the injector is completely in and the control tube just begins to rotate. Tighten the other screw on the injector control tube lever firmly.

(f) Remove the control link lever pin and hold the control tube so that number 1 injector rack assembly remains in the full throttle position. Set the remaining injector racks to full throttle position and tighten the rack control lever screws. Particular attention must be given to this

## ASSEMBLY OF THE ENGINE

operation because it is important that each rack be completely in, without any of the other racks being moved away from "in" position. Insert the control link pin and install the cotter pins.

(g) Loosen the low speed spring screw to its approximate original position. Tighten the lock nut. Replace the cover, using a screwdriver to tighten the screws.

(h) When the power plant is installed in the vehicle, it may be found more convenient to position the racks as follows: Back out the buffer spring screw until it projects approximately  $\frac{5}{8}$  inch from the governor housing. Set the throttle lever in full fuel position. Loosen all rack control lever screws. Adjust the control lever for the number 1 cylinder as in (e) of this paragraph. Set all other control levers in a similar manner. The buffer screw can be reset when equalizing the injector with the engine running.

### (6) BALANCE THE INJECTORS.

(a) After positioning the injector racks (with subsequent assembly operations completed), if the engine does not idle smoothly to at least 140 F (jacket water) after warming up, the cause is probably improper injector balance, providing that the engine is in otherwise good running condition. If the engine idles smoothly when hot, no attempt should be made to balance the injectors. A good criterion of well-balanced injectors is a smooth running engine at idle speed and an even temperature of all exhaust manifold branches. If the manifold is cooler at one branch than on the others (either by feel or pyrometer), this cylinder is not doing its share of the work and should be adjusted for more fuel. After listening to and observing a smooth running engine and noting the temperature of each exhaust manifold branch with properly equalized injectors, one can quickly detect an engine body equalized by the "rough" running and the temperature of the various exhaust manifold branches. NOTE: Under no circumstances should the rack control levers be moved more than  $\frac{1}{4}$  turn of the adjustment screws. If one injector is adjusted too far out of line with the others, the full travel of all racks will be prevented and the maximum power of the engine reduced. A "heavy" injector is signified by a slight knocking noise, due to an excess of fuel, and should, therefore, be adjusted for a slightly smaller amount of fuel.

(b) To increase the amount of fuel injected, loosen the outer adjusting screw slightly and tighten the inner adjusting screw; the injector rack assembly must move inward (fig. 138).

(c) To decrease the amount of fuel injected, loosen the inner adjusting screw slightly and tighten the outer adjusting screw; the injector rack assembly must move outward.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**168. INSTALLATION OF THE WATER BYPASS TUBE**  
(figs. 23 and 34).

**a. Equipment.**

Wrench, open-end, 1½-in.

Wrench, socket, ⅞-in.

**b. Procedure.**

**(1) INSTALL UPPER ELBOW TO THE THERMOSTAT HOUSING.**

Wrench, socket, ⅞-in.

Using a new gasket, install the upper elbow to the thermostat housing, securing the gasket and elbow to the housing with the bolts and lock washers and tightening the bolts with a ⅞-inch socket wrench.

**(2) INSERT TUBE IN UPPER ELBOW.**

Install a new seal in the top of the water bypass tube and insert the tube in the upper elbow.

**(3) INSTALL TUBE TO THE OIL COOLER HOUSING.**

Wrench, socket, ⅞-in.

Using a new gasket, install the lower end of the tube to the oil cooler housing, securing the gasket and the tube to the housing with the two bolts and lock washers and tighten the bolts with a ⅞-inch socket wrench.

**(4) TIGHTEN THE NUT HOLDING THE TUBE TO THE UPPER ELBOW.**

Wrench, open-end, 1½-in.

Using a 1½-inch open-end wrench, tighten the nut on the upper elbow of the water bypass tube.

**(5) INSTALL THE WATER BYPASS TUBE CLIPS.**

Wrench, socket, ⅞-in.

Set the water bypass tube clips in place. Install the lock washers and bolts holding the clips to the block and tighten the bolts with a ⅞-inch socket wrench.

**169. REMOVAL OF THE ENGINE FROM THE ROTATING  
STAND.**

**a. Equipment.**

Hoist, chain

Wrench, open-end, 1½-in.

Wrench, open-end, ⅝-in.

**b. Procedure.**

**(1) ATTACH THE CHAIN HOIST TO ENGINE LIFTER BRACKETS**  
(figs. 28 and 33).

Hoist, chain

Attach the chain hoist to the engine lifter brackets.

**(2) DISCONNECT ENGINE FROM STAND.**

Wrench, open-end, ⅝-in.

Wrench, open-end, 1½-in.

Loosen the clamp locking nuts holding the engine in place. Remove

## ASSEMBLY OF THE ENGINE

the two bolts and washers at the bottom of the plate, using a  $\frac{5}{8}$ -inch open-end wrench to loosen the bolts. Turn the handles so that the brackets across the handhole cover openings are in a vertical position. This makes it possible to withdraw the brackets through the openings.

### (3) LIFT THE ENGINE FROM STAND.

Hoist, chain

Lift the engine from the rotating stand for additional operations.

## 170. INSTALLATION OF THE AIR HEATER ASSEMBLIES.

### a. Equipment.

Shellac

Wrench, socket,  $\frac{9}{16}$ -in.

### b. Procedure.

#### (1) INSTALL NEW GASKETS.

Shellac new gaskets to both air heaters and to the six remaining handhole covers, two of which are on the side of the engine opposite the air heaters.

#### (2) INSTALL AIR HEATERS.

Wrench, socket,  $\frac{9}{16}$ -in.

After the shellac on the gaskets has almost dried, install the washers, copper washers, and the bolts holding the two air heater assemblies to the cylinder block, tightening the bolts with a  $\frac{9}{16}$ -inch socket wrench. Install in the openings at the number 2 and number 5 cylinders.

## 171. INSTALLATION OF HANDHOLE COVERS (fig. 31).

### a. Equipment.

Wrench, open-end,  $\frac{9}{16}$ -in.

**b. Procedure.** Install the lock washers, copper washers and bolts holding the six handhole covers to the cylinder block, using a  $\frac{9}{16}$ -inch socket wrench to tighten the bolts.

## 172. INSTALLATION OF FUEL AND LUBRICATING OIL LINES, HIGH-TENSION LEADS, THREE-WAY TEE AND JUNCTION PLATES.

### a. Equipment.

Pliers

Wrench, open-end,  $\frac{5}{8}$ -in.

Screwdriver

Wrench, open-end,  $\frac{3}{4}$ -in.

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, open-end,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{5}{8}$ -in.

Wrench, open-end,  $\frac{9}{16}$ -in.

### b. Procedure.

#### (1) INSTALL THE UPPER JUNCTION PLATE (fig. 30).

Wrench, socket,  $\frac{9}{16}$ -in.

Remove the nuts and lock washers of the two through bolts at the



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

upper right-hand side of the rear end plate. Install the upper junction plate over the bolts, and install the lock washers and nuts.

**(2) INSTALL THE LOWER JUNCTION PLATE (fig. 31).**

Wrench, open-end,  $\frac{5}{8}$ -in.

Install the lower junction plate, the lock washers, and the two bolts holding the plate to the cylinder block, tightening the bolts with a  $\frac{5}{8}$ -inch open-end wrench.

**(3) INSTALL THE HIGH-TENSION LEADS TO AIR HEATER (fig. 31).**

Pliers

Wrench, socket,  $\frac{5}{8}$ -in.

Slip the grommet over the terminal of each high-tension lead. Attach the high-tension leads to the air heater porcelain insulators, tightening the knurled nuts with pliers. Install the lock washers, bolts and clips holding the leads to the cylinder block, using a  $\frac{5}{8}$ -inch socket wrench to tighten the bolts. Before installing the forward clip, insert the special clip and the three-way tee.

**(4) INSTALL THE FUEL PUMP INLET TUBE (UPPER JUNCTION PLATE TO FUEL PUMP) (fig. 30).**

Wrench, open-end,  $\frac{3}{4}$ -in.

Wrench, socket,  $\frac{5}{8}$ -in.

Connect the fuel pump inlet tube coupling at the upper junction plate and the coupling at the fuel pump, using a  $\frac{3}{4}$ -inch open-end wrench to tighten the couplings. Install the lock washers and bolts holding the two clips attaching the fuel pump inlet tube to the tachometer drive cover and stud assembly, tightening the bolts with a  $\frac{5}{8}$ -inch socket wrench.

**(5) INSTALL THE OIL PRESSURE GAGE TUBE AND LUBE OIL FILTER INLET TUBE (fig. 31).**

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

Wrench, open-end,  $\frac{9}{16}$ -in.

Connect the coupling of the oil pressure gage tube to the lower junction plate, tightening with a  $\frac{9}{16}$ -inch open-end wrench and a  $\frac{5}{8}$ -inch open-end wrench. Connect the coupling to the two-way tee elbow at the cylinder block, tightening with a  $\frac{7}{16}$ -inch open-end wrench. Connect the coupling of lube oil filter inlet tube to the upper junction plate, using a  $\frac{9}{16}$ -inch open-end wrench and a  $\frac{5}{8}$ -inch open-end wrench to tighten. Connect the lower coupling to the two-way tee elbow at the cylinder block, using a  $\frac{7}{16}$ -inch open-end wrench to tighten.

**(6) INSTALL THE LUBE OIL FILTER OUTLET TUBE (fig. 31).**

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

Install the coupling on the lube oil filter outlet tube to the elbow, tightening the coupling with a  $\frac{9}{16}$ -inch open-end wrench. Install the coupling on the upper end of the tube to the upper junction plate, using a  $\frac{9}{16}$ -inch open-end wrench and a  $\frac{5}{8}$ -inch open-end wrench to tighten.

## ASSEMBLY OF THE ENGINE

(7) INSTALL THE FUEL INLET TUBE (LOWER JUNCTION PLATE TO UPPER JUNCTION PLATE) (fig. 31).

Wrench, open-end  $\frac{9}{16}$ -in.

Wrench, open-end,  $\frac{5}{8}$ -in.

Install the couplings on the fuel inlet tube to the lower junction plate and the upper junction plate, tightening the coupling with a  $\frac{9}{16}$ -inch open-end wrench and a  $\frac{5}{8}$ -inch open-end wrench.

(8) INSTALL THE FUEL INLET TUBE (TEE TO LOWER JUNCTION PLATE) (fig. 31).

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, open-end,  $\frac{1}{2}$ -in.

Install the coupling to the three-way tee, using a  $\frac{7}{16}$ -inch open-end wrench to tighten the coupling. Using a  $\frac{9}{16}$ -inch open-end wrench to hold the bulkhead union, tighten the coupling to the union.

(9) INSTALL THE FUEL INLET TUBES (TEE TO HEATER) AND CLIPS (fig. 31).

Screwdriver

Wrench, open-end,  $\frac{7}{16}$ -in.

Slip the ends of the tubes through the grommets on the high-tension leads. Install the couplings at the air heaters and three-way tee, using a  $\frac{7}{16}$ -inch open-end wrench to tighten the couplings. Attach the bolts holding the clips to the air heater bodies, using a  $\frac{7}{16}$ -inch open-end wrench to tighten.

(10) INSTALL THE AIR HEATER COVERS (fig. 30).

Wrench, open-end,  $\frac{1}{2}$ -in.

Install the air heater covers, sliding the grommet into place in the slot and installing the two bolts and lock washers holding each cover to the air heater body. Tighten the bolts with a  $\frac{1}{2}$ -inch open-end wrench.

## 173. INSTALLATION OF THE GENERATOR ASSEMBLY.

### a. Equipment.

Wrenches, open-end,  $\frac{9}{16}$ -in., two

### b. Procedure.

(1) INSTALL GENERATOR (fig. 139).

The generator is installed on the LC engine, which has a long blower drive shaft. The procedure is as follows: Install the generator gasket. Install the generator drive gear on the splines of the blower drive shaft. Install the generator pilot in the flywheel housing at the blower drive gear with the generator driven gear meshing with the generator drive gear on the blower shaft (fig. 139).

(2) INSTALL AND TIGHTEN BOLTS.

Wrenches, open-end,  $\frac{9}{16}$ -in., two

Install the two short bolts and lock washers, holding the generator to the flywheel housing. Install the through bolt, holding the fuel pump drip shield and the generator to the flywheel housing. Install the three remain

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

ing through bolts. Using two  $\frac{9}{16}$ -inch open-end wrenches, tighten the four nuts and lock washers.

**174. INSTALLATION OF LA ENGINE ON TWIN ENGINE STAND.**

**a. Equipment.**

Hoist, chain

Wrench, socket,  $\frac{3}{4}$ -in.

Wrench, open-end,  $\frac{3}{4}$ -in.

**b. Procedure.**

**(1) MOVE ENGINE TO STAND (fig. 28).**

Hoist, chain

Using the chain hoist, move the engine to the proper side of the twin engine stand. Remove the chain hoist. **NOTE:** When the engine is moved to the stand, be sure to line up the faces of the flywheel housings. Bolts are provided on one side of the stand for alining the dowels in the housings.

**(2) INSTALL THE ENGINE TIE PLATE ASSEMBLY (fig. 23).**

Wrench, open-end,  $\frac{3}{4}$ -in.

Wrench, socket,  $\frac{3}{4}$ -in.

Install the lock washers, bolts and nuts that fasten the engine tie plate to the balance weight covers at the rear of both engines, using a  $\frac{3}{4}$ -inch open-end wrench and  $\frac{3}{4}$ -inch socket wrench to tighten the bolts.

**175. INSTALLATION OF THE OIL COOLER WATER DRAIN  
VALVE ASSEMBLY.**

**a. Equipment.**

Pliers

Wrench, pipe

Wrench, open-end,  $\frac{7}{16}$ -in.

**b. Procedure.**

**(1) INSTALL ELBOW.**

Wrench, pipe

Using a pipe wrench, install the elbow and universal joint at the bottom of the oil cooler housing.

**(2) INSTALL ROD AND HANDLE.**

Wrench, open-end,  $\frac{7}{16}$ -in.

Install the rod and handle, using a  $\frac{7}{16}$ -inch open-end wrench to tighten the two bolts which hold the supporting bracket to the governor weight housing cover.

**(3) TIGHTEN THE CONNECTION AT THE UNIVERSAL JOINT.**

Pliers

Tighten the packing gland nut and install the cotter pin.

**176. INSTALLATION OF THE SIX AIR CLEANER ASSEMBLIES  
(fig. 27).**

Examine all air cleaner gaskets for breaks and proper seal. Remove

## ASSEMBLY OF THE ENGINE

the covers and elements and set the air cleaner assemblies in place. Replace the elements and covers and tighten the wing bolts holding the air cleaners to the air inlet housings. Do not fill the air cleaners until after the power plant has been installed. The oil level should not be above that indicated, which is just flush with the top of the reservoir itself. If too much oil is used, it will be pulled up into the metal wool, down into the blower, and thence into the air box, which may cause excessive engine speeds. Do not use a detergent or inhibited heavy-duty Diesel oils in the air cleaner, as they may foam and pull over.

### 177. INSTALLATION OF THE FAN AND RELATED PARTS (figs. 23, 24, 25 and 26).

#### a. Equipment.

Screwdriver, short or offset

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, open-end,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{3}{4}$ -in.

#### b. Procedure.

##### (1) INSTALL THE FAN SHAFT (fig. 26).

Wrench, open-end,  $\frac{9}{16}$ -in.

Install the fan shaft with the plate and hub assembly, bearing and oil seal retainer, gear and spacers into the fan tower and onto the studs, sliding the driven gear into mesh with the idler gear. Install the governor lever retracting spring clip on the stud indicated (fig. 26) and tighten the five nuts and lock washers with a  $\frac{9}{16}$ -inch open-end wrench.

##### (2) INSTALL FAN ASSEMBLY ON THE SHAFT (figs. 24 and 25).

Wrench, open-end,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{3}{4}$ -in.

Oil the fan shaft, then slide the fan assembly on the shaft, with the studs through the holes in the plate and hub assembly. Install the six lock washers and nuts holding the fan assembly to the hub, tightening with a  $\frac{1}{2}$ -inch open-end wrench (fig. 25). Install the lock washer, flat washer, and bolt on the rear end of the shaft, using a  $\frac{3}{4}$ -inch socket wrench to tighten the bolt (fig. 24).

##### (3) INSTALL FAN HUB COVER (fig. 23).

Screwdriver, short or offset

Put the fan cover in place and install the four fillister-head bolts, tightening them with a short or offset screwdriver (fig. 23). Hook up the governor lever retracting spring to the clip (fig. 25).

### 178. INSTALLATION OF THE CLUTCH HOUSING ASSEMBLY.

#### a. Equipment.

Cord

Wrench, open-end,  $\frac{5}{8}$ -in.

Hammer

Wrenches, open-end,  $\frac{7}{8}$ -in., two

Handle, socket,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 139—Front View of Power Plant with Clutch Housing Removed

## ASSEMBLY OF THE ENGINE

### b. Procedure.

#### (1) INSTALL CLUTCH HOUSING IN PLACE (figs. 21, 22 and 139).

Cord

Wrench, socket,  $\frac{9}{16}$ -in.

Tie a cord to each clutch release bearing hose, drawing the ends up through the clutch housing inspection holes. Install the clutch housing in place over the dowel pins on the flywheel housings, centering the clutch shifter yokes on the clutch release bearing assembly sleeve bushings. Install the bolts and lock washers that are reached through the plug holes, tightening with a  $\frac{9}{16}$ -inch socket wrench, pulling the clutch housing onto the flywheel housings. Install the remaining bolts and lock washers holding the clutch housing to the flywheel housings, using a  $\frac{9}{16}$ -inch socket wrench to tighten the bolts.

#### (2) INSTALL NEW GASKETS ON INSPECTION HOLES.

Wrenches, open-end,  $\frac{7}{8}$ -in., two

Install new gaskets on the clutch housing inspection holes. Install the lubrication fitting through the inspection hole cover, tightening with two  $\frac{7}{8}$ -inch open-end wrenches. Install and tighten the bolts holding the cover to the housing with a  $\frac{7}{8}$ -inch open-end wrench (fig. 21).

#### (3) INSTALL THE FIVE PIPE PLUGS (fig. 20).

Handle, socket,  $\frac{1}{2}$ -in.

Install the five plugs that give access to the inside clutch housing bolts, using a  $\frac{1}{2}$ -inch drive socket handle to tighten.

#### (4) INSTALL THE CLUTCH SHIFTER LEVERS (fig. 20).

Hammer

Wrench, open-end,  $\frac{5}{8}$ -in.

Using a soft hammer, drive the shifter levers onto the shifter shafts in the position shown (fig. 20). Install the two bolts holding the clutch shifter levers in place, using a  $\frac{5}{8}$ -inch open-end wrench to tighten.

## 179. INSTALLATION OF THE ENGINE TRANSFER GEAR HOUSING.

### a. Equipment.

Screwdriver

Wrench, plug,  $\frac{1}{2}$ -in.

Wrench, open-end,  $\frac{7}{8}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, pipe

Wrench, socket,  $2\frac{3}{4}$ -in.

### b. Procedure.

#### (1) INSTALL ENGINE TRANSFER GEAR HOUSING IN PLACE (fig. 19).

Wrench, socket,  $\frac{9}{16}$ -in.

Install the engine transfer gear housing in place over the dowel pins on the clutch housing. Install the lock washers and 24 bolts holding the engine transfer gear housing to the clutch housing, tightening the bolts with a  $\frac{9}{16}$ -inch socket wrench.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2****(2) TIGHTEN THE ENGINE DRIVE SHAFT AND ENGINE DRIVEN  
SHAFT NUTS (fig. 18).**

Screwdriver

Wrench, socket, 2 $\frac{3}{4}$ -in.Wrench, socket,  $\frac{9}{16}$ -in.

Remove the four bolts and lock washers temporarily holding the two engine drive shaft covers, loosening the bolts with a  $\frac{9}{16}$ -inch wrench. Remove the covers. Place a screwdriver through the flywheel inspection hole to keep the flywheel from turning. Tighten the two special engine drive shaft nuts and the engine driven shaft special nut holding the yoke flange on the shaft. Install the twelve bolts and lock washers holding the two engine drive shaft covers to the housing, tightening the bolts with a  $\frac{9}{16}$ -inch wrench.

**(3) INSTALL THE FLYWHEEL HOUSING INSPECTION HOLE COVERS  
(fig. 17).**Wrench, open-end,  $\frac{7}{16}$ -in.

Install the four bolts and lock washers holding the two flywheel housing inspection hole covers to the housing, using a  $\frac{7}{16}$ -inch open-end wrench to tighten the bolts.

**(4) INSTALL THE TWO PLUGS AND TWO ELBOWS ON ENGINE TRANS-  
FER GEAR HOUSING (fig. 15).**

Wrench, pipe

Wrench, plug,  $\frac{1}{2}$ -in.

Install the two elbows, tightening with a pipe wrench. Install the four oil plugs, tightening with a  $\frac{1}{2}$ -inch plug wrench.

**180. TIMING THE ENGINE.****a. Equipment.**

Tool, KM-J-1929

**b. Procedure.**

Before the assembled engines are installed in the vehicle, the timing of the engine should be checked as follows:


(1) The number 5 injectors of both engines must be correctly timed.

(2) Remove the number 1 injector and install the engine timing fixture in its place, using tool KM-J-1929. Use the injector clamp to hold the fixture in place (fig. 140).

(3) Push the timing rod down against the piston head.

(4) Hand crank the engine in the direction of rotation until the timing rod no longer moves upward. Hand crank the engine at least one-fourth of a revolution more to make sure timing dead center has been passed. Do not touch the timing rod. It must stay in the timing dead center position until step 5 is completed.

ASSEMBLY OF THE ENGINE



RA PD 11326

*Figure 140—Timing the Engine*



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

(5) Adjust the compensation screw to correspond with the timing mark on the timing rod. This adjustment is made to compensate for any variation in head thickness, gasket thickness, carbon or piston head, etc.

(6) Hand-crank the engine in the direction of rotation until the timing rod can be pushed all of the way down against the stop nut on the upper end of the rod.

(7) Hand-crank in the direction of rotation until the upper mark on the timing rod is flush with the face of the compensating screw. This position of the rod will be as illustrated.

(8) Try the GO — NO GO gage between the injector timing pin and the face of the follower guide (fig. 140). This operation is performed at number 5 injectors for both engines.

(9) If the GO side of the gage will go and the NO GO side of the gage will not go, engine timing is correct.

(a) If both GO and NO GO sides of the gage will go, the engine is timed fast.

(b) If neither GO nor NO GO side of the gage will go, the engine timing is late or slow.

## Section VIII

# AIR INLET HOUSING AND BLOWER ASSEMBLIES

	Paragraph
Inspection while on engine .....	181
Trouble shooting .....	182
Removal from engine .....	183
Disassembly of the air inlet housing assembly .....	184
Disassembly of the blower assembly, including accessories .....	185
Inspection of the air inlet housing and blower assemblies .....	186
Overhaul of the air inlet housing and blower assemblies .....	187
Assembly of the blower assembly .....	188
Assembly of the air inlet housing assembly .....	189
Preinstallation inspection .....	190
Installation on engine .....	191

## 181. INSPECTION WHILE ON ENGINE.

a. Proper functioning of the blower is necessary for efficient operation of the Diesel engine. Therefore, it is recommended that the blower be inspected at intervals of 1,000 engine hours or 20,000 miles. If the engine assembly is removed from the tank, the blower can be inspected without removal from the engine. Otherwise, the blower and air inlet housing assemblies should be removed from the engine in order to make a thorough inspection.

b. After removing the air cleaners, inspection without disassembly can be done as follows:

(1) Check the operation of the air shut-down valve which is attached to the air inlet housing. Flap valves should close tightly against the striker plate gasket which is next to the air inlet housing, between the housing and the blower, when the air inlet housing is attached to the blower. If the valves do not close tightly, disassemble and inspect (pars. 185 and 186).

(2) Remove the air inlet housing from the blower as outlined in paragraph 183, and inspect the air inlet housing for cracks and to see that it is not obstructed.

(3) Inspect the blower for dirt or chips which might be drawn through the blower to make deep scratches in the rotors and housing and throw up burs around such abrasions. If such conditions cause interference between the rotors or between the rotors and housing, the blower should be removed from the engine and the parts dressed down, or rotors changed, if too badly scored.

(4) Check for leaky oil seals by looking for oil on the blower rotors or the inside of the housing. Oil on rotors sometimes results from pull-

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

over from overfilled air cleaners, however, and the two conditions should not be confused. An oil seal leak can be detected by directing a strong light into the rotor compartment and looking for a thin film of oil which will radiate away from a leaky oil seal.

(5) Check for a worn blower drive. Grasp the top rotor firmly and attempt to rotate it. Rotors should move with a springing action from  $\frac{3}{8}$  to  $\frac{5}{8}$  inch, measured at the lobe crown. When released, rotors should move back at least  $\frac{1}{4}$  inch. If rotors cannot be moved in this manner, if rotors move too freely, or if they can be rattled, the blower flexible drive coupling should be inspected. If inspection shows the drive coupling to be worn, the blower drive gear assembly can be withdrawn from the front of the cylinder block end plate after the blower has been removed from the engine and the drive gear housing-to-cylinder block end plate bolts have been removed.

(6) Check for loose rotor shafts or damaged bearings, as indicated by rubbing and scoring between crowns of the rotor lobes and mating rotor roots, between rotors and end plates, or between rotors and housing. Generally, a combination of these conditions exists.

(a) A loose shaft usually causes rubbing between rotors and end plates.

(b) Worn or damaged bearings will cause rubbing between mating rotor lobes at some point, or, perhaps, allow rotor assemblies to rub the blower housing. This condition is usually indicated at the end of rotors at which bearings have failed.

(c) Excessive backlash in blower timing gears usually results in rotor lobes rubbing throughout their entire length.

(7) To correct any of the conditions cited in (3), (4), (5) and (6) of this paragraph, the blower must be removed from the engine and overhauled or replaced (pars. 183 and 187).

**182. TROUBLE SHOOTING.**

A blower may fail to function properly because of any one of the following reasons or a combination of them:

a. Dirt or foreign matter, having been drawn through the blower, scores the rotor lobes and the housing.

b. Worn oil seals permit lubricating oil to be drawn into the rotor compartment.

c. Loose rotor shafts, worn gear teeth, or damaged bearings cause contact between rotor lobes, rotors, and end plates, and between rotors and the housing.

## AIR INLET HOUSING AND BLOWER ASSEMBLIES

d. When the blower is out of time because of timing gear wear, the mating rotor lobes may not have adequate clearance at one side and too much clearance on the opposite side.

e. The blower can be inspected for these conditions without removing it from the engine, providing the engine assembly is removed from the tank. For inspection procedure consult paragraph 181.

### 183. REMOVAL FROM ENGINE.

a. To remove the blower assembly and air inlet housing assembly from the engine when the engine is installed in the tank, follow the procedure outlined in TM 9-753 and TM 9-758.

b. To remove the air inlet housing and blower assemblies from the engine after the engine assembly has been removed from the tank, consult paragraph 56, which covers the removal of the two assemblies as a unit. To remove the air inlet housing assembly from the blower assembly, proceed as follows:

(1) Using a  $\frac{9}{16}$ -inch combination box and open-end wrench, unscrew the six bolts and lock washers which hold the air inlet housing to the blower housing.

(2) Remove the air inlet housing with the gasket, striker plate, and the combination screen and gasket.

### 184. DISASSEMBLY OF THE AIR INLET HOUSING ASSEMBLY.

#### a. Equipment.

Screwdriver

Wrench, socket,  $\frac{7}{16}$ -in.

#### b. Procedure (figs. 49 and 141).

If the air shut-down valves function properly, it is ordinarily unnecessary to disassemble the air inlet housing, unless outside damage results in a broken part. To disassemble, proceed as follows:

(1) Remove the cotter pin (22, fig. 141) holding the clevis pin (21) in the solenoid rod end clevis (24). Remove the clevis pin (21).

(2) Using a  $\frac{7}{16}$ -inch socket wrench, loosen the two bolts (1) and lock washers (2) holding the solenoid assembly (3) to the air inlet assembly housing (4), and remove the bolts (1) and the lock washers (2).

(3) Using a screwdriver, loosen the two fillister-head bolts (16) holding the air shut-down lock plate (19) to the air inlet housing (4), and remove the bolts (16), lock washers (17), and the one flat washer (23).

(4) Drive out the air shut-down valve lever pin (15).

(5) Remove the air shut-down valve lever (14), the air shut-down

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2

RA PD 11311



Figure 141—Component and Related Parts of the Air Inlet Housing

**AIR INLET HOUSING AND BLOWER ASSEMBLIES**

- |   |   |              |
|---|---|--------------|
| 1—Bolt, Solenoid to Housing               | 15—Pin, Air Shut-Down Valve Lever                   | RA PD 11311A |
| 2—Washer, Lock                            | 16—Bolt, Fillister-Head, Lock Plate to Housing      |              |
| 3—Solenoid                                | 17—Washer, Lock                                     |              |
| 4—Housing, Air Inlet (Model LA24M Engine) | 18—Spring, Air Shut-Down Valve (Model LA24M Engine) |              |
| 5—Pin, Cotter, Shaft Retaining            | 19—Plate, Air Shut-Down Valve Lock                  |              |
| 6—Washer, Flat, Shaft Retaining           | 20—Washer, Felt Seal, Ends of Shaft                 |              |
| 7—Washer, Felt Seal, Ends of Shaft        | 21—Pin, Clevis                                      |              |
| 8—Shaft, Valve Control                    | 22—Pin, Cotter                                      |              |
| 9—Valve, Air Shut-Down                    | 23—Washer, Flat, Spring to Lock Plate               |              |
| 10—Pin, Groove, Valve to Shaft            | 24—Clevis, Solenoid Rod End                         |              |
| 11—Gasket, Striker Plate                  | 25—Nut, Lock, Solenoid to Lever                     |              |
| 12—Plate, Striker                         | 26—Tube, Air Cleaner Mounting                       |              |
| 13—Screen and Gasket, Air Inlet Housing   |   |              |
| 14—Lever, Air Shut-Down Valve             |   |              |

**Nomenclature for Figure 141 —Component and Related Parts of the Air Inlet Housing**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

valve spring (18), the air shut-down lock plate (19), and the felt seal washer (20).

(6) Remove the cotter pin (5), the flat washer (6) and the felt seal washer (7) from the other end of the shaft (8).

(7) Drive out the four straight pins (10) holding the two air shut-down valves (9) to the valve control shaft (8).

(8) Pull out the shaft (8).

**185. DISASSEMBLY OF THE BLOWER ASSEMBLY, INCLUDING  
ACCESSORIES.****a. Equipment.**

Hammer, soft

Wrench, open-end, 1/2-in.

Screwdriver

Wrench, socket, 7/16-in.

Tool KM-J-1682-C (set)

Wrench, socket, 1/2-in.

Tool KM-J-1699

Wrench, socket, 3/4-in.

**b. Procedure** (figs. 49, 142, 143, 144, 145, 146, 147, 148 and 149). Completely disassemble the blower assembly according to the following steps:

(1) Remove the remaining bolts and lock washers from the fuel pump.

(2) Remove the fuel pump gasket.

(3) Using a 1/2-inch socket wrench, remove the six bolts (31, fig. 142) and lock washers (30) holding the blower drive cover (32) to the blower assembly. Remove the blower drive cover and cover gasket (29).

(4) Using a 1/2-inch socket wrench, remove the 20 bolts (21) and lock washers holding the blower end covers to the end plates and the blower housing (15). **NOTE:** Use a soft hammer (if necessary) striking on the sides of the bosses, and loosen the covers from the end plates. Do not use a screwdriver for prying or the part may be damaged. Remove the covers and the gaskets.


(5) Lock the rotors with a rag. Then, using tool KM-J-1699, loosen the Allen screw in the water pump shaft and coupling assembly (fig. 143).

(6) Remove the water pump shaft and coupling assembly (5, fig. 142) (5) from the blower rotor and coupling (17).

(7) Using a 1/2-inch socket wrench, remove the 6 bolts and lock washers holding the blower rotor gear hub (26, fig. 144) to the blower rotor gear.

(8) Turn down the teeth on the external tooth lock washers (24, fig. 145) which lock both the bolts on the rear end of the blower rotor shafts.

# AIR INLET HOUSING AND BLOWER ASSEMBLIES




1. BOLT, BLOWER END PLATE COVER
2. WASHER, LOCK
3. COVER, BLOWER END PLATE
4. GASKET, BLOWER END PLATE COVER
5. SHAFT AND COUPLING, WATER PUMP; ASSEMBLY
6. BOLT, BLOWER BEARING RETAINER
7. WASHER, LOCK
8. RETAINER, BLOWER REAR BEARING
9. BEARING, BLOWER REAR
10. SCREW, MACHINE, BLOWER END PLATE TO HOUSING
11. PLATE, BLOWER END
12. SEAL, BLOWER END PLATE OIL
13. BOLT, BLOWER HOUSING TO BLOCK
14. GASKET, BLOWER HOUSING TO BLOCK
15. HOUSING, BLOWER
16. ROTOR AND RETAINER, UPPER—R.H. HELIX; ASSEMBLY
17. ROTOR AND COUPLING, LOWER—L.H. HELIX; ASSEMBLY
18. BEARING, BLOWER FRONT THRUST
19. RETAINER, BLOWER FRONT THRUST BEARING
20. { SHIM, BLOWER ROTOR GEARS — .002" THICK  
SHIM, BLOWER ROTOR GEARS — .003" THICK  
SHIM, BLOWER ROTOR GEARS — .005" THICK  
SHIM, BLOWER ROTOR GEARS — .010" THICK
21. GEAR SET, BLOWER ROTOR (INCLUDES R. H. HELIX AND L. H. HELIX GEAR — SERVICED ONLY IN MATCHED SETS)
22. WASHER, BLOWER ROTOR GEAR RETAINING — USED ON UPPER ROTOR ONLY
23. DISC, BLOWER ROTOR GEAR COUPLING — USED ON LOWER ROTOR ONLY
24. WASHER, LOCK, EXTERNAL TOOTH
25. BOLT, BLOWER ROTOR GEAR
26. HUB, BLOWER ROTOR GEAR
27. WASHER, LOCK
28. BOLT, BLOWER ROTOR GEAR HUB
29. GASKET, BLOWER DRIVE COVER
30. WASHER, LOCK
31. BOLT, BLOWER DRIVE COVER
32. COVER, BLOWER DRIVE

RA PD 11489


Figure 142—Component Parts of Blower Assembly



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**




**Figure 143—Removing Water Pump Shaft and Coupling Assembly**



**Figure 144—Removing Blower Rotor Gear Hub**

**AIR INLET HOUSING AND BLOWER ASSEMBLIES**  
WASHER, LOCK, EXTERNAL TOOTH



BOLT,  
ROTOR GEAR RA PD 11298

**Figure 145—Blower Rotor Gear Assembly Partly Disassembled**

(9) Using a  $\frac{3}{4}$ -inch socket wrench, remove the bolts locking the gears to the shafts.

(10) Remove the external tooth lock washer and the gear retaining washer from the upper rotor shaft, and remove the external tooth lock washer and the coupling disk from the lower rotor shaft.

(11) Using a  $\frac{1}{2}$ -inch socket wrench, attach the gear pullers in the rotor blower service set KM-J-1682-C to the rotor blower gears, by attaching the bolts through the two opposite holes in each puller to the gears (fig. 146). Using a  $\frac{3}{4}$ -inch socket wrench, pull off both gears at the same time by alternately turning the center puller bolts one or two turns while holding the rotors and keeping them from turning. The gears must be removed together because the helix angles of the gears and the rotors are not the same.

(12) Remove the shims (if any) between the gears and the bearings. Note whether the shims are at the upper or lower rotor and also their thickness.

(13) Using a  $\frac{7}{8}$ -inch socket wrench, remove the six bolts and lock washers holding the bearing retainers on each blower end plate. Remove the two retainers from each end plate.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



**RA PD 11313**

***Figure 146—Pulling Blower Rotor Gears***

(14) Loosen the two fillister-head bolts on the front end. Remove the two fillister-head bolts holding the end plate to the blower housing or the gear end.


(15) Using a 1/2-inch socket wrench, remove the pullers from the gears. Remove the four short bolts from the pullers and install the six long bolts in the three equally spaced holes in each puller. Attach both pullers to the blower end rear plate and pull off the plate by alternately turning the center bolts a few turns at a time, using a 3/4-inch socket wrench (fig. 148). **NOTE:** Do not pry off the end plate from the housing with a screwdriver or the sealing surfaces may be damaged.

(16) Remove the two pullers and attach them to the opposite end plate. Repeat the previous step, pushing the rotor shaft out of the bearings.

(17) Lift out the rotors. Remove the two fillister-head bolts and the end plate from the housing.


(18) Using the driver from the rotor blower service set KM-J-1682-C, drive out the two bearings and oil seals from both blower end plates (fig. 149).

**AIR INLET HOUSING AND BLOWER ASSEMBLIES**  
**SCREW, MACHINE, END PLATE**



RETAINER, BLOWER FRONT BEARING      BOLT, BEARING RETAINER      RA PD 11296


**Figure 147—Blower End Plate, Showing Blower Front Bearing Retainers**



RA PD 11314

**Figure 148—Removing Blower End Plate**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



**Figure 149—Removing Blower End Plate Bearings and Seals**

**186. INSPECTION OF THE AIR INLET HOUSING AND BLOWER  
ASSEMBLIES.**

When these assemblies are disassembled, parts should be inspected as follows:

a. Wash all parts thoroughly in fuel oil and blow off with compressed air. Then remove all traces of old gaskets.

b. Make the following inspection of the air inlet housing assembly:

(1) See that the striker plate of the air inlet housing assembly is perfectly flat and that the gasket on the plate for the shut-down valve is in good condition.

(2) Inspect the finished face of the valve. It must be perfectly flat for a tight seal against the gasket.

(3) If felt seal washers on the valve shaft do not form a tight fit on the shaft, they should be replaced.

c. Make the following inspection of the blower assembly:

(1) Inspect the blower housing for score marks on the inside. Slight score marks may be removed with a scraper or fine sandpaper, but a badly scored housing should be replaced.

(2) Inspect the rotors for score marks or evidence of rubbing and

## AIR INLET HOUSING AND BLOWER ASSEMBLIES

check the rotor shafts at the bearing seal contacts for wear or score marks. Shafts should be inspected for tightness in the rotors by tapping them lightly with a soft hammer.

(3) Replace any rotor with a loose shaft, or one which shows excessive scoring or wear. To insure a tight fit at the oil seal, rotors should be replaced if the shaft at the seal contact shows ridges and cannot be reconditioned.

(4) Inspect the end plates for smoothness on the inside faces and examine the bearing bores for any trace of wear.


(5) Examine the bearings for smoothness and wear, and evidence of overheating.

(6) Examine the teeth of the blower rotor gears for chipping or wear. Inspect the inside serrations for wear.

(7) Inspect the inside serrations of the blower rotor gear hub for wear.

### 187. OVERHAUL OF THE AIR INLET HOUSING AND BLOWER ASSEMBLIES.

All disassembled parts should be washed and cleaned, as outlined in paragraph 186. All parts which, in the inspection procedure, have been found to be defective (par. 186) should be replaced.



**Figure 150—Installing Blower End Plate Oil Seal**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2****188. ASSEMBLY OF THE BLOWER ASSEMBLY.****a. Equipment.**

Gage, feeler	Tool KM-J-1699
Hammer, rawhide	Wrench, socket, 1/2-in.
Shellac	Wrench, socket, 3/4-in.
Tool KM-J-1682-C (set)	Wrench, tension

**b. Procedure (figs. 142, 150, 151, 152, 153, 155, 156 and 157).**

(1) Pull new oil saturated oil seals into the blower end plates as shown in figure 150, using one of the gear pullers and a slotted washer from the rotor blower service tool set KM-J-1682-C. Tighten the puller bolt with a 3/4-inch socket wrench. The edge of the seal must not be above the flat surface of the plate. The leather edge of the seal must face away from the rotors. **NOTE:** Before the seals are installed, they should be immersed in light oil for approximately 30 minutes to soften the leather and saturate the seal.

(2) Install the blower rear end plate. The top of the blower may be identified by the flange which carries the entire length of the housing and provides a rest on top of the cylinder block. The end plate is semi-circular at the top, and is also marked TOP on the outer ribbed side. Even though the blower end plate is interchangeable, front and rear, the plate at the rear end of the blower should be assembled to the blower housing first. The front end plate should be assembled after the rotors are in place. When viewing the blower housing from the cylinder block side, the end plate for the rear will be assembled to the right-hand end of the blower housing for the LA engine, and to the left-hand end of the blower housing for the LC engine. With these identifications clearly in mind, attach the end plate to the rear end of the blower housing, as follows:

(a) Start the end plate dowels in the dowel holes of the blower housing. Tap the dowels and the end plate lightly with a rawhide hammer to fit the end plate to the housing. Note that no gaskets are used between the end plates and the housing; therefore, mating surfaces must be perfectly flat and smooth.

(b) Lock the end plate securely to the housing with two fillister-head screws. No lock washers are used.

(c) Inspect to see that the dowels project 3/8 inch beyond the outer face of the end plate.

(3) Before further assembly of the blower, certain checking operations are necessary to insure the proper relation of parts. The lobes on one of the blower rotors and the teeth on one of the timing gears form a right-hand helix and on the mating parts a left-hand helix. The rotor

**AIR INLET HOUSING AND BLOWER ASSEMBLIES**

with the right-hand helix must be used with gear having right-hand helical teeth and vice versa.

(a) Rotor and gear with right-hand helices are the upper units in the blower; the parts with left-hand helices are the lower units. Furthermore, for convenience in blower timing, one serration is omitted on the drive end of each blower shaft with corresponding omissions in the gear bushing. Gears must be placed on the shafts with the serrations in registration. Rotors must be assembled with the omitted serrations toward the top on both rotor shafts, as shown in figure 151.


(b) To avoid confusion when assembling, place the right-hand rotor and the right-hand gear together on the bench, as shown in figure 151; do the same thing with the left-hand rotor and gear.

(4) Assemble the blower rotors into the housing front end plate, using oil seal pilots from tool set KM-J-1682-C, with checks in mind, as outlined in (3) of this paragraph.

(a) Install one oil seal pilot over the short end (non-splined) of each rotor shaft, as shown in figure 152, and with rotors in mesh and omitted serrations toward the top of the blower housing, slip the rotors into the housing.

(b) Remove the oil seal pilots.

(5) Install the blower rear end plate, with oil seal pilots from tool



**Figure 151 — Lining Up Timing Marks on Blower Rotors**



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

set KM-J-1682-C, with rotors positioned in the housing as outlined in (4) of this paragraph.

(a) Install one oil seal pilot over the serrated end of each rotor shaft.

(b) Identify the top and bottom of the end plate, as described in (2) of this paragraph, and start the end plate dowels into the dowel holes in the blower housing. Tap dowels lightly to fit end plate to housing.

(c) Lock the end plates securely to the housing with two fillister-head screws. Do not use lock washers.


(d) Inspect and see that dowels project  $\frac{3}{8}$  inch beyond the outer face of the end plate to accommodate the end cover.

(e) Remove the oil seal pilots.

(6) Install the blower rotor shaft front bearings into the end plate with the bearing assembly tool from tool set KM-J-1682-C, as shown in figure 153 for installation of rear bearings. Single-row ball bearings are used at the front end of the blower rotor shafts and double-row ball bearings at the rear (serrated) end. The bearing number is stamped at one end of the ball race only. When assembled, the markings are toward the outside face of the end plate. With these identifications in mind:

(a) Start the single row bearings onto the front end of the rotor shafts (short end with internal splines).

TOOL, PART OF KM-J-1682-C



RA PD 11318

**Figure 152—Pilot Tools Installed Over Rotor Shaft Serrations**

**AIR INLET HOUSING AND BLOWER ASSEMBLIES**


(b) Using tool KM-J-1682-C, as shown in figure 153 tap the bearings into the end plates. **NOTE:** Bearing retainers for single-row (front) bearings have a  $1\frac{1}{8}$ -inch inside diameter; those for double-row (rear) bearings have a  $1\frac{9}{16}$ -inch inside diameter.

(c) Install front bearing retainers with the flange at the inner diameter of the retainer directed toward the bearing. Lock each retainer with three bolts and lock washers.

(7) Install rotor shaft rear bearings exactly the same way the fronts were installed and using the same tool, except that the flange at the inner diameter of the retainer is directed away from the bearing. Be sure that markings on the bearing race are toward the blower end cover. Use only bearing No. 954307 at these positions.

(8) Rotor to housing and rotor to end plate clearances may be checked at this time, as described in (10), below.

(9) Press the blower timing gears onto the rotor shafts with rotor gear assembly tools from tool set KM-J-1682-C. If a used blower once used is being reassembled, shims were no doubt used back of one or perhaps both blower timing gears, and therefore, they should be installed in their original positions before pressing the gears onto the shafts. If new gears and rotors are used, install them without shims, and use shims later, if necessary, when timing rotors. Be sure that both rotor



**Figure 153—Installing Blower Front Thrust Bearings**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

shafts with the timing marks, as shown in figure 151, point toward top of blower; that the drive gear (timing gear) with six tapped holes in the hub is located on the upper rotor shaft; and that the original shims are placed on their respective shafts. Then start both gears onto shafts with omitted serrations on shafts and gears registering. A center punch mark is indented into the end of the shaft at omitted serration to assist in locating gears properly. Apply engine oil at shaft serrations and proceed to press the gears onto the shafts with tool, as follows:

(a) Using timing gear retainer bolts and washers to hold the gears onto the upper and lower shafts, respectively, install bolts and washers into the ends of the shafts, and press the gears uniformly into position tight against the bearing races.

(b) Remove the retaining bolts from the center of the shafts, which were used to pull the gears into place, and install a special lock washer next to the head of each retainer bolt. Be sure that the retainer washer at the upper gear has pierced the lugs to engage the slots in the gear hub. The ears of the lock washer will then engage the slots in the retaining washer. Draw the retaining bolt tight.

(c) For the lower gear lock, install the special lock washer and fuel pump coupling disk on the retainer bolt so that the lock tangs of the disk engage the slot in the gear hub, and the lock washer ear engages the slot in the coupling disk. Then draw the retainer bolt tight, but not tight enough to bend the fuel pump coupling disk.

(10) Check the lash in the blower gear set. These gears normally have a zero to 0.0005-inch lash. If a noticeable lash is apparent, check the amount with a feeler gage. Worn tolerance should not exceed 0.004-inch.

(11) Before checking the blower rotor clearances, refer to the chart in figure 154. Using a feeler gage, check the thrust clearance between the rotors and the rear of the blower end plate. See dimension A in figure 154.

(12) Using a feeler gage, check the end clearance between the rotors and the front of the blower end plate. See dimension B in figure 154. **NOTE:** End clearances are established by manufacturing tolerances and cannot be adjusted. They will remain constant unless the blower is damaged in disassembly or assembly, or unless thrust bearings become worn.

(13) Before checking the rotor to the rotor clearances, consult figures 154, 155, and 156. In figure 154 the leading edge refers to the edge which is in advance according to the rotation, while the trailing edge follows the leading edge. Because the upper and lower rotors turn in opposite directions, a leading edge of the lower rotor is always adjacent to a trailing edge of the upper rotor, and clearance is measured between a leading and a trailing edge.

**AIR INLET HOUSING AND BLOWER ASSEMBLIES**

(14) Insert a feeler gage through the air outlet side of the blower, and between the leading edge of the lower rotor and the trailing edge of the upper rotor, as shown in figure 156. See figure 154, dimension CC, for tolerance. Rotate the rotors sufficiently to check the clearance at several points along the full length of the rotors.

(15) Rotate the rotors approximately one-sixth of a turn, which will bring the trailing edge of the lower rotor and the leading edge of the upper rotor together. Using a feeler gage, check the clearance. See figure 154, dimension C, for tolerance.

(16) Repeat the operation to check dimensions CC and C for all leading and trailing edge clearances; this makes a total of six operations to completely check the rotor to the rotor clearances.

(17) If clearance tolerances are not within the limits given in figure 154, it will be necessary to correct clearances by increasing or decreasing the thickness of the shims between either the upper or lower gear of the blower rotor gear set. See figure 155 for a diagram of the placement of the shims to the correct tolerances. NOTE: The amount of increase or decrease in shim thickness will alter the clearance by approximately the same amount. Thus the addition of a 0.002-inch shim will increase the tolerance by 0.002 inch on one side, and decrease the tolerance by 0.002 inch on the other.

(18) After proper clearances have been established, remove the blower rotor gear bolts, using a  $\frac{3}{4}$ -inch socket wrench. Remove the rotor gear washer and the disk from the bolts. Install an external tooth lock washer on each bolt.

(19) Assemble the retainer washer on the bolt and install the bolt in the upper shaft. Assemble the coupling on the disk on the other bolt and install the bolt in the lower shaft.

(20) Hold rotors to keep them from turning and, using a  $\frac{3}{4}$ -inch socket wrench, tighten the bolts. Check to 45 foot-pounds with a tension wrench.

(21) Bend external teeth back on the bolt head.

(22) Install the blower rotor gear hub on the upper gear and, using a  $\frac{1}{2}$ -inch socket wrench, install and tighten the six bolts and lock washers (fig. 144).

(23) Install the shaft and the water pump coupling assembly in the splines of the lower rotor shaft, making sure that the end of the shaft pilots against the shoulder on the coupling (fig. 143).

(24) After the coupling is snug against the rotor shaft shoulder, tighten the Allen set screw, using tool KM-J-1699.

(25) Shellac new gaskets on the end covers.

(26) Using a  $\frac{1}{2}$ -inch socket wrench, install and tighten the 20 bolts and lock washers holding the end covers to the blower housing, bearing

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2






Figure 154—Chart for Checking Blower Rotor Clearances

AIR INLET HOUSING AND BLOWER ASSEMBLIES



(NOTE: INCREASING CLEARANCE AT "C" DECREASES CLEARANCE AT "CC")  
**Figure 155—Blower Rotor Shim Placement Diagram**



**Figure 156—Checking Rotor Clearances**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

in mind that threads are tapped into an aluminum housing. Do not tighten as though in steel or cast iron.

**189. ASSEMBLY OF THE AIR INLET HOUSING ASSEMBLY.**

**a. Equipment.**

Cutters, side

Wrench, socket,  $\frac{1}{8}$ -in.

Screwdriver

Wrench, socket,  $\frac{3}{8}$ -in.

**b. Procedure (figs. 49 and 141).**

(1) Install the valve control shaft (8, fig. 141) partially into the air inlet housing (4).

(2) Install the two air shut-down valves (9) to the shaft by pushing the shaft through the holes in the valves.

(3) Install the straight pins (10) holding the valves to the shaft.

(4) Install the felt seal washer (7), the flat washer (6) and the cotter pin (5) on one end of the shaft opposite the solenoid.

(5) Install the felt seal washer, the air shut-down lock plate, the air shut-down valve spring (13) and the air shut-down valve lever on the other end of the shaft.

(6) Install the air shut-down valve lever pin (15) in the lever (14).

(7) Install the two fillister-head bolts (16), the lock washers (17), and the one flat washer (23) holding the spring and the plate to the air inlet housing, using a screwdriver to tighten.

(8) Using a  $\frac{1}{8}$ -inch socket wrench, install the two bolts and lock washers holding the solenoid assembly to the air inlet housing, and install the assembly.

(9) Install the clevis pin in the clevis solenoid rod end and install the cotter pin (22) holding the clevis pin in the clevis.

(10) Check the air shut-down valves with a straightedge to be sure that they close together.

(11) Energize the solenoid with a 12-volt direct-current supply. Note the position of the valves; then disconnect the current and adjust by backing off the lock nut and turning the solenoid shaft. Repeat this process until the upper lips of the valves are approximately  $\frac{1}{16}$  inch above the stroker plate surface when the solenoid is energized. The adjustment must be done while the solenoid is not energized. When the adjustment is completed, tighten the lock nut (25) against the yoke end (24).

(12) After the blower is reconditioned, install the screen and gasket (13), the striker plate (12), the striker plate gasket (11) and the air

**AIR INLET HOUSING AND BLOWER ASSEMBLIES**

inlet assembly to the blower, using a  $\frac{7}{8}$ -inch socket wrench to tighten the six bolts and lock washers. **NOTE:** The long bolts (2 $\frac{7}{8}$ -in.) are used for the upper end, and the shorter bolts (1 $\frac{1}{4}$ -in.) are used for the lower end of the air inlet housing. Do not use longer bolts than specified.

**190. PREINSTALLATION INSPECTION.**

Before installing the air inlet housing and the blower assemblies on the engine, a recheck should be made to make sure that all previously required inspections and adjustments have been made, as outlined in paragraph 186. Check the assembly for cleanliness and loose parts.

**191. INSTALLATION ON ENGINE.**

To install the air inlet housing and the blower assemblies on the engine, when the engine is installed in the tank, see TM 9-753 and TM 9-758. To install when the engine assembly is removed from the tank, see section VII, paragraph 157, of this manual.



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71**  
**POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section IX**

**WATER PUMP ASSEMBLY**

	<b>Paragraph</b>
<b>Inspection while on engine</b> .....	192
<b>Trouble shooting</b> .....	193
<b>Removal from engine</b> .....	194
<b>Disassembly of the water pump assembly</b> .....	195
<b>Inspection of the water pump assembly</b> .....	196
<b>Overhaul of the water pump assembly</b> .....	197
<b>Assembly of the water pump assembly</b> .....	198
<b>Preinstallation inspection</b> .....	199
<b>Installation on engine</b> .....	200

**192. INSPECTION WHILE ON ENGINE.**

It is impossible to make an adequate inspection of the water pump without first removing it from the engine. See paragraph 196 for inspection after removal from engine.

**193. TROUBLE SHOOTING.**

As required for inspection, the proper functioning of the water pump can be checked only by removing the assembly from the engine (par. 196). An inoperative water pump will result in engine overheating. Should checks for causes of engine overheating, as outlined in the trouble shooting procedure in TM 9-753 and TM 9-758 fail to locate the trouble, the water pump should be inspected (par. 196).

**194. REMOVAL FROM ENGINE.**

a. To remove the water pump assembly from the engine when the engine is installed in the tank, see the procedure outlined in TM 9-753 and TM 9-758.

b. To remove the water pump assembly from the engine, after the engine assembly has been removed from the tank, see paragraph 56.

**195. DISASSEMBLY OF THE WATER PUMP ASSEMBLY.**

**a. Equipment.**

Hammer	Screwdriver
Press, arbor	Tool KM-J-1930
Punch	Wrench, open-end, $\frac{7}{16}$ -in.


**b. Procedure (figs. 157 and 159).**

(1) Remove the water pump outlet packing flange (17, fig. 157) and the water pump outlet packing (18) from the water pump body assembly (13).

(2) Using a  $\frac{7}{16}$ -inch open-end wrench, remove the water pump body cover (1) by removing the four nuts (2) and lock washers which hold

# WATER PUMP ASSEMBLY

TM 9-1750G  
195



RA PD 11323

Figure 157 — Component and Related Parts of Water Pump Assembly

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

the cover to the body. Then remove the water pump body cover gasket (11).

(3) Press off the water pump shaft and bearing assembly (14) through the water pump impeller (4), using an arbor press (fig. 158).

(4) Remove the impeller assembly from the pump housing.

(5) Disassemble the impeller assembly by removing, in order, the water pump seal retaining cup (10), the water pump seal washer (9), the water pump seal clamp ring (8), the water pump seal (7), the water pump seal spring guide (6), and the water pump seal spring (5).

(6) If the thrower and coupling are to be removed, put the shaft and bearing assembly into the special tool KM-J-1930 (fig. 159). Then, resting the tool on the jaws of the vise, drive out the shaft from the water pump thrower and coupling assembly, using a hammer and a punch.

**196. INSPECTION OF THE WATER PUMP ASSEMBLY (fig. 157)**

- a. Check the bearing and shaft assembly for wear.
- b. Check shaft ring (15, fig. 157) for wear and replace if necessary.
- c. Inspect the water pump seal (7) for smoothness, wear and evidence of leakage. Examine the clamp ring (8) and the washer (9) for wear.
- d. Examine the cup (10) for wear and smoothness.
- e. Inspect the interior of the body for evidence of scale, and for smoothness of the seat for water pump seal washer.

**197. OVERHAUL OF THE WATER PUMP ASSEMBLY.**

All parts comprising the water pump assembly should, when disassembled, be washed and cleaned. All parts which, in the inspection procedure outlined in the previous paragraphs, have been found to be defective should be replaced.

**198. ASSEMBLY OF THE WATER PUMP ASSEMBLY.**

**a. Equipment.**

Press, arbor

Wrench, open-end,  $\frac{7}{16}$ -in.

Shellac


**b. Procedure (fig. 157).**

(1) Using an arbor press, press the water pump shaft and bearing assembly (14, fig. 157) into the body (13). Prick punch the end of the body to hold the bearing in place.

(2) Assemble the water pump seal (7) and related parts into the water pump impeller (4) in the following order: the water pump seal spring (5), the water pump seal spring guide (6), the water pump seal (7), the water pump seal clamp ring (8), the water pump seal washer (9), and the water pump seal retaining cup (10).

(3) After putting a little grease on the seal, place the impeller assembly into the water pump assembly body (13).


**WATER PUMP ASSEMBLY**



RA PD 11295

**Figure 158—Removing Water Pump Shaft and Bearing Assembly**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11324

**Figure 159—Removing Water Pump Thrower and Coupling Assembly**

(4) Press the impeller on the shaft and water pump bearing assembly, using an arbor press. **NOTE:** If the impeller is loose on the shaft, a new impeller should be used to avoid the possibility of slippage.

(5) Shellac a new gasket to the water pump body cover (1).

(6) Install the cover. Using a  $\frac{1}{8}$ -inch open-end wrench, install and tighten the four bolts and lock washers holding the cover to the body.

(7) Turn the shaft by hand to check for free movement, with no contact between the impeller and the body.

(8) Install the water pump outlet packing flange (17) on the body.

(9) Install new water pump outlet packing.

(10) Using an arbor press, press on the thrower and coupling.

**NOTE:** If the thrower and coupling are loose on the shaft, a new coupling should be used to avoid possible slippage.

## **199. PREINSTALLATION INSPECTION.**

The assembly should be checked for cleanliness and loose parts.

## **200. INSTALLATION ON ENGINE.**

a. To install the water pump on the engine, when the engine is installed in the tank, see TM 9-753 and TM 9-758.

b. To install the water pump when the engine assembly is removed from the tank, see section VII, paragraph 157 of this manual.

Section X

FUEL PUMP ASSEMBLY

	Paragraph
Inspection while on engine .....	201
Trouble shooting .....	202
Removal from engine .....	203
Disassembly of the fuel pump assembly .....	204
Inspection of the fuel pump assembly .....	205
Overhaul of the fuel pump assembly .....	206
Assembly of the fuel pump assembly .....	207
Preinstallation inspection .....	208
Installation on engine .....	209

201. INSPECTION WHILE ON ENGINE.

If the fuel oil pump is to be inspected and reconditioned, the pump assembly must be removed from the engine.

202. TROUBLE SHOOTING.

As discussed in paragraph 228 on injector trouble shooting, a faulty fuel oil pump may be the cause of an insufficient supply of fuel at the injectors. The fuel oil pump should maintain a minimum fuel pressure of 10 pounds per square inch in the return manifold of the engine at a speed of 600 to 800 revolutions per minute. If fuel flow is insufficient, after making the checks and necessary corrections referred to in paragraph 228, proceed as follows:

- a. Remove the fuel pump from the engine as outlined in paragraph 56.
- b. Remove the relief valve, valve seat, and valve parts. Thoroughly wash them, and reassemble.
- c. If this does not correct the pump condition, overhaul the pump as directed in paragraph 206.

203. REMOVAL FROM ENGINE.

- a. To remove the fuel pump from the engine when the engine assembly is installed in the tank, refer to the procedure in TM 9-753 and TM 9-758.
- b. To remove the fuel pump from the engine after the engine assembly has been removed from the tank, refer to the procedure outlined in paragraph 56 of this manual.

204. DISASSEMBLY OF THE FUEL PUMP ASSEMBLY.

a. Equipment.

- Hammer, soft
- Tool KM-J-1508

- Wrench, open-end,  $\frac{9}{16}$ -in.
- Wrench, socket,  $\frac{7}{16}$ -in.

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 160—Components of Fuel Pump

## FUEL PUMP ASSEMBLY

### b. Procedure (figs. 160 and 161).

(1) Using a  $\frac{1}{8}$ -inch open-end wrench, remove the fuel pump valve screw (14, fig. 160) and the fuel pump valve gasket (13).

(2) Lift out in order the fuel pump valve retaining spring (12), the valve and seat assembly (11), the fuel pump valve spring and the fuel pump valve and seat assembly cage (9), being careful to note the direction in which the valve and seat assembly is facing. It must be installed facing the same direction.

(3) Using a  $\frac{7}{8}$ -inch socket wrench, remove the two short bolts (7), the long bolts (8), and the lock washers holding the fuel pump cover (2C) and the fuel pump body (2B) to the fuel pump flange (2A).


(4) Turn the pump over and tap the rotor shaft with a soft hammer to remove the flange from the body and cover.

(5) Remove the fuel pump body gasket (3) and pull out the fuel pump rotor assembly.

(6) Remove the two fuel pump rotor vanes (5), the fuel pump rotor vane spring (16), and the fuel pump rotor vane spring guide (15).

(7) Tap the body loose from the cover with a soft hammer and remove the gasket (6).

(8) Using special tool KM-J-1508 pull out the fuel pump oil seals (1, fig. 161) one at a time from the flange.



**Figure 161—Removing Seals from Fuel Pump Flange**



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**205. INSPECTION OF THE FUEL PUMP ASSEMBLY.**

- a. Inspect all parts of the fuel pump valve assembly, particularly the valve and seat assembly, for wear and smoothness.
- b. Inspect the vanes on the rotor, particularly the outside working surfaces for smoothness and wear.
- c. Check the free movement of the spring on the guide.
- d. Inspect the rotor shaft for wear, particularly at the seal contacts.
- e. Inspect the inside diameter of the body for smoothness and wear.
- f. Check all contacting surfaces of the flange, body and cover for smoothness and evidence of leakage.

**206. OVERHAUL OF THE FUEL PUMP ASSEMBLY.**

Wash all parts of the disassembled fuel pump in fuel oil and blow out all oil holes with compressed air. All parts found to be defective when making the inspection outlined in the previous paragraph should be replaced.

**207. ASSEMBLY OF THE FUEL PUMP ASSEMBLY**


**a. Equipment.**

Hammer

Tool KM-J-1508 (set)

Wrench, open-end,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{7}{16}$ -in.



RA PD 11326

**Figure 162—Driving Inner Oil Seal into Fuel Pump Flange**

## FUEL PUMP ASSEMBLY

b. Procedure (figs. 160, 162, 163 and 164).

(1) Using a hammer and tool set KM-J-1508 (fig. 162), with the long shoulder of the adapter toward the flange, drive in a new inner seal. The inner seal is installed with the edge of the seal leather toward the rotor. **NOTE:** It is advisable to soak the seals in oil for 30 minutes before installing.


(2) Reverse the tool adapter and drive in a new outer seal (fig. 163). The outer seal is installed with the edge of the seal leather on the side toward the blower. **NOTE:** With the seals properly installed, a space exists between them, from which leaking fuel or lubricating oil escapes outside.

(3) Install a new gasket and the pump body to the pump cover by tapping them on over the dowels. **NOTE:** Be sure that the holes in the body line up with the holes in the cover.

(4) Assemble, in order, the guide, the spring, and the vanes into the rotor.

(5) Holding the vane assembly compressed, install the rotor assembly in the body.

(6) Install special Tool KM-J-1508 on the end of the shaft to protect the seals and to act as a pilot. Then install a new gasket and the flange over the dowel pins to the body (fig. 164).



**Figure 163—Driving Outer Oil Seal into Fuel Pump Flange**

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 164 — Using Tool KM-J-1508-3 to Assemble Fuel Pump

## **FUEL PUMP ASSEMBLY**

(7) Install the three bolts and lock washers, tightening them with a  $\frac{7}{8}$ -inch socket wrench.

(8) Install, in order, the cage, the spring, and the valve and seat assembly. Retain the spring in the cover and be sure that the cage, the spring, and the valve and seat assembly are installed in the same direction as when removed. NOTE: In the LA engine (pump marked "L. H. in"), the direction is as shown in figure 160. In the LC engine (pump marked "R. H. in"), the direction is reversed.

(9) Using a  $\frac{3}{8}$ -inch open-end wrench, install the valve screw and the new gasket.

### **208. PREINSTALLATION INSPECTION.**

Check the assembly for cleanliness and loose parts.

### **209. INSTALLATION ON ENGINE.**

#### **a. Equipment.**

Tool KM-KMO-326-A	Wrench, open-end, $\frac{5}{8}$ -in.
Wrench, open-end, $\frac{1}{2}$ -in.	Wrench, open-end, $\frac{3}{4}$ -in.

#### **b. Procedure.**

(1) To install the fuel pump on the engine when the engine is installed in the tank, see TM 9-753 and TM 9-758.

(2) To install the fuel pump when the engine assembly is removed from the tank, proceed as follows:

(a) Install a new gasket.

(b) Install the fuel pump and the fuel pump coupling fork.

(c) Install and tighten the three bolts and lock washers which hold the fuel pump to the blower, using a  $\frac{1}{2}$ -inch open-end wrench and the fuel pump wrench KM-KMO-326-A.

(d) Attach fuel inlet and outlet lines to the fuel pump, using a  $\frac{3}{4}$ -inch and a  $\frac{5}{8}$ -inch open-end wrench to tighten the nuts.

(e) Install air cleaners which may have been removed.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section XI**

**GOVERNOR ASSEMBLY**

	<b>Paragraph</b>
Inspection while on engine .....	210
Trouble shooting .....	211
Removal from engine .....	212
Disassembly of the governor control housing .....	213
Inspection of the governor control housing .....	214
Overhaul of the governor control housing .....	215
Assembly of the governor control housing .....	216
Disassembly of the governor cover and lever assembly .....	217
Inspection of the governor cover and lever assembly .....	218
Overhaul of the governor cover and lever assembly .....	219
Assembly of the governor cover and lever assembly .....	220
Disassembly of the weight and housing assembly .....	221
Inspection of the weight and housing assembly .....	222
Overhaul of the weight and housing assembly .....	223
Assembly of the weight and housing assembly .....	224
Preinstallation inspection .....	225
Installation on engine .....	226

**210. INSPECTION WHILE ON ENGINE.**

To inspect the governor while it is installed on the engine, the following checks should be made:

**a. Check for Free Operation of Parts.**

**b. Low-Speed Spring Plunger Gap Adjustment.**


(1) Remove governor cover.

(2) Remove governor to control shaft link.

(3) Start the engine and regulate its speed by hand control of the injector control shaft.

(4) **CAUTION: BE CAREFUL NOT TO OVERSPEED THE ENGINE.** Gradually increase engine speed from 350 to 700 revolutions per minute. In this range of speed, the bell crank should move IN, practically closing the gap between low-speed spring plunger and seat before reaching 700 revolutions per minute. Gradually raise speed to 1,500 revolutions per minute, and no further motion of the bell crank should take place. If adjustment is necessary, run the engine at any speed above 800 revolutions per minute and adjust the low-speed spring

**GOVERNOR ASSEMBLY**



**Figure 165—Adjusting Governor Low Speed Gap**

stop screw until the plunger gap is closed to a smooth pull on a 0.0015-inch or 0.002-inch feeler (fig. 165).

- (5) Attach governor link to governor and control tube.
- (6) Replace governor cover and gasket.
- (7) Position injector control racks, as outlined in paragraph 167.

**c. Low-Speed Adjustment for Controlling Engine Idling Speed.**

The desirable idling speed of these engines is approximately 350 revolutions per minute. Even though the low-speed adjustment is set at the factory before the engine is shipped, it may be desirable either to raise or lower the idling speed of the engine; in this case the engine should be hot and running while making this adjustment, as follows:

(1) Remove the low-speed adjustment cover at the rear side of the governor control housing.

(2) Loosen the lock nut and turn the buffer screw out until the screw projects  $\frac{5}{8}$  inch beyond the lock nut. Set the throttle control lever in idling position and start the engine. If the engine "gallops" or "rolls," after it has become thoroughly warm, gradually turn the buffer spring screw IN to contact the differential lever until "roll" disappears or nearly disappears. If engine does not "roll," leave the buffer screw backed out until after low-speed adjustment has been completed.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

- (3) Loosen the lock nut on the idle adjusting screw.
- (4) Adjust the screw IN, clockwise, for higher speed and OUT, counterclockwise, for lower speed.
- (5) Again check buffer spring adjustment, and readjust idle speed if necessary.
- (6) Tighten idle adjusting screw lock nut, and replace cover and gasket at low-speed adjustment.

d. **Buffer Spring Adjustment for Limiting "Off" Travel of the Differential Lever.** To adjust, after the screw has been backed out as directed for the low-speed adjustment, turn the screw IN until the engine idling speed is increased slightly (not to exceed 20 revolutions per minute), thus insuring spring contact with the differential lever.

e. **Load-Limit Screw Adjustment for Limiting Engine Maximum Output.** To set the load-limit screw for maximum fuel position, back out the load-limit screw. Then with injector racks held in full fuel position (way in), turn the screw IN to contact the differential lever, causing racks to move OUT (toward no fuel position)  $\frac{1}{8}$ -inch to  $\frac{1}{2}$ -inch. **NOTE:** No high-speed spring setting check is necessary, since this adjustment has been made at the factory for the maximum engine revolutions per minute under which the engine should operate. The load-limit screw has been eliminated on late models, since it is not required.

## **211. TROUBLE SHOOTING.**

While governor faults are usually manifest in speed variations of the engine, it is important to remember that all such speed variations do not necessarily indicate governor faults. Therefore, when improper speed variations appear, the following trouble shooting steps should be followed:

- a. Check the load to be sure that the speed changes observed are not the result of load fluctuations.
- b. If the load is uniform, carefully check the engine to be sure that all cylinders are firing properly. If all cylinders are not firing properly, check exhaust valve lash (par. 163), injector timing (par. 163), and injector equalization (par. 167). If these operations do not locate the trouble, remove and check the injector from the faulty cylinder (par. 52). If this test reveals plugged holes in the spray tip, remove and clean the tip as outlined in paragraph 232.
- c. See that no binding exists in any of the governor mechanism or operating linkage between the governor and the engine. Also check to see that no binding is evident in the injector control tube or its mounting

## GOVERNOR ASSEMBLY

brackets. Should excess friction exist in the mechanism, it can be located and eliminated as follows:

(1) Injector control racks may stick or move too hard. This may be because the injector hold-down crab is too tight or not positioned properly. This often can be eliminated by tapping the foot of the crab lightly with a small hammer and a long punch or screwdriver. However, an injector which has been in service a long time may become sticky from an accumulation of gum and sludge. This can be corrected by removing the sticky parts and washing them in a pail of clean gasoline.

(2) Injector racks may stick because they are cramped by the control tube lever being out of position or cocked. Loosen the screws in the control tube lever, and if this relieves the binding, move the lever end-ways on the control tube until the lever no longer cramps the injector rack. Cocking of the control tube lever may also be due to damage of the adjusting screws or the surfaces which they contact. This can be corrected by filing. After the trouble has been remedied, the control tube lever must be readjusted for proper position.

(3) The control tube may stick or bind in its ball bearings. These bearings must be free from chips, dirt, or sludge, and must be lubricated. Binding due to poor alinement of the bearing supports can be corrected by loosening the bearing support cap screws and realining the bearing supports. When the control tube is free of bind and is operating the injector racks, the control tube should return freely to the no fuel position by the tube return spring only. If the control tube bearing supports have been loosened, injectors should be equalized after the engine has been started and warmed up (par. 167). CAUTION: Never stretch or tamper with the injector rack control spring to change the tension. If the spring has been bent out of shape, replace it with a new part.

(4) The control tube may have too much friction, because the control tube spring is bent. Replace it with a new spring.

(5) The pin in the governor control link may be binding in the control tube lever. Remove the binding.

(6) Should the governor fail to control the engine properly after all the preceding steps have been followed, the governor may be worn or otherwise unfit for further use. It should be completely torn down, inspected, and overhauled, or replaced.

### 212. REMOVAL FROM ENGINE.


a. To remove the governor from the engine, when the engine assembly is installed in the tank, follow the procedure outlined in TM 9-753 and TM 9-758.

b. To remove the governor from the engine, after the engine assembly has been removed from the tank, see paragraph 46 of this manual.



**TM 9-1750G**  
**212**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71**  
**POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



**Figure 166—Component Parts of Governor**

GOVERNOR ASSEMBLY

- |   |   |
|---|---|
| 1—Lever, Governor Control   | 29—Bolt, Weight Housing Cover                               |
| 1a—Lever—No Separate Part Number (Part of Cover and Lever Assembly) | 30—Cover, Weight Housing                                    |
| 2—Bolt, Control Lever   | 31—Weight, High-Speed—Light                                 |
| 3—Washer, Governor Control Cam                                      | 32—Weight, Low-Speed—Heavy                                  |
| 4—Cam, Governor Control (Model LA24M Engine)                        | 33—Washer, Governor Weights                                 |
| 5—Pin, Taper  | 34—Screw, Set, Governor Weights                             |
| 6—Retainer, Throttle Shaft Packing                                  | 35—Pin, Governor Weights                                    |
| 7—Packing, Throttle Shaft   | 36—Carrier, Weight  |
| 8—Cover—Assembly (Model LA24M Engine)                               | 37—Shaft, Weight  |
| 9—Bearing, Throttle Shaft   | 38—Riser  |
| 10—Shaft, Throttle (Model LA24M Engine)                             | 39—Gasket, Governor Assembly (to Blower)                    |
| 11—Clip, Retainer   | 40—Housing, Weight  |
| 12—Washer, Differential Lever and Pin                               | 41—Fork, Operating Shaft (Part of Operating Shaft Assembly) |
| 13—Nut, Operating Shaft Gap Adjusting Screw                         | 42—Pin, Taper (Part of Operating Shaft Assembly)            |
| 14—Screw, Operating Shaft Gap Adjusting                             | 43—Tube, Breather   |
| 15—Lever and Pin, Differential—Assembly                             | 44—Gasket, Breather Tube                                    |
| 16—Bearing, Operating Shaft Upper                                   | 45—Gasket, High- and Low-Speed Spring Cover                 |
| 17—Shaft, Operating—Assembly (Model LA24M Engine)                   | 46—Cap, Low-Speed Spring                                    |
| 18—Housing, Governor Control—Assembly (Model LA24M Engine)          | 47—Spring, Low-Speed  |
| 19—Plug, Expansion  | 48—Seat, Low-Speed Spring                                   |
| 20—Bearing, Operating Shaft Lower                                   | 49—Plunger, Low-Speed Spring                                |
| 21—Plug, Expansion  | 50—Shim—0.010-inch Thick Shim—0.078-inch Thick              |
| 22—Cap, Weight Housing  | 51—Spring, High-Speed                                       |
| 23—Screw, Thrust Bearing  | 52—Retainer, High-Speed Spring                              |
| 24—Washer, Lock, Special  | 53—Screw, Low-Speed Spring Adjusting                        |
| 25—Ring, Thrust Bearing Snap  | 54—Nut, Low-Speed Spring Adjusting Screw                    |
| 26—Bearing, Weight Shaft End  | 55—Cover, Spring  |
| 27—Bearing, Weight Shaft Thrust                                     | 56—Washer, Lock, High- and Low-Speed Spring Cover           |
| 28—Gasket, Weight Housing Cover                                     | 57—Bolt, Filler-Head, High- and Low-Speed Spring Cover      |

Nomenclature for Figure 166—Component Parts of Governor

RA PD 11330A

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**213. DISASSEMBLY OF THE GOVERNOR CONTROL HOUSING.**

**a. Equipment.**

Hammer, light

Punch, small

Screwdriver

Tool KM-J-1652

Vise

Wrench, open-end,  $\frac{1}{8}$ -in.


Wrench, open-end,  $\frac{1}{2}$ -in.

Wrench, open-end,  $\frac{3}{8}$ -in.

**b. Procedure** (figs. 35, 36, 166, 167, 168, 169, 170, 171, 172, 173, 174, 175, 176, 177, 178, 179, 180, 181 and 182).

The governor assembly is divided into the weight carrier housing assembly, the governor control housing assembly, and the governor cover and levers assembly. During disassembly, as outlined in section V, the weight carrier assembly was removed with the blower and later removed from the blower to permit blower disassembly and inspection (par. 56). In disassembling the engine, the control housing cover and lever assembly was removed before the control housing was disassembled from the engine. Use the following procedure in disassembling the governor control housing assembly:

(1) Using a screwdriver, remove the two fillister-head bolts and lock washers holding the breather tube to the governor control housing. Remove the breather tube gasket.



RA PD 11292

**Figure 167—Governor Control Housing with Cover and  
Lever Assembly Removed**

## GOVERNOR ASSEMBLY

(2) Using a  $\frac{3}{8}$ -inch open-end wrench and a screwdriver, remove the screw and buffer screw nut and the spring assembly (fig. 167).

(3) Using a screwdriver, remove the two fillister-head bolts and lock washers holding the high-speed spring cover to the housing. Remove the cover and the gasket from the cover.

(4) Using a  $\frac{1}{4}$ -inch open-end wrench and a screwdriver, loosen the low-speed adjusting screw lock nut.


(5) Using tool KM-J-1652, remove the retainer and remove the high-speed spring assembly and the low-speed spring cap (fig. 168).

(6) Remove the low-speed spring cap, the low-speed spring, and the low-speed spring seat from the plunger (fig. 166).

(7) With a screwdriver, remove the low-speed adjusting screw, releasing the high-speed spring retainer, shims (if any), the high-speed spring, and the low-speed plunger (fig. 166).

(8) Remove the two  $\frac{3}{8}$ -inch expansion plugs, one plug located on each side of the base of the housing, by drilling a hole in the plugs and lifting them out with a small punch. Then drive out the tapered pin holding the operating shaft fork to the shaft (fig. 169).


(9) Using a screwdriver, remove the screw holding the lock washer, and the flat washer holding the upper bearing to the housing (fig. 170).




RA PD 11291

**Figure 168—Removing Governor High-Speed Retainer Spring**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



**Figure 169—Driving Out Tapered Pin from Operating Shaft Fork**



LEVER AND PIN, DIFFERENTIAL; ASSEMBLY

**Figure 170—Location of Screw Holding Upper Bearing to the  
Governor Control Housing**

## GOVERNOR ASSEMBLY

(10) Using a light hammer, tap the operating shaft fork off the end of the shaft.

(11) Remove the operating shaft, the differential lever and pin assembly, and the upper bearing as an assembly from the housing.

(12) Remove the retainer clip and the differential lever and pin washer, and lift off the lever (fig. 169).

### 214. INSPECTION OF THE GOVERNOR CONTROL HOUSING.

a. Inspect the operating shaft top bearing for wear. If the bearing is loose and needs replacing, remove the operating shaft from the vertical shaft, after first driving out the tapered pin. Install the operating shaft bearing and the tapered pin.

b. Inspect both differential lever pins for tightness or looseness.

c. Inspect the lower needle bearing in the bottom of the housing. If wear makes replacement necessary, it may be removed by removing the  $\frac{3}{4}$ -inch expansion plug at the bottom of the housing. Also inspect the operating shaft which contacts the bearing.

d. Examine the low-speed plunger for fit in the housing. It should move freely but without play.

e. Examine the low-speed spring cap, checking fit and freedom of movement in the plunger.

### 215. OVERHAUL OF THE GOVERNOR CONTROL HOUSING.

All parts of the disassembled governor control housing should be washed. When the inspection outlined in the previous paragraph is made, parts found to be defective should be replaced with new parts.

### 216. ASSEMBLY OF THE GOVERNOR CONTROL HOUSING.

#### a. Equipment.

Screwdriver

Wrench, open-end,  $\frac{1}{2}$ -in.

Shellac

Wrench, open-end,  $\frac{9}{16}$ -in.

Tool KM-J-1652

#### b. Procedure (figs. 167, 168, 169, 170 and 171).


(1) Assemble the lower needle bearing in the housing if it has been removed. Install the differential lever on the operating shaft pin and install the flat washer and the retainer clip (fig. 168).

(2) Assemble the upper ball bearing on the shaft. Install the operating shaft assembly into the large end of the housing and tap the shaft operating fork on the other end of the shaft. Drive in the tapered pin holding the fork to the shaft (fig. 169).

(3) Install the two  $\frac{3}{8}$ -inch expansion plugs in the lower housing. Also install the  $\frac{3}{4}$ -inch plug if it has been removed.

(4) Using a screwdriver, install the screw with the lock washer and the plain washer, holding the upper bearing to the housing (fig. 169).

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11331

**Figure 171—Installing Governor High-Speed Spring  
Adjusting Screw**

(5) Install the shims (if any), the high-speed spring, and the high-speed spring retainer on the plunger.

(6) Compressing the high-speed spring assembly by hand or with a vise (fig. 171), install the adjusting screw and the adjusting screw nut.

(7) Install the spring seat, the low-speed spring, and the low-speed spring cap on the plunger.

(8) Oil the plunger and the cap and install the assembly in the housing.

(9) Install the retainer, using the special tool KM-J-1652.

(10) Shellac a new gasket to the high-speed spring cover and install the cover. Using a screwdriver, install the two fillister-head bolts and lock washers holding the cover to the housing.

(11) Using a screwdriver, install the load-limit screw to the housing. Using a 1/2-inch open-end wrench, install the nut on the load-limit screw.

(12) Install the buffer screw and nut assembly, using a 1/8-inch open-end wrench and a screwdriver.

(13) Install the breather tube gasket and the breather tube, using a screwdriver to tighten the two fillister-head bolts and lock washers holding the tube to the housing.

## GOVERNOR ASSEMBLY

### 217. DISASSEMBLY OF THE GOVERNOR COVER AND LEVER ASSEMBLY.

#### a. Equipment.

Punch, small

Wrench, open-end,  $\frac{7}{8}$ -in.

#### b. Procedure (fig. 166).

(1) Using a  $\frac{7}{8}$ -inch open-end wrench, loosen the bolt on the control lever and remove the lever from the throttle shaft (fig. 166).

(2) Remove the retainer clip and the flat washer from the control cam.

(3) Using a small punch, drive out the tapered pin holding the accelerator stop to the shaft and lift off the stop, the flat washer, and the felt washer (fig. 166).

(4) Pull out the throttle shaft and washer (fig. 166).

(5) Lift off the control cam from the cover.

### 218. INSPECTION OF THE GOVERNOR COVER AND LEVER ASSEMBLY.

a. Insert the throttle shaft in the needle bearing and examine it for wear. The shaft must move freely in the bearing, but with no play. Replace both bearings and the shaft, if necessary. NOTE: The needle bearing can be driven from the cover with a punch or bar of a diameter approximating that of the bearing.

b. Examine the control cam for looseness on the shaft. If necessary, replace the cam and the shaft.

### 219. OVERHAUL OF THE GOVERNOR COVER AND LEVER ASSEMBLY.

Wash all parts and replace all parts found to be defective when making the inspection outlined in the previous paragraph.

### 220. ASSEMBLY OF THE GOVERNOR COVER AND LEVER ASSEMBLY.

#### a. Equipment.

Wrench, open-end,  $\frac{7}{8}$ -in.

#### b. Procedure (fig. 166).

(1) Install the control cam on the cover, slipping it on the operating shaft, and install the washer and the retainer spring.

(2) Install the throttle shaft and washer.


(3) Install the felt washer, the flat washer, and the accelerator stop entering the stop pin in the cam.

(4) Install the tapered pin holding the accelerator stop to the throttle shaft.

(5) Install the throttle lever on the shaft, using a  $\frac{7}{8}$ -inch open-end wrench to tighten the bolt.



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



RA PD 11332

**Figure 172—Governor Weight and Housing Assembly**

**221. DISASSEMBLY OF THE WEIGHT AND HOUSING ASSEMBLY.**

**a. Equipment.**

Block, wooden  
Drift, brass  
Eyebolt  
Hammer

Pliers, small  
Punch  
Screwdriver  
Wrench, socket,  $\frac{1}{8}$ -in.


**b. Procedure (figs. 166, 172, 173 and 174).**

(1) Using a screwdriver, puncture and remove the housing cap from the end of the housing (fig. 173), being careful not to drive the screwdriver in far enough to damage the bearing, which is directly below the cap. **NOTE:** If replacement caps are not available, the cap may be removed undamaged by soldering the nut to the cap and removing the cap and nut with an eyebolt.

(2) Bend down the finger on the lock and bearing screw shaft washer (fig. 166). Using an  $\frac{1}{8}$ -inch socket wrench, remove the bearing end shaft screw and the lock washer.

(3) Drive out the shaft assembly using a brass drift.

## GOVERNOR ASSEMBLY



RA PD 11333

**Figure 173—Removing Cap from Governor Weight Housing**

- (4) Remove the thrust bearing assembly from the housing (fig. 166).
- (5) Pull the riser off the carrier shaft.
- (6) Using small pliers, pull out the snap ring holding the end bearing in place and lift out the spacer.
- (7) Tap out the end bearing from the inside, using a wooden block and hammer.
- (8) With a punch, mark the weights on the end of the carrier so that they can be replaced in the proper order (figs. 166 and 172).
- (9) Loosen the two set screws holding the pins in place. Remove the washers, pins, and weights from the carrier.

### **222. INSPECTION OF THE WEIGHT AND HOUSING ASSEMBLY.**

- a. Inspect the governor weight pins and washers for wear. Replace, if worn.
- b. Inspect the thrust bearing for wear and smoothness.
- c. Inspect the end bearing for wear and end play.
- d. Inspect each end of the riser for wear and smoothness.
- e. Inspect the serrations on the end of the carrier for wear.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**223. OVERHAUL OF THE WEIGHT AND HOUSING ASSEMBLY.**

All disassembled parts should be washed thoroughly and all parts which were found defective when the inspection outlined in the previous paragraph was made should be replaced.

**224. ASSEMBLY OF THE WEIGHT AND HOUSING ASSEMBLY.**

**a. Equipment.**

Hammer

Wrench, socket,  $\frac{1}{8}$ -in.


**b. Procedure (figs. 166, 172 and 174).**

(1) Install the weights in position (figs. 166 and 172).

(2) Install the pin washers between the weights and the carrier. Oil and install the pins on the carrier so that the small hole in each pin is in line for the ends of the two set screws (fig. 172). Tighten the set screws, holding the pins and weights in place.

(3) Install the bearing and snap ring (fig. 174). Then install the riser on the carrier shaft.

(4) Oil and install the thrust bearing assembly on the carrier shaft.  
**NOTE:** The hole diameters of the thrust washers of the thrust bearing vary slightly. The one with the smaller hole is installed first, next to the riser.



RA PD 11334

**Figure 174—Governor Weight Housing with Cap Removed**

## **GOVERNOR ASSEMBLY**

(5) Install the carrier assembly into the housing with shaft through the end bearing. Tap the bearing end into the end of the housing, using a soft hammer. Using an  $\frac{1}{8}$ -inch socket wrench, install the bearing screw end and the special lock washer. Turn up the finger of the washer.

(6) Oil the end bearing and install a new housing cap, forcing it into place with a hammer.

### **225. PREINSTALLATION INSPECTION.**

Before a governor is installed on an engine, it should be checked for free working of all parts and for cleanliness and condition of parts. This is particularly important when the governor to be installed has not been overhauled and reassembled by the personnel making the installation on the engine.

### **226. INSTALLATION ON ENGINE.**

a. Procedure for installation of the governor on the engine, when the engine is installed in the tank, is outlined in TM 9-753 and TM 9-758.

b. Procedure for the installation of the governor on the engine, when the engine assembly is removed from the tank, is outlined in section VII, paragraph 167 of this manual.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section XII**

**INJECTOR ASSEMBLY**

	<b>Paragraph</b>
Inspection while on engine . . . . .	227
Trouble shooting . . . . .	228
Removal from engine . . . . .	229
Disassembly of the injector assembly . . . . .	230
Inspection of the injector assembly . . . . .	231
Overhaul of the injector assembly . . . . .	232
Assembly of the injector assembly . . . . .	233
Preinstallation inspection . . . . .	234
Installation on engine . . . . .	235

**227. INSPECTION WHILE ON ENGINE.**

The condition of an injector cannot be inspected unless it is removed from the engine. However, a check of the following important adjustments can be made:

- a. Check injector timing (par. 163).
- b. Check positioning of injector control racks (par. 167).
- c. Check equalization of injectors (par. 167).


**228. TROUBLE SHOOTING.**

Lack of engine power, uneven running, excessive vibration, and a tendency to stall when idling may be caused by a compression loss, faulty injector action, poor adjustment of the throttle and injector control linkage, or improper adjustment of the governor. Therefore, the trouble shooting procedure given in TM 9-753 and TM 9-758, which outlines symptoms and corrective measures involving injector operation and the related adjustments, should first be followed to determine whether the trouble lies in injector operation or in some other source.

**229. REMOVAL FROM ENGINE.**

The procedure outlined in paragraph 52 for the removal of injectors may be followed, either when the engine is installed or when it is removed from the tank. When injector operation is at fault, the adjustments given in the preceding paragraph may be made, if necessary, or the injector removed and inspected (par. 231).

# INJECTOR ASSEMBLY



**Figure 175—Removing Injector Nut**

## 230. DISASSEMBLY OF THE INJECTOR ASSEMBLY.

### a. Equipment.

Brush, wire	Tool KM-J-1241-A
Hammer, steel	Tool KM-J-1261-A
Screwdriver	Tool KM-J-1290
Tool KM-J-1238	Tool KM-J-1330

### b. Procedure (figs. 175, 176, 177, 178 and 179).


(1) Clean off the spray tip (2, fig. 177) of the injector.

(2) Put the injector body vise jaws KM-J-1261-A into a vise and clamp the injector assembly.

(3) Using the injector nut wrench KM-J-1238 (fig. 175), remove the injector body nut (1, fig. 177). NOTE: Care should be taken in lifting the nut away from the injector spray tip. Check the valve parts so that they will stay in place.

(4) Lift off the injector body seal ring (12, fig. 176) and the spill deflector (8). NOTE: Sometimes the spill deflector and seal ring will come off with the nut.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



**Figure 176—Injector Assembly with Nut Removed**

(5) Lift off the spray tip (2), the spherical check valve stop (3), the spherical check valve spring (4), and the spherical check valve and seat assembly (5). Remove the flat check valve (6) and the flat check valve spacer (7).


(6) Lift off the bushing part of the injector plunger and bushing assembly (9, fig. 178), leaving the assembly.

(7) Remove the remaining assembly from the vise, turn it over, and shake out the bushing of the rack assembly gear retainer (10) and the rack assembly gear (11).

(8) Pull out the rack assembly (23) from the side of the injector body (13).

(9) Insert special tool KM-J-1290 under the plunger spring (15, fig. 179). Depress the injector follower guide (17) by hand and, using a screwdriver, pry out the stop pin (14). Lift out the injector follower guide (17), the injector follower pin (16), the plunger spring (15), and the plunger assembly.

INJECTOR ASSEMBLY




- 1. NUT, INJECTOR BODY
- 2. TIP, SPRAY
- 3. STOP, SPHERICAL CHECK VALVE
- 4. SPRING, SPHERICAL CHECK VALVE
- 5. VALVE AND SEAT, SPHERICAL CHECK; ASSEMBLY
- 6. VALVE, FLAT CHECK
- 7. SPACER, FLAT CHECK VALVE
- 8. DEFLECTOR, SPILL
- 9. PLUNGER AND BUSHING, INJECTOR; ASSEMBLY
- 10. RETAINER, RACK ASSEMBLY GEAR
- 11. GEAR, RACK ASSEMBLY
- 12. RING, INJECTOR BODY SEAL
- 13. BODY, INJECTOR
- 14. PIN, STOP
- 15. SPRING, PLUNGER
- 16. PIN, INJECTOR FOLLOWER
- 17. GUIDE, INJECTOR FOLLOWER
- 18. FOLLOWER, INJECTOR
- 19. CAP, INJECTOR FILTER
- 20. GASKET, INJECTOR FILTER CAP
- 21. SPRING, INJECTOR FILTER
- 22. ELEMENT, INJECTOR FILTER
- 23. RACK; ASSEMBLY

Figure 177—Component Parts of Injector Assembly


RA PD 11337



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



**Figure 178—Bottom of Injector Body with Lower End of Plunger Exposed**



**Figure 179—Compressing Injector Spring to Release Injector Follower Pin**

## **INJECTOR ASSEMBLY**

(10) **Disassemble** the spring and plunger assembly by pulling off the follower spring (15, fig. 177), the follower pin (16), the follower (18), and the plunger (9) from the follower guide (17).

(11) **Returning** to the assembly remaining in the vise, by using injector filter cap wrench KMO-240, remove the injector filter caps (19), and remove the injector filter cap gaskets (20). Because the gaskets become deformed when the filter cap (20) is tightened, they will be stuck tightly in the recess at the top of the filter cap threads. They may be removed by laying the filter cap (20) on its side on a metal surface and tapping lightly with a small steel hammer around the edge of the gasket. In this manner the gasket is stretched, and it may be removed. Remove the two injector filter springs (21), and remove the injector filter elements (22). **NOTE:** One of the two filters is an inlet filter, the other an outlet filter. In order to reassemble them in their proper positions, mark one of the filters plainly for identification, at the same time indicating its location on the body.

### **231. INSPECTION OF THE INJECTOR ASSEMBLY.**

All parts of the disassembled injector assembly should be carefully inspected for cleanliness and wear. See overhaul procedure outlined in paragraph 232 below.

### **232. OVERHAUL OF THE INJECTOR ASSEMBLY (fig. 177).**

The disassembled injector assembly should be cleaned and repaired and all defective parts replaced, as follows:

- a. Clean the injector components using SOLVENT, dry cleaning.
- b. Clean out the holes in the spray tip (2, fig. 177), using a 0.006-inch wire and the holder from the cleaning kit KM-J-1241-A. Clean inside the spray tip (2) with drill provided in the cleaning kit. Blow out the tip with filtered, compressed air from the tip end in order to prevent blowing air back into the spray holes.
- c. Brush the spill deflector (8) with the large brush from the kit, to remove tarnish.
- d. Clean the bushing cross holes of the injector bushing and plunger assembly (9) with a small drill from the kit.
- e. Clean the inside of the injector plunger and bushing assembly (9), removing all trace of tarnish and gum with a small brush and a rod covered with tissue.
- f. Clean the injector plunger (9). After cleaning, check the fit of the plunger and bushing. Movement should be free without binding or looseness. **NOTE:** Plungers and bushings are mated pairs and etched with identical numbers. Do not attempt lapping of plunger and bushing on the bore diameter or fits will be destroyed.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

g. Flush out the injector body (13). Brush thoroughly and dry with filtered compressed air.

h. Flush the injector filter elements (22) and blow with compressed air. **NOTE:** A good method of checking filters is to blow through them when they are placed before the mouth in order to determine whether they are usable. If plugged, the parts should be replaced.

i. Clean the teeth of the rack assembly gear (11) and rack assembly (23), using a wire brush.

j. Reconditioning of the lapped surfaces of the spray tip (2), the check valve seat (5), the flat check valve (5), the flat check valve spacer (7), and the plunger bushing (9) should be done by a lapping block. **NOTE:** The contacting surfaces of these component parts are lapped, to insure perfect fit and accurate operation to prevent leaks. The original surfaces, free from dirt and wear, are so smooth that the parts will adhere to each other. If surfaces of removed and cleaned parts are discolored, the parts should be reconditioned by lapping in a figure eight motion on the lapping block KM-J-1330, and using the Norton grinding and polishing compound 600X, or its equivalent. The spherical check valve and seat cannot be lapped but should be replaced if the seats show any pitting, ridging, or other evidence of leakage. This leakage will be noted in testing the injector, as indicated in a later step.

**233. ASSEMBLY OF THE INJECTOR ASSEMBLY.**

**a. Equipment.**

Screwdriver	Tool KM-J-1290
Tool KM-J-1238	Vise
Tool KM-J-1261-A	

**b. Procedure** (figs. 175, 176, 177, 178 and 179).

During the assembly of the injector, it is advisable to flush each part in a pan of clean fuel oil before installing it into the assembly. Damaged or excessively worn parts should be replaced. Assemble the injector assembly as follows:

(1) Place the injector body in vise jaw KM-J-1261-A, and install the filter elements (22, fig. 177), filter springs (21), filter cap gaskets (20), and caps (19). Using the injector filter cap wrench KM-KMO-240, tighten the filter caps (19). **NOTE:** The elements should be assembled with the washer side downward, and new filter cap gaskets should always be used.

(2) Invert the injector body in a vise and install the rack assembly (23) so that the key slot on the body is exactly between the two marks on the rack teeth.

## INJECTOR ASSEMBLY

(3) Line up the mark on the tooth of the rack assembly gear (11) with the two marks on the rack assembly (23), and drop the gear in place. Check to see that the mark on the gear tooth is between the two marks on the rack teeth. Install the rack gear spacer (10).

(4) Install the plunger bushing (9) with the stop pin, engaging the slot in the body.

(5) Install the spill deflector (8).

(6) Holding the spherical check stop (3) in your fingers, assemble the spring and valve (5). Holding the spring tip (2) in the opposite hand, place the stop (3), spring (4), and spherical valve (5) in the tip (2) with the spherical valve outward.

(7) Assemble the spherical check valve seat (5) over the valve (5). Place the flat check valve (6) in the counterbore of the valve seat (5). Install the flat check valve seat (5). This complete unit can be placed on the plunger and bushing assembly (9).

(8) Install a new body seal ring (12), and install the body nut (1) over the spray tip (2) and tighten by hand, making sure the parts inside the body nut can seat perfectly without forcing. Turn the body nut (1) down all the way by hand and rotate the end of the spring tip (2) by hand to insure proper seating of parts. Then tighten the nut (1), using tool KM-J-1238 (fig. 175). NOTE: Before tightening with a wrench, observe whether the nut is down close to its seat, that is, very close to the shoulder on the body. If not, it indicates that the valve parts have not properly entered the bore in the nut. Remove the nut and restack the parts.

(9) Reverse the position of the injector in tool KM-J-1261 and assemble the plunger and bushing assembly (9) and the follower (18) into the follower guide (17). Install the follower pin (16) through the guide into the follower.

(10) Install the plunger spring (15) on the follower guide (17), and install in the injector body (13) with the flat side of the plunger in line with the flat side of the hole rack gear (11).


(11) Using tool KM-J-1290, depress the plunger spring (15). Turn the follower guide (17) slightly to line up the slot for the stop pin (14), and install the pin (14) into the injector body (13). Remove tool KM-J-1290, to allow the spring to lock the stop pin (14) in place and seat on the injector body (13).

(12) Using the handle provided with tool KM-J-1261, hold the injector in vise, and compress the plunger all the way down. The injector rack assembly (23) must move freely between no fuel and full fuel positions.

(13) Test the injector assembly for leaks and popping pressure (par. 234).

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

TOOL KM-J-1261-A



RA PD 11241

**Figure 180—Testing or Popping the Injector**

**234. PREINSTALLATION INSPECTION.**

After an injector has been overhauled or supplied for replacement in the engine, it should first be tested by a test called popping the injector.

**a. Equipment.**

Beaker

Tool KM-J-1261-A

Can, Oil

Vise

**b. Procedure** (fig. 180). Place the injector in test fixture. Use an oil can to introduce fuel into one of the injector openings, until fuel flows from the other openings. Set a beaker under and surrounding the injector spray tip, so that fuel injected from the tip hits the inside of the beaker. Always use the beaker and keep hands away from the spray tip when "popping" the injector; otherwise, the fuel from the spray tip will penetrate the skin and may cause blood poisoning. To determine whether all seven holes in the spray tip are open, push the injector rack in to full fuel position, and press the test handle down on the plunger follower with a quick motion, repeating this several times.

Fuel should then be discharged from all seven holes in the spray tip. If the check valve opening pressure is satisfactory, considerable down-

## **INJECTOR ASSEMBLY**

ward pressure will be required on the fixture handle to open the check valve and discharge the fuel through the seven holes. If considerable pressure is not required on the fixture handle to open the check valve so that the fuel is discharged in a fog from the spray tip, the valve opening pressure is too low. To test for a check valve leak or dribble, wipe or blow all fuel from the spray tip and press down firmly on the fixture handle to the point where the check valve is about to open. (Do not force the check valve open.) Continue to hold the handle down against check valve pressure. Then no dribble should take place at the spray tip. If dribble does occur, the check valve is not seating properly. If the injector does not pass the above three tests satisfactorily, it should be disassembled, carefully and thoroughly cleaned, and any worn or corroded parts replaced. **NOTE:** Never remove filters from injector unless unit is entirely disassembled, because there is a possibility of dirt entering the injector when the filters are removed.

### **235. INSTALLATION ON ENGINE.**

Procedure outlined in paragraph 161 can be followed whether the engine is removed from, or installed in, the tank.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section XIII**

**OIL COOLER AND ADAPTER ASSEMBLY**

	<b>Paragraph</b>
Inspection while on engine .....	236
Trouble shooting .....	237
Removal from engine .....	238
Disassembly of the oil cooler and adapter assembly .....	239
Inspection of the oil cooler and adapter assembly .....	240
Overhaul of the oil cooler and adapter assembly .....	241
Assembly of the oil cooler and adapter assembly .....	242
Preinstallation inspection .....	243
Installation on engine .....	244

**236. INSPECTION WHILE ON ENGINE.**

The installed oil cooler and adapter assembly should be inspected periodically for leaks at the gasket, the water inlet and outlet, and the bypass inlet.

**237. TROUBLE SHOOTING.**

When there is insufficient lubricating oil pressure, the oil cooler should be removed and inspected to see if it is clogged, providing one or more of the other possible causes of inadequate pressure, as outlined in trouble shooting procedure in TM 9-753 and TM 9-758, are not responsible for the condition.

**238. REMOVAL FROM ENGINE.**

a. To remove the oil cooler and adapter assembly from the engine, when the engine is installed in the tank, see TM 9-753 and TM 9-758. However, since removal under this condition necessitates the removal of a number of other components before access to the cooler can be obtained, whenever possible, the oil cooler should be serviced when the engine is removed from the tank.

b. To remove the oil cooler and adapter assembly from the engine, when the engine is removed from the tank, refer to paragraph 58.

**239. DISASSEMBLY OF THE OIL COOLER AND ADAPTER  
ASSEMBLY (fig. 181).**

**a. Equipment.**

Wrench, socket,  $\frac{7}{8}$ -in.

**b. Procedure.**

In removing this assembly from the engine, as outlined in paragraph 40, remove the housing, including the oil cooler assembly from the

## OIL COOLER AND ADAPTER ASSEMBLY

adapter, and then remove the adapter as an assembly from the engine. The balance of the disassembly procedure is as follows:

(1) Using a  $\frac{7}{8}$ -inch socket wrench, remove the plug (1, fig. 181) and gasket (2) from the adapter assembly.

(2) Remove the relief valve spring (3) and the relief valve (4).

(3) Lift the oil cooler assembly (13) from the oil cooler housing (15), and remove the gasket.

### 240. INSPECTION OF THE OIL COOLER AND ADAPTER ASSEMBLY.

Inspect the condition of all parts and inspect the relief valve seat for wear.

### 241. OVERHAUL OF THE OIL COOLER AND ADAPTER ASSEMBLY.

All parts found by inspection to be defective should be replaced and parts should be cleaned and serviced as follows:

- a. Blow out the relief valve oil holes with compressed air.
- b. Wash the adapter and blow out all oil passages.
- c. Wash the oil cooler, flushing cleaning compound through the passages, under pressure if possible. If steam is available, it should be used for cleaning the oil cooler.

### 242. ASSEMBLY OF THE OIL COOLER AND ADAPTER ASSEMBLY (fig. 181).

#### a. Equipment.

Shellac

Wrench, socket,  $\frac{7}{8}$ -in.

#### b. Procedure.

(1) Shellac a new gasket (14, fig. 181) to the housing (15) and install the oil cooler assembly into the housing.

(2) Shellac a new gasket (12) to the oil cooler assembly (13).

(3) Install the relief valve (4), the spring (3), the gasket (2), and the plug (1) into the oil cooler adapter assembly. Tighten the plug, using a  $\frac{7}{8}$ -inch socket wrench. NOTE: The two gaskets (5) on the back of the adapter are shellacked to the cylinder block when the adapter is installed on the engine.

### 243. PREINSTALLATION INSPECTION.

Before the oil cooler and adapter assembly is installed on the engine, all parts should be inspected for condition, fit, and cleanliness.


### 244. INSTALLATION ON ENGINE.

a. TM 9-753 and TM 9-758 outline the procedure for installing the oil cooler and adapter assembly on the engine when the engine is installed in the tank.

b. Procedure for the installation of the oil cooler and adapter assembly on the engine, when the engine is removed from the tank, is outlined in paragraph 155 of this manual.



ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



KA PD 11340

Figure 181—Components of Oil Cooler Assembly

**OIL COOLER AND ADAPTER ASSEMBLY**

Number	Item	Number	Item
1—	Plug, Relief Valve	9—	Bolt, Adapter to Cylinder Block—Lower Hole
2—	Gasket, Relief Valve Plug	10—	Bolt, Adapter to Cylinder Block—Side Holes
3—	Spring, Relief Valve	11—	Bolt, Adapter to Cylinder Block—Upper Hole
4—	Valve, Relief	12—	Gasket, Oil Cooler to Adapter
5—	Gasket, Adapter to Cylinder Block	13—	Cooler, Oil—Assembly
6—	Bolt, Adapter to Housing	14—	Gasket, Cooler to Housing
7—	Washer, Lock	15—	Housing, Oil Cooler (Model LA24M Engine)
8—	Adapter, Oil Cooler—Assembly (Model LA24M Engine)	16—	Bolt, Housing to Adapter
		17—	Washer, Lock

RA PD 11340A

**Nomenclature for Figure 181—Components of Oil Cooler Assembly**

**ORDNANCE MAINTENANCE--GENERAL MOTORS TWIN DIESEL 6-71**  
**POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section XIV**

**AIR HEATER ASSEMBLIES**

	<b>Paragraph</b>
Inspection while on engine . . . . .	245
Trouble shooting . . . . .	246
Removal from engine . . . . .	247
Disassembly of the air heater assemblies . . . . .	248
Inspection of the air heater assemblies . . . . .	249
Overhaul of the air heater assemblies . . . . .	250
Assembly of the air heater assemblies . . . . .	251
Preinstallation inspection . . . . .	252
Installation on engine . . . . .	253

**245. INSPECTION WHILE ON ENGINE.**

If two or three strokes of the air heater pump, which is mounted on the right of the instrument panel, fail to produce a fire while the engine is being turned over at wide-open throttle, it is advisable to stop turning over the engine, and check possible causes of failure. Assuming that the engine is in otherwise good running order, while the engine is turning over at 80 revolutions per minute or more, the air heater assembly should be checked for:

- a. Failure of ignition.
- b. Poor oil spray.

**NOTE:** It is necessary to remove the air heater assembly from the engine to make the above two checks.

**246. TROUBLE SHOOTING.**

The procedure for correcting possible failure of ignition or poor oil spray, as outlined in **a** and **b** of the preceding paragraph, is covered in subsequent paragraphs 249 and 250, covering inspection and overhaul of the air heater assemblies.

**247. REMOVAL FROM ENGINE.**

a. Refer to TM 9-753 and TM 9-758 for procedure to remove the air heater assemblies from the engine when the engine is installed in the tank.

b. Refer to paragraph 44 for procedure to remove the air heater assemblies when the engine is removed from the tank.

AIR HEATER ASSEMBLIES




Figure 182—Components of Air Heater

**TM 9-1750G**  
**248-251**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71**  
**POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**248. DISASSEMBLY OF THE AIR HEATER ASSEMBLIES.**

**a. Equipment.**

Wrench, socket,  $\frac{7}{16}$ -in.

Wrench, socket,  $\frac{5}{8}$ -in.

**b. Procedure** (fig. 182). In disassembling the engine, the air heater covers are removed. The balance of the disassembly is done as follows:

(1) Using a  $\frac{5}{8}$ -inch socket wrench, remove the nut and pull out the insulator assembly from the air heater body. Remove the insulator gasket.

(2) Using a  $\frac{7}{16}$ -inch socket wrench, remove the electrode and lock washer.

(3) Using a  $\frac{5}{8}$ -inch socket wrench, remove the nozzle. Then remove the washer, filter, and the filter spring.

(4) Remove the other air heater assembly in the same manner.

**249. INSPECTION OF THE AIR HEATER ASSEMBLIES.**

The disassembled air heater assembly should be inspected as follows:

**a.** The gap between the electrodes should be checked, and, if necessary, the wire electrode reset to approximately  $\frac{1}{8}$  inch.

**b.** The spray nozzle should be inspected for clogging.

**c.** Inspect the condition of all parts.

**250. OVERHAUL OF THE AIR HEATER ASSEMBLIES.**

All parts found to be defective, when making the inspection outlined in the preceding paragraph, should be replaced. Parts should be cleaned and serviced in this manner:

**a.** Wash all parts and blow out all body oil passages with compressed air.

**b.** Blow out the filter with compressed air, and replace if necessary.

**c.** Remove the metering screw from the nozzle cap. Then clean out the oil channels on the end of the screw, and blow out the oil passages. Clean the hole in the end of the nozzle cap.

**d.** Reinstall the metering screw in the nozzle.

**251. ASSEMBLY OF THE AIR HEATER ASSEMBLIES.**

**a. Equipment.**

Wrench,  $\frac{7}{16}$ -in.

Wrench, socket,  $\frac{5}{8}$ -in.

**b. Procedure** (fig. 182).

(1) Install the filter spring into the air heater body.

(2) Install the filter and the washer.

(3) Install the nozzle. Tighten with a  $\frac{5}{8}$ -inch socket wrench.

(4) Using a  $\frac{7}{16}$ -inch wrench, install and tighten the electrode and the washer.

## **AIR HEATER ASSEMBLIES**

- (5) Install the insulator gasket and the insulator assembly, using a  $\frac{5}{8}$ -inch socket wrench to install and tighten the nut.
- (6) Assemble the other air heater assembly in the same manner.

### **252. PREINSTALLATION INSPECTION.**

Before installing an air heater assembly, make the following inspections:

- a. Check the gap between electrodes. It should be approximately  $\frac{1}{8}$  inch.
- b. If not previously checked, inspect the spray nozzle to be sure that it is not plugged. Be sure that the nozzle gasket does not leak.

### **253. INSTALLATION ON ENGINE.**

- a. Refer to TM 9-753 and TM 9-758 for installation procedure when the engine is installed in the tank.
- b. Refer to paragraph 170 of this manual for procedure when the engine is removed from the tank.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71**  
**POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section XV**

**ENGINE TRANSFER GEAR HOUSING ASSEMBLY**

	<b>Paragraph</b>
Inspection while on engine .....	254
Trouble shooting .....	255
Removal from engine .....	256
Disassembly of the engine transfer gear housing assembly .....	257
Inspection of the engine transfer gear housing assembly .....	258
Overhaul of the engine transfer gear housing assembly .....	259
Assembly of the engine transfer gear housing assembly .....	260
Preinstallation inspection .....	261
Installation on engine .....	262

**254. INSPECTION WHILE ON ENGINE.**

It is impossible to inspect the condition of the engine transfer gear housing assembly without first removing it from the engine. See paragraph 256, which follows.

**255. TROUBLE SHOOTING.**

Barring accidents, minimum servicing of the transfer gear housing assembly should be required, providing the unit has proper maintenance. In event of failure of engine power to be transmitted efficiently to the power train of the tank, maintenance personnel should listen for unusual sounds in the power train as well as in the transfer gear housing assembly, which may be an indication of worn or otherwise defective parts.

**256. REMOVAL FROM ENGINE.**

a. The engine transfer gear housing assembly can be removed from the tank without removing the engine assembly. This procedure is outlined in TM 9-753 and TM 9-758.

b. The procedure for removal of the assembly from the engine, when the engine assembly is removed from the tank, is outlined in paragraph 36 of this manual.


**257. DISASSEMBLY OF THE ENGINE TRANSFER GEAR**  
**HOUSING ASSEMBLY.**

**a. Equipment.**

Wrench, socket,  $\frac{3}{16}$ -in.

Wrench, socket,  $\frac{5}{8}$ -in.

ENGINE TRANSFER GEAR HOUSING ASSEMBLY



RA PD 11344

Figure 183—Components of Engine Transfer Gear Housing



ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 184—Cross Section of Engine Transfer Gear Housing

## ENGINE TRANSFER GEAR HOUSING ASSEMBLY

### b. Procedure (figs. 183, 184, 185 and 186).

(1) Hold the gears from rotating, and, using a  $\frac{5}{8}$ -inch socket wrench, remove the bolts and lock washers on all three gears (fig. 185). Remove the engine driven gear, and then remove the two engine drive gears.


(2) Turn the gear housing over on the opposite side and remove the two engine drive shaft covers and gaskets. Use a  $\frac{9}{16}$ -inch socket wrench to remove the remaining two bolts holding each cover.

(3) Remove the nuts from the engine drive shafts. Remove the self-locking nut from the end of the driven shaft. Remove the engine driven gear flange from the splines on the end of the engine driven shaft.

(4) Using a  $\frac{9}{16}$ -inch socket wrench, remove the six bolts and lock washers holding the cover and engine driven shaft seal (4, fig. 183). Remove the seal from the driven shaft cover (23, fig. 183).

(5) Remove the driven shaft assembly through the bearing opening in the housing. Remove the engine driven shaft bearing from the splined end of the engine driven shaft (fig. 183).

(6) Remove the two engine drive shafts with bearings (fig. 183). Remove the two engine drive shaft bearings from the drive shafts.



**Figure 185—Engine Transfer Gear Housing with Driven Gear and Drive Gears in Place**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**


**258. INSPECTION OF THE ENGINE TRANSFER GEAR  
HOUSING ASSEMBLY.**

Inspect the engine transfer gears and housing as follows:

- a. Inspect all bearings for smoothness and wear.
- b. Inspect gear teeth for chipping, wear, or breakage.
- c. Inspect the oil seal for evidence of leakage or damage.
- d. Inspect the flange for oil seal contact.
- e. Check shaft splines for wear.

**259. OVERHAUL OF THE ENGINE TRANSFER GEAR HOUSING  
ASSEMBLY.**

Wash all bearings and gears of the disassembled transfer gear housing assembly. Replace gears having broken, chipped, or worn teeth, and replace other parts which have been found to be defective, when making the inspection outlined in the previous paragraph. NOTE: Only gears used after power plant 6046-354 for 30 miles per hour tanks will be available for service. It will be necessary, therefore, to replace gears in complete sets on any units prior to 6046-354 when any one of them becomes defective.



**Figure 186—Engine Transfer Gear Housing with Driven Gear  
and Drive Gears Removed**

## ENGINE TRANSFER GEAR HOUSING ASSEMBLY

### 260. ASSEMBLY OF THE ENGINE TRANSFER GEAR HOUSING ASSEMBLY.

#### a. Equipment.

Block, wooden  
Hammer, soft  
Press, arbor  
Rag


Tool KM-J-1910  
Tool KM-J-1916  
Wrench, socket,  $\frac{9}{16}$ -in.  
Wrench, socket,  $\frac{5}{8}$ -in.

#### b. Procedure (figs. 187, 188, 189 and 190).

(1) Install the two engine drive shaft bearings onto the drive shafts, using tool KM-J-1910 (fig. 187). Pound them onto the shaft with a soft hammer, making sure that the bearing stop ring is toward the top of the shaft when installing. If an arbor press is available, the bearing can be pressed on, rather than driven on.

(2) Place the shafts through the holes provided for the shafts in the housing, with the splined end first. Tap the bearing end shaft into position with a soft hammer (fig. 188).

(3) Place the engine driven shaft bearing on the splined end of the engine driven shaft, and tap it onto the shaft, using the engine driven



**Figure 187 — Installing Bearing on Engine Drive Shaft**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

shaft flange as a driving tool (fig. 189). A block of wood should be used between the hammer and the flange. Remove the flange.

(4) Place the driven shaft assembly through the bearing opening in the housing, with the splined end out, and tap it into place with a soft hammer.


(5) Place the self-locking nuts on the two drive shafts and tighten slightly.

(6) Drive the oil seal with the sealing edge entering the driven shaft cover first, using tool KM-J-1916 (fig. 190).

(7) Place a new cover gasket onto the shaft cover, with the seal installed over the driven shaft, and attach the cover to the housing with the six bolts and lock washers. Tighten the bolts and lock washers, using a  $\frac{1}{8}$ -inch socket wrench.

(8) Slide on the engine driven gear flange over the splines on the end of the engine driven shaft. Put the self-locking nut on the driven shaft end and tighten slightly.


(9) Turn the gear housing over so that the shafts are accessible for installing the gears (fig. 186). Then install the two engine drive gears, HOUSING ENGINE TRANSFER GEAR BEARING, ENGINE DRIVE SHAFT




RA PD 11347

**Figure 188—Installing Engine Drive Shaft and Bearing in  
Transfer Gear Housing**

**ENGINE TRANSFER GEAR HOUSING ASSEMBLY**



**Figure 189—Installing Engine Driven Shaft Bearing**



**Figure 190—Installing Oil Seal on Engine Driven Shaft Cover**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

putting the concave side next to the housing, and install the eight bolts and lock washers holding each gear in place (fig. 185). Tighten the bolts slightly with a  $\frac{5}{8}$ -inch socket wrench.

(10) Install the driven gear in a similar manner.

(11) Keep the gears from rotating by placing a clean rag between the gear teeth. Then securely tighten all the bolts on all three gears.

(12) Replace the two drive shaft covers and hold them temporarily with four bolts, in order to protect the bearings from dirt. Note that these covers must be removed for final tightening of the drive shaft nuts, when the engine transfer gears and the housing assembly are assembled to engines. Final tightening of the driven shaft nut should also be done at this time.

**261. PREINSTALLATION INSPECTION.**

Inspect all gears and bearings to be sure that they are in perfect condition before installing the engine transfer gear housing assembly. A new gasket should be installed. All parts should be thoroughly clean.

**262. INSTALLATION ON ENGINE.**

a. TM 9-753 and TM 9-758 outline the steps to follow in installing the engine transfer gear housing assembly on the engine when the engine assembly is installed in the tank.

b. Paragraph 179 of this manual outlines the procedure for installing the assembly when the engine assembly is removed from the tank.

## Section XVI

# CLUTCH HOUSING AND CLUTCH ASSEMBLIES

	Paragraph
Inspection while on engine .....	263
Trouble shooting .....	264
Removal from engine .....	265
Disassembly of the clutch housing assembly .....	266
Inspection of the clutch housing assembly .....	267
Overhaul of the clutch housing assembly .....	268
Assembly of the clutch housing assembly .....	269
Disassembly of the clutch assembly .....	270
Inspection of the clutch assembly .....	271
Overhaul of the clutch assembly .....	272
Assembly of the clutch assembly .....	273
Preinstallation inspection .....	274
Installation on engine .....	275

## 263. INSPECTION WHILE ON ENGINE.

An inspection of the clutch housing and clutch assemblies cannot be made while these assemblies are installed on the engine. See paragraph 265 for removal procedure.

## 264. TROUBLE SHOOTING.

Faulty clutch operation, such as slipping, grabbing, or rattling should be looked for while using the clutch to shift back and forth through the gears when driving the vehicle. If a complete clutch adjustment and clutch pedal adjustment, as outlined in TM 9-753 and TM 9-758, does not remedy the trouble, proceed as follows:

a. Disassemble, inspect, overhaul, and reassemble the clutch housing assembly (pars. 266, 267, 268 and 269).

b. If step a does not locate the trouble, disassemble, overhaul and reassemble the clutch assembly (pars. 270, 271, 272 and 273).

## 265. REMOVAL FROM ENGINE.

a. Refer to TM 9-753 and TM 9-758 for procedure to follow in removing the clutch housing and clutch assemblies from the tank without removing the engine.

b. Refer to paragraphs 37 and 59 of this manual for steps to follow in removing the clutch housing and clutch assemblies from the engine, when the engine is removed from the tank.



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**266. DISASSEMBLY OF THE CLUTCH HOUSING ASSEMBLY.**

**a. Equipment.**

Hammer

Tool KM-J-943A

Tool KM-J-1907

Wrench, open-end,  $\frac{3}{8}$ -in.

Wrench, open-end,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{3}{8}$ -in.


**b. Procedure (figs. 191, 192, 193 and 194).**

(1) Inspect the seals in the guide and seal assemblies for wear and evidence of leakage (fig. 191). If the seals are faulty, remove them, using puller tool KM-J-943A and tapping them out with a hammer (fig. 192).

(2) Using puller tool KM-J-943A, remove the driven shaft front bearing from the housing.

(3) Using a  $\frac{3}{8}$ -inch socket wrench, remove the six bolts and lock washers holding the clutch release bearing guide and seal assembly to the clutch housing, and remove the guide and seal assemblies and gaskets (fig. 191).

(4) Using a  $\frac{3}{4}$ -inch open-end wrench, remove the bolts, lock washers, and flat washers from the ends of the clutch shifter shafts (fig. 191). Remove the shims, packing washers, and packings from the shafts. Then



RA PD 11431

**Figure 191—Clutch Housing Assembled**

## CLUTCH HOUSING AND CLUTCH ASSEMBLIES

remove the Woodruff key at the shift lever end of each shifter shaft and remove the packings and the packing washers.

(5) Open the lock ring holding the packing on the bottom of each shaft inside the clutch housing, and move the shafts down through the lower bearings as far as they will go. Remove the two packings, the packing washers, and the lock ring from the top of each shaft.

(6) Slide the shafts up through the top bearing as far as possible and remove the washer packing and lock ring from the other end of each shaft.


(7) Using a  $\frac{5}{8}$ -inch open-end wrench, remove the bolts locking the clutch shifter yokes to the shafts (fig. 197). Tap the yokes out of position far enough to remove the two Woodruff keys (upper and lower). Pull out the shafts.

(8) Drive the four shifter shaft bearings out from the housing, using special tool KM-J-1907 (fig. 193).

### 267. INSPECTION OF THE CLUTCH HOUSING ASSEMBLY.

The disassembled clutch housing assembly should be inspected as follows:

- a. Examine the shifter shaft bearings for wear.
- b. Inspect the shafts for wear and score.




RA PD 11432

**Figure 192—Tools Used in Disassembly and Assembly of Clutch Housing**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

- c. Inspect the yokes for wear where they contact the bushings on the release bearing sleeves.
- d. Inspect the driven shaft bearing for wear and smoothness.



**Figure 193—Tools Used in Removing and Installing Clutch  
Shifter Shaft Bearings**

**268. OVERHAUL OF THE CLUTCH HOUSING ASSEMBLY.**

When all parts of the assembly have been disassembled, they should be washed thoroughly. All lubrication holes should be blown out with compressed air. Defective parts should be replaced.

**269. ASSEMBLY OF THE CLUTCH HOUSING ASSEMBLY.**

**a. Equipment.**

Shellac	Wrench, open-end, $\frac{5}{8}$ -in.
Tool KM-J-1906	Wrench, open-end, $\frac{3}{4}$ -in.
Tool KM-J-1908	Wrench, socket, $\frac{11}{16}$ -in.
Tool KM-J-1912	Wrench, socket, $\frac{5}{8}$ -in.

**b. Procedure (figs. 191, 192 and 194).**

- (1) Drive the four shifter shaft bearings into the housing, using special tool KM-J-1906 (fig. 193).
- (2) Oil each shaft and insert it through the bearing into the housing, entering it with the large groove end first, from the top of the housing.
- (3) Install the lower Woodruff key for the shifter yoke on each shaft. Install the yoke on the shaft and slide the shaft down until the upper Woodruff key can be installed. Install the key and position the yoke on the shaft to permit installation of the bolts. Install the two bolts on each yoke (fig. 191).

## CLUTCH HOUSING AND CLUTCH ASSEMBLIES

(4) Install the lower lock ring, the packing washer, and the two packings on the lower end of the shaft, sliding them past the ring groove and up to the yoke.


(5) Push the shafts through the lower bearing as far as they will go and install the lock ring, the washer, and the two packings in position on the upper ends of the shafts.

(6) Raise the shafts through the upper bearings into their proper position and slide the lower packings, the washer, and the lock ring into position. Install the lower packing and washer on the lower end of each shaft outside the housing, and install the Woodruff keys. Install the packing and the packing washer on the upper end of each shaft, outside the housing.

(7) Install the shims, the thrust washer, lock washer, and the bolt on the top end of each shaft, using a  $\frac{3}{4}$ -inch open-end wrench to tighten the bolt.

(8) If the guide seals and the seal assembly are to be replaced, drive in the new seals, using tool KM-J-1912 (fig. 192). NOTE: Seals should be soaked in oil before installing.


(9) Shellac new gaskets on the guide and seal assemblies and install the assemblies in place in the housing, with the bosses in a vertical position (fig. 191). Using a  $\frac{9}{16}$ -inch socket wrench, install and tighten the



RA PD 11434

Figure 194—Spacing Clutch Shifter Yokes  
303

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



RA PD 11435

Figure 195—Components of Clutch Assembly

CLUTCH HOUSING AND CLUTCH ASSEMBLIES

Number	Item	Number	Item
1	Bolt, Clutch Release Bearing Sleeve	12	Washer, Lock—Clutch Release Bearing
2	Washer, Lock	13	Bearing, Clutch Release
3	Bushing, Clutch Release Bearing Sleeve	14	Cover, Clutch Release Bearing Sleeve
4	Nut, Clutch Release Bearing Sleeve	15	Bolt, Clutch Pressure Plate Release Spring
5	Pin, Cotter	16	Spring, Clutch Pressure Plate Release
6	Fitting, Clutch Release Bearing Hose	17	Spacer, Clutch Pressure Plate Release Spring
7	Coupling, Clutch Release Bearing Hose Pipe	18	Plate, Clutch Cover
8	Hose, Clutch Release Bearing	19	Hub, Clutch Spring
9	Sleeve, Clutch Release Bearing—Assembly	20	Spring, Clutch
10	Gasket, Clutch Release Bearing Sleeve Cover	21	Plate, Clutch Pressure
11	Nut, Clutch Release Bearing	22	Disk, Clutch—Assembly

RA PD 11435A

Nomenclature for Figure 195—Components of Clutch Assembly

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

six bolts and lock washers holding each guide and seal assembly to the clutch housing.

(10) Space the yokes on the shafts so that each arm is equidistant from the outer diameter of the guide and seal assembly, as shown by dimensions A on figure 194. Tighten the bolts, using a  $\frac{5}{8}$ -inch socket wrench.

(11) Lubricate the front driven shaft bearing and drive it into place in the housing, using tool KM-J-1908 (fig. 192).

**270. DISASSEMBLY OF THE CLUTCH ASSEMBLY.**

**a. Equipment.**

Cutters, side

Wrench, socket,  $\frac{1}{2}$ -in.

Hammer

Wrench, socket,  $\frac{1}{8}$  in.


Punch, brass

Wrench, socket,  $\frac{3}{4}$ -in.

Wrench, open-end,  $\frac{7}{16}$ -in.

**b. Procedure (figs. 195, 196, 197 and 198).**

(1) Remove the 12 bolts and lock washers which hold the pressure plate cover (18, fig. 195) and lift off the cover.




RA PD 11436

**Figure 196—Removing Bolts from Clutch Release Bearing  
Sleeve Assembly**

## CLUTCH HOUSING AND CLUTCH ASSEMBLIES

(2) Using a  $\frac{7}{16}$ -inch open-end wrench, remove the release bearing hose (8).

(3) Using a  $\frac{1}{2}$ -inch socket wrench, remove the six bolts and lock washers holding the release bearing sleeve to the clutch assembly (fig. 196). Using the side cutters, remove the cotter pins (5, fig. 195) from the lock nuts (4) holding the bushings (3) to the release bearing sleeve, and, using a  $\frac{3}{4}$ -inch socket wrench, remove the nuts. Then remove the bushings and the release bearing assembly sleeve. Use a hammer and a brass punch to drive the sleeve out of the clutch spring hub and off the bearing. Remove the gasket (fig. 197).



**Figure 197 — Removing Clutch Release Bearing Sleeve Assembly**

(4) Using a hammer and punch, drive down the finger on the lock washer which holds the release bearing nut in place (fig. 198). Using the same tools, drive off the release bearing nut and lift off the lock washer. Lift out the release bearing and cage (13 and 14, fig. 195).

(5) Using a  $\frac{1}{8}$ -inch socket wrench, remove the three clutch pressure plate release spring bolts which hold the three clutch pressure plate release springs in place (fig. 198). Lift off the three springs and the three spacers. Lift off the clutch spring from the pressure plate (figs. 195 and 198).

### **271. INSPECTION OF THE CLUTCH ASSEMBLY.**


Inspect the disassembled clutch assembly as follows:



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

- a. Inspect the clutch disk and hub splines for wear.
- b. Check the facings for wear and evidences of oil or glazing. If facings are worn nearly down to the rivet heads, replace the disk with a new one.
- c. Check the pressure plate for wear and flatness. If it is warped or shows evidence of overheating, the plate should be replaced.
- d. Check the release bearing for wear and smoothness.
- e. Inspect the sleeve release bearing assembly bushings for wear.
- f. Check the spring for cracks or breakage.

BOLT, CLUTCH PRESSURE PLATE RELEASE SPRING



RA PD 11438

**Figure 198—Clutch Assembly with Release Bearing Sleeve Assembly Removed**

**272. OVERHAUL OF THE CLUTCH ASSEMBLY.**

After the clutch assembly has been disassembled, all parts except the disk should be washed, and all parts which were found to be worn or defective when making the inspection outlined in the previous paragraph should be replaced.

**273. ASSEMBLY OF THE CLUTCH ASSEMBLY.**

**a. Equipment.**

Hammer

Punch

Wrench, open-end,  $\frac{7}{16}$ -in.

Wrench, socket,  $\frac{1}{2}$ -in.

Wrench, socket,  $\frac{9}{16}$ -in.

Wrench, socket,  $\frac{3}{4}$ -in.

## CLUTCH HOUSING AND CLUTCH ASSEMBLIES

### b. Procedure (figs. 195, 196 and 198).

- (1) Set the clutch and plate pressure spring together (fig. 195).
- (2) Install the three pressure plate release springs, the three spacers, and the bolts, and tighten the bolts with a  $\frac{9}{16}$ -inch socket wrench (fig. 198).
- (3) Oil the release bearing and then install the cage and release bearing on the clutch spring hub (fig. 198). Install the clutch release bearing lock washer, and install the nut. Using a hammer and a punch, drive up the finger on the lock washer which holds the nut from turning.
- (4) Install the release bearing assembly sleeve gasket (10, fig. 195). Using a hammer, drive the release bearing assembly sleeve into the clutch spring hub and onto the release bearing.
- (5) Install the sleeve assembly bushings (fig. 195). Use a  $\frac{3}{4}$ -inch socket wrench to install and tighten the nuts (4, fig. 195) holding the release bushings. Install cotter pins (5).
- (6) Using a  $\frac{1}{2}$ -inch socket wrench, install the six bolts and lock washers holding the release bearing assembly sleeve in place (fig. 196).
- (7) Using a  $\frac{7}{8}$ -inch open-end wrench, install the lubrication hose (fig. 195).
- (8) Install the clutch pressure plate cover.

## 274. PREINSTALLATION INSPECTION.

a. When the clutch housing assembly or clutch assembly to be installed has not been overhauled and assembled by the same personnel which is to install it on the engine assembly, the installing personnel should check all parts of the assembly for cleanliness, fit, and general condition, before installing the unit.

b. The clutch shifter shafts on the early production of these vehicles are equipped with lubrication fittings at both ends. Since the lower lubrication fittings are entirely inaccessible and since the bearings on the lower ends of the clutch shifter shafts require no additional lubrication for the length of time between engine removals, replace the lower fittings with pipe plugs at the next engine removal. On later production of these vehicles the lower lubrication fittings have been replaced with pipe plugs. Whenever an engine is removed from a vehicle, install a lubrication fitting, lubricate the bearing and replace the fitting with the pipe plug.

## 275. INSTALLATION ON ENGINE.

a. Refer to TM 9-753 and TM 9-758 for the steps to follow in installing either the clutch housing assembly or the clutch assembly, when the engine assembly is installed in the tank.


b. Refer to paragraphs 154 and 178 of this manual for steps to follow when these assemblies are to be installed on an engine assembly which has been removed from the tank.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section XVII**

**PROPELLER SHAFT ASSEMBLY**

	<b>Paragraph</b>
Inspection while installed in vehicle .....	276
Trouble shooting .....	277
Removal from the vehicle .....	278
Disassembly of the propeller shaft assembly .....	279
Inspection of the propeller shaft assembly .....	280
Overhaul of the propeller shaft assembly .....	281
Assembly of the propeller shaft assembly .....	282
Preinstallation inspection .....	283
Installation in vehicle .....	284



RA PD 11439

**Figure 199—Propeller Shaft Assembly**

**276. INSPECTION WHILE INSTALLED IN VEHICLE.**

Inspection covers, built into the "tunnel" at each end of the propeller shaft in the M3A5 Medium Tank, give access to the propeller shaft at each universal joint to facilitate inspection. The needle bearing assem-

## PROPELLER SHAFT ASSEMBLY

blies and journal trunnions, together with the splines of the slip joint, are the only parts subject to wear. Therefore, these parts should be inspected at the 50-hour or 500-mile and 100-hour or 1000-mile inspections. See TM 9-753. During these inspection operations the propeller shaft should be checked for vibration and backlash. Seals, also, should be checked for leaks.

### 277. TROUBLE SHOOTING.

Excessive vibration produced by the propeller shaft while the vehicle is in motion is a symptom of worn parts. When such a condition is encountered, the propeller shaft should be serviced or replaced.

### 278. REMOVAL FROM THE VEHICLE.

Since the propeller shaft is never removed from the tank with, and attached to, the engine assembly, the removal of the propeller shaft must always be made from the vehicle, even though the engine assembly may have been removed previously. This procedure necessitates the removal of considerable equipment from the crew compartment of the tank, and is outlined in detail in TM 9-753 and TM 9-758. It should be borne in mind, however, that replacement of the needle bearing assemblies and journal trunnions, together with the splines of the propeller shaft tube and sleeve yoke, can be made without removing the propeller shaft assembly from the tank.

### 279. DISASSEMBLY OF THE PROPELLER SHAFT ASSEMBLY.

#### a. Equipment.

Hammer, soft

Screwdriver

Wrench, open-end, 1/2-in.

#### b. Procedure (figs. 199 and 200).

(1) Unscrew the knurled dust cap by hand and pull the propeller shaft tube (splined end) from the sleeve yoke. Remove the dust cap and remove the steel washer and the cork washer from the cap.

(2) Bend down the locking lugs on the four lock straps with a screwdriver. Then, using a 1/2-inch open-end wrench, remove the bolts which hold the lock strap and bearing caps.

(3) Tap the exposed face of one of the needle bearing assemblies with a soft hammer until the opposite bearing assembly is removed from the journal assembly. Then tap the exposed end of the journal assembly until the opposite bearing assembly is free. Remove the trunnion gaskets and retainers.

(4) Remove the remaining two bearing assemblies, trunnion gaskets, and retainers in a similar manner.

(5) By sliding the journal to one side of the yoke, the end of the journal will be free to tip and to clear the lug on the yoke, so that it can be removed from the assembly.

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 200—Components of the Propeller Shaft Assembly

## PROPELLER SHAFT ASSEMBLY

### 280. INSPECTION OF THE PROPELLER SHAFT ASSEMBLY.

When the propeller shaft assembly has been disassembled, all parts, particularly the needle bearing assemblies, journals, and splines, should be inspected for wear.

### 281. OVERHAUL OF THE PROPELLER SHAFT ASSEMBLY.

After disassembly and inspection, as outlined in paragraphs 279 and 280 above, the propeller shaft assembly parts should be washed in SOLVENT, dry cleaning, and then dried with compressed air. All worn or otherwise defective parts should be replaced.

### 282. ASSEMBLY OF THE PROPELLER SHAFT ASSEMBLY.

#### a. Equipment.

Screwdriver

Wrench, open-end, 1/2-in.

#### b. Procedure (figs. 199 and 200).

- (1) Install the journal in the sleeve yoke.
- (2) Install one bearing assembly, first installing the trunnion gasket retainer and the trunnion gasket. Install the other bearing assemblies in the same manner.
- (3) Install bearing caps and lock straps, and install the two bolts through each lock strap, using a 1/2-inch open-end wrench. Bend up the lugs on the lock straps with a screwdriver to secure the bolts.
- (4) Install the steel washer into the dust cap, insert a new cork washer into the cap, and slip the cap over the splined end of the propeller shaft tube.
- (5) Slide the propeller shaft tube into the sleeve yoke so that the stamped arrows on the tube and yoke are in alinement. Screw on the dust cap tightly by hand.

### 283. PREINSTALLATION INSPECTION.

Inspect for oil leaks at the dust cap and check the universal joints for fit and condition of parts before installing the propeller shaft assembly.

### 284. INSTALLATION IN VEHICLE.

Refer to TM 9-753 and TM 9-758 for the procedure which covers the installation of the propeller shaft assembly in the tank.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71**  
**POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section XVIII**

**STARTING MOTOR AND SOLENOID SWITCH**  
**ASSEMBLIES**

	<b>Paragraph</b>
Inspection while on engine .....	<b>285</b>
Trouble shooting .....	<b>286</b>
Removal from engine .....	<b>287</b>
Disassembly of the starting motor assembly .....	<b>288</b>
Inspection and overhaul of the starter solenoid switch assembly .....	<b>289</b>
Inspection and overhaul of the starter frame and field assemblies .....	<b>290</b>
Inspection and overhaul of the starter brushes .....	<b>291</b>
Inspection and overhaul of the starting motor assembly .....	<b>292</b>
Assembly of the starting motor and solenoid switch assemblies .....	<b>293</b>
Preinstallation inspection .....	<b>294</b>
Installation on engine .....	<b>295</b>

**285. INSPECTION WHILE ON ENGINE.**

The starting motor and solenoid switch assemblies cannot be inspected while installed on the engine when the engine assembly is installed in the tank. When the engine assembly is removed from the tank, the starting motor and solenoid switch assemblies should be removed, overhauled, and inspected as outlined in paragraphs 287, 288, 289, 290, 291 and 292 which follow.

**286. TROUBLE SHOOTING.**

When the starting motor fails to operate, check to see that battery current is supplied at the starting motor. If the battery or the leads are not the source of trouble, the starter should be replaced or overhauled as outlined in paragraphs 289, 290, 291 and 292.

**287. REMOVAL FROM ENGINE.**

a. If it is necessary to remove the starting motor and solenoid switch assemblies from the engine when the engine is installed in the tank, follow the steps outlined in TM 9-753 and TM 9-758.

b. If the engine is removed from the tank, the starting motor and solenoid switch assemblies can be removed from the engine as outlined in paragraph 57 of this manual.

STARTING MOTOR AND SOLENOID SWITCH ASSEMBLIES




Figure 201 — Starting Motor Partly Disassembled

RA PD 11460



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**288. DISASSEMBLY OF THE STARTING MOTOR ASSEMBLY.**

**a. Equipment.**

Cutters, side	Wrench, socket, $\frac{7}{8}$ -in.
Screwdriver	Wrench, socket, $\frac{9}{8}$ -in.
Wrench, open-end, $\frac{1}{2}$ -in.	Wrench, socket, $\frac{1}{2}$ -in.
Wrench, open-end, $\frac{3}{4}$ -in.	

**b. Procedure** (figs. 201, 202 and 203). In disassembling the starter, the drive end assembly is first separated from the frame and field assembly, and then each one is disassembled. Figure 201 shows the two subassemblies. This is done by means of the following steps:

(1) Using a screwdriver, remove the cover band (fig. 201).

(2) Using a  $\frac{3}{4}$ -inch open-end wrench, remove the nut, the lock washer, and the cable clip from the terminal stud (commutator end) part of the brush plate assembly.

(3) Using a  $\frac{3}{4}$ -inch open-end wrench, remove the nut and lock washer from the solenoid terminal stud and then remove the solenoid connector cable.

(4) Using a screwdriver, remove the three brush lead screws and the lock washers, holding the three field leads to the brushes. Remove the leads and replace the washers and screws. When removing these wires, mark connections to facilitate assembly.

(5) Check the tension of all brush springs. Tension should be maintained at 34 to 40 ounces. Mark all springs needing replacement.

(6) Bend down the fingers on the lock washers holding the six bolts in the commutator end frame. Using a  $\frac{7}{8}$ -inch socket wrench, remove the six bolts and lock washers and remove the commutator end frame and the brush plate assembly.

(7) Using a  $\frac{3}{4}$ -inch open-end wrench, remove the nut and the lock washer from the terminal stud. Remove the plain washer and insulating washer.

(8) Using a screwdriver, remove the four bolts and washers holding the brush plate assembly to the commutator end frame and remove the frame.

(9) Bend down fingers on the lock washers on the motor drive housing. Using a  $\frac{7}{8}$ -inch socket wrench, remove the five bolts and lock washers from the motor drive housing.


(10) Remove the cotter pin from the shift lever pin and remove the pin. Then remove the motor drive housing assembly including the armature (fig. 202).

(11) Using a screwdriver, remove the four fillister-head bolts and lock washers holding the cover plate to the motor drive housing and remove the plate.

(12) Pry off the shift lever spring.

STARTING MOTOR AND SOLENOID SWITCH ASSEMBLIES

RA PD 11461



317

Figure 202—Component and Related Parts of Motor Drive Housing

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

(13) Cut the locking wire from the three bolts holding the center bearing plate to the motor drive housing. Using a  $\frac{1}{2}$ -inch wrench, remove the three bolts and lock washers; and, using a screwdriver, remove the remaining bolt. **NOTE:** A special bolt is used on the LA engine starting motor only. On the LC engine starting motor four bolts are used.

(14) Remove the shift lever from the groove in the shift sleeve and pull out the drive assembly and armature.

(15) Remove the cotter pin locking the motor drive pinion stop collar and remove the collar by rotating it slightly and sliding it off the shaft (fig. 202).

(16) Slide the shift sleeve off the shaft, bringing with it the motor drive pinion, the pinion meshing spring and the pinion guide.

(17) Remove the space washer, the cupped space washer and the center bearing plate from the armature shaft. **NOTE:** On the LC engine the center bearing plate is numbered.

(18) Using a  $\frac{3}{4}$ -inch socket wrench, remove the solenoid and terminal shield by removing the four bolts and lock washers holding the assembly to the frame and coil assembly (fig. 203).

(19) Unscrew the shield cap from the terminal shield and, using an  $\frac{1}{2}$ -inch socket wrench, remove the nut from the shielded terminal stud. Remove the lock washer and then remove the terminal clip, lifting it out through the upper opening of the shield.

(20) With an  $\frac{1}{2}$ -inch open-end wrench, remove the nut. Remove the sliding shield, the lock washer, the plain washer, and the large insulating washer from the stud along with the shield. Then remove the remaining insulating washers, small and large.

**289. INSPECTION AND OVERHAUL OF THE STARTER  
SOLENOID SWITCH ASSEMBLY.**

**a. Equipment.**

Screwdriver

Wrench, socket,  $\frac{7}{8}$ -in.

**b. Procedure** (figs. 202, 203 and 204). Disassemble, inspect, service, and reassemble the solenoid, using the following steps:

(1) Using a screwdriver, remove the four attaching screws and lock washers holding the terminal plate to the solenoid housing and remove the plate, studs, insulating strips, and solenoid contacts as an assembly.

(2) Clean and inspect the contacts on the ends of the studs and replace, if they show wear or pitting.

(3) Check the studs and plate for shorts.

(4) Inspect the threads of the copper studs for cross threading or corrosion. Replace the studs if necessary.

STARTING MOTOR AND SOLENOID SWITCH ASSEMBLIES




Figure 203—Component and Related Parts of Commutator End Frame, Field Frame and Solenoid

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**


(5) Remove the cotter pin, and, using a  $\frac{1}{8}$ -inch socket wrench, remove the attaching nut, the plain washer, the retainer washer, and the disk from the plunger and rod assembly.

(6) Clean and inspect the disk. If the disk shows signs of wear or pitting, it may be reversed on the plunger shaft or replaced if necessary.

(7) Remove the plunger and rod assembly through the back of the solenoid housing. Clean the outside diameter of the plunger and the inside diameter of the sleeve, and then inspect them for wear and scoring. Also inspect the felt washer at the back of the plunger for wear. If any of these parts are worn, replace the entire plunger and rod assembly, including the washer. **NOTE:** The plunger should not be oiled. Care should be exercised to see that both plunger and sleeve are entirely clean before reassembling the plunger into the solenoid housing.

(8) Using an ammeter connected to a battery, test both the pull-in coil and the hold-in coil. See figure 204 for a wiring diagram of the coils. Note that this is a grounded system.

(9) Reassemble the shield and terminal plate and the solenoid by reversing the steps used in disassembling.



**Figure 204—Wiring Diagram of Solenoid Pull-in and Hold-in Coils**

**STARTING MOTOR AND SOLENOID SWITCH ASSEMBLIES****290. INSPECTION AND OVERHAUL OF THE STARTER FRAME AND FIELD ASSEMBLIES.****a. Equipment.****Hammer****Punch****Screwdriver**Screwdriver, short, heavy, with  $\frac{1}{2}$ -in. square shank and  $\frac{1}{8}$ -in. bladeWrench, open-end,  $\frac{1}{2}$ -in.

**b. Procedure** (figs. 202, 203 and 204). Test the frame and field assemblies for shorts, making sure that the leads are not touching the frame before making the high voltage test. Make a separate check for each pair of field coils. If any evidence of a short is found, it will be necessary to remove the field coil assemblies and six pole shoes from the field frame. This is done by the following steps:

(1) Using a screwdriver, remove the two field coil ground screws and the two lock washers grounding the field coil assemblies to the frame.

(2) With a short, heavy screwdriver, having a  $\frac{1}{2}$ -inch square shank and a blade approximately  $\frac{1}{8}$ -inch wide and  $\frac{1}{8}$ -inch thick, remove the 12 pole shoe screws from the field frame. **NOTE:** These screws have been installed under a very high tension, making it necessary to turn the screwdriver with a  $\frac{1}{2}$ -inch open-end wrench on the shank while holding the blade of the screwdriver firmly in place in the slot of the screw. To prevent burring or damaging of the screw heads, it is essential that the screwdriver be as close to the exact size as possible. In the absence of such a tool, the screws may be removed by using a punch and a hammer. However, in this case, it will be necessary to replace them on reassembling.

(3) Remove the pole shoes and the field coil assemblies from the field frame and remove the shoes from the field coils. Also remove the insulation strip which shields the field coil leads from the frame. **NOTE:** When removing the field coils, be careful to note the position of the six insulation strips (triangular), so that they can be reassembled in the same positions.

(4) Clean the shoes and the inside of the frame, being careful to remove any small metal particles and to examine the field coils for injury to the insulation or the coils.

(5) Remove the wires holding the field coil assemblies together.

(6) Retape the coils with cotton tape if it is not necessary for them to be replaced, and wire the three assemblies together.

(7) Install the field coil assemblies into the frame, being sure that all insulation strips are in proper position.

(8) Install each pole shoe and partially install the pole shoe screws to hold the shoe in place, being careful to see that the shoe is thoroughly nested inside the coil and is making complete metal-to-metal contact with the frame. **NOTE:** If the shoes do not make perfect metal-to-metal

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

contact with the frame over their entire outside surface, the efficiency of the starting motor will be impaired.

(9) Using the screwdriver and ½-inch open-end wrench used in step (2), tighten the pole shoe screws. NOTE: It is essential that these screws be installed at a very high tension to prevent any possible loosening of the shoe.

(10) Install the field coil ground screws and lock washers, grounding the field coils to the frame.

**291. INSPECTION AND OVERHAUL OF THE STARTER  
BRUSHES.**

**a. Equipment.**

Screwdriver

**b. Procedure (fig. 203).** Inspect and service the brush plate assembly and brushes, using the following steps:

(1) Inspect the brushes for wear and for dirt. If the brushes have worn down more than half their original length, they should be replaced. Check the brush pig tails for tightness.

(2) Inspect the brush springs and the brush holders for evidence of overheating. If brushes or springs should need replacement, continue with the disassembly steps indicated in (3) below.

(3) Remove the two brush lead attaching screws from the brush holders and remove the brushes.

(4) Remove the three brush holder screws and the three brush holder lock washers which hold the brush holders to the brush plate assembly. Remove the springs. Remove the remaining six screws holding the brush holders to the brush plate and remove the space plates and the insulation plates from the brush plate. NOTE: The space plates on the insulated brushes are of a different thickness from that of the space plates on the ground brushes. Mark them to assist in reassembly.

(5) Check the commutator end terminal stud for stripped threads and replace the plate and stud assembly if necessary.

(6) After replacing the worn parts, reassemble the brush and brush plate assembly by reversing the steps covered in the disassembly.

**292. INSPECTION AND OVERHAUL OF THE STARTING MOTOR  
ASSEMBLY.**

**a. Equipment.**

Air, compressed

Sandpaper, No. 00

Fluid, cleaning

**b. Procedure (figs. 202, 203 and 204).** Inspect and overhaul the balance of the starting motor assembly as follows:

(1) Clean all parts except the armature, using fuel oil or other cleaning fluid, and blow off with compressed air.

## **STARTING MOTOR AND SOLENOID SWITCH ASSEMBLIES**

- (2) Inspect the commutator end frame assembly.
- (3) Examine the bushing for wear and scoring and replace if necessary. **NOTE:** The shafts in all bushings should move freely but without appreciable play.
- (4) To remove the bushing, first drive out the end plug, and then drive out the bushing.
- (5) Drive in a new bushing and a new plug.
- (6) Inspect the oiler and, if dirty, replace both it and the wick.
- (7) Inspect the armature, checking the shafts for wear and smoothness at the points where they contact the bushings.
- (8) Using No. 00 sandpaper, clean the commutator. Never use emery or carborundum cloth to clean the brushes or the armature. If the commutator is badly scored or worn, it should be trued in a lathe.
- (9) Clean the armature thoroughly with compressed air.
- (10) At the bench, test each segment of the armature for shorts.
- (11) Examine the splines on the drive end of the shaft for wear.
- (12) Inspect the center bearing plate, examining the bushings for smoothness and wear, and replacing the plate if necessary. Remove the wick and blow out the oiler passage with compressed air.
- (13) Inspect the shift sleeve for cracks or wear.
- (14) Examine the motor drive pinion, checking the teeth for wear and chipping.
- (15) Inspect the motor drive housing and examine the bushing for wear and smoothness and replace if necessary.
- (16) Examine the solenoid connector cable, being sure that the connections at the clips are tight and that the insulation has not become frayed or oil soaked. Replace if necessary.

### **293. ASSEMBLY OF THE STARTING MOTOR AND SOLENOID SWITCH ASSEMBLIES.**

#### **a. Equipment.**

Screwdriver	Wrench, open-end, $\frac{3}{4}$ -in.
Spacer, $\frac{3}{4}$ -in.	Wrench, socket, $\frac{7}{8}$ -in.
Wrench	

**b. Procedure** (figs. 201, 202, 203, 204 and 205). Assemble the starting motor, using the following steps:

- (1) Install the starter switch and solenoid assembly to the starter with the four bolts and lock washers, using a wrench (fig. 203).
- (2) Install the center bearing plate, the cupped space washer and the space washer on the armature shaft (fig. 202).
- (3) Install the shift sleeve.
- (4) Install the pinion guide, the pinion meshing spring, and the motor drive pinion, being sure that the lugs on the guide are toward the pinion and are engaged in the slots in the pinion sleeve. Push the pinion



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

and spring assembly back until the guide locks are in the indentations on the armature shaft (fig. 204).

(5) Install the stop collar on the shaft, with the lugs on the inside of the collar and toward the pinion (fig. 204). Install the collar on the shaft splines by rotating it slightly and lock it in position with the cotter pin. The position is indicated by grooves in the shaft splines.

(6) Install the parts so far assembled by engaging the shift lever in the groove in the shift sleeve.

(7) Fasten the center bearing plate to the motor drive housing, using a  $\frac{7}{16}$ -inch socket wrench to install and tighten the three bolts and lock washers and a screwdriver to install the bolt and lock washer. Install the lock wire on the three bolts.


(8) Install the shift lever spring.

(9) Install the cover plate, using a screwdriver to install and tighten the four fillister-head bolts and lock washers.

(10) Install the motor drive housing assembly and the armature into the frame and field assembly, being careful to lift up the brushes when installing the armature.

(11) Install the shift lever pin in the gear lever and the cotter pin.

(12) Using a  $\frac{7}{16}$ -inch socket wrench, install the five bolts and lock



**Figure 205—Method of Installing Pinion Stop Collar on  
Armature Shaft**

## **STARTING MOTOR AND SOLENOID SWITCH ASSEMBLIES**

washers holding the motor drive housing to the frame and field assembly. Bend down the fingers on the lock washers, thus locking the bolts.

(13) Install the brush plate assembly and the commutator end frame, and install the six bolts and lock washers which hold them to the frame and field assembly. Use a  $\frac{7}{16}$ -inch socket wrench. Bend down the fingers on the lock washers, thus locking the bolts.

(14) With a screwdriver, install the screws connecting the three field leads to the brushes.

(15) Install the solenoid connector cable on the solenoid terminal stud and the terminal stud (commutator end).

(16) Using a  $\frac{3}{4}$ -inch open-end wrench, install the insulation washer, the plain washer, the lock washer, and the nut on the terminal stud (commutator end), and the plain washer, the lock washer, and nut on the solenoid terminal stud.

(17) Install the cover band.

(18) Check the clearance between the pinion guide and the bottom of the slots in the pinion sleeve by putting the pinion and the shift sleeve in full operating position (fig. 206). If there is no clearance, the pinion and guide should both be replaced.

(19) Check the amount of pinion travel against the spring pressure when the pinion is in the engaged position, by moving the shift lever forward until the solenoid switch contacts are closed and then rotating the shift sleeve and pinion into the fully engaged position (fig. 212). It should be possible to push the pinion back against the spring pressure at least  $\frac{1}{8}$  inch to  $\frac{3}{16}$  inch. If the amount of travel is incorrect, it can be adjusted by turning the stud in the end of the plunger in or out, as required.

(20) Check the proper adjustment of the solenoid switch contacts by placing a  $\frac{3}{4}$ -inch spacer between the pinion and the pinion stop. With a battery attached to the starting motor terminals, move the shift lever forward, forcing the pinion against the spacer. It should be impossible to close the contacts (thus turning the armature) with the spacer in place. If contact is made, correct the adjustment by turning the stud further into the plunger.

### **294. PREINSTALLATION INSPECTION.**


Before installing a starting motor and solenoid switch assembly on the engine, a check should be made to make sure that the assemblies are either new units or that they have been thoroughly overhauled and inspected.

### **295. INSTALLATION ON ENGINE.**

a. Refer to TM 9-753 and TM 9-758 for procedure to follow if the starter is to be installed on an engine installed in the tank.

b. See paragraph 156 of this manual for procedure for installing the assemblies on an engine which has been removed from the vehicle.

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 4-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



A. OPERATING POSITION

B. ENGAGEMENT ACTION COMPLETED

2A PD 11457

Figure 206—Starter Drive Mechanism in Operating Position (A)  
and Engaged Position (B) to Show Clearances

**Section XIX**

**GENERATOR ASSEMBLY**

	<b>Paragraph</b>
Inspection while on engine .....	296
Trouble shooting .....	297
Removal from engine .....	298
Disassembly of the generator assembly .....	299
Inspection and overhaul of the generator frame and field assembly .....	300
Inspection and overhaul of generator brushes .....	301
Inspection and overhaul of the generator assembly .....	302
Assembly of the generator assembly .....	303
Preinstallation inspection .....	304
Installation on engine .....	305

**296. INSPECTION WHILE ON ENGINE.**

Less effort is required to complete an inspection of the generator assembly by first removing it from the engine (when engine is installed in the tank). Therefore, refer to TM 9-753 and TM 9-758 for procedure to follow in removing the generator from the installed engine. See paragraphs 300, 301 and 302 of this manual for inspection procedure.

**297. TROUBLE SHOOTING.**

When faulty generator operation is evident, the cut-out relay, voltage, and current regulator and generator system of the vehicle should be checked as a whole, to isolate the trouble. If the trouble is found to be in the generator, the conditions listed below may be corrected as follows:

a. **No Output.** Remove the cover band and check for sticking or worn brushes, and burned commutator bars. Burned bars, with other bars fairly clean, indicate open-circuited armature coils. If brushes are making good contact with the commutator, and the commutator is in good condition, the generator should be removed from the engine and checked with a set of test points and a 110-volt test lamp. Proceed as follows:

(1) **TEST FOR A GROUNDED ARMATURE.** Raise the two grounded brushes and insulate them from the commutator with pieces of cardboard. Use the test points and check for ground from the generator main brush lead or A terminal to the generator frame. Should the test lamp light, indicating ground, raise and insulate all brushes and check in turn the insulated brush holders, armature, A terminal, commutator, and fields to locate the ground.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

(2) Test for a grounded field by disconnecting field lead from grounded brush and checking from the F terminal to frame.

(3) If no ground is found, check the field for open circuit with the test lamp connected from the F terminal to the field lead which was disconnected from the grounded brush in the previous check.

(4) If the field is not open, check for shorts in the field by checking the field current. Use a 24-volt battery and an ammeter, connected in series with the fields. Proceed with care in this check, since a shorted field may draw an excessively high current. The field current draw should not be greater than 0.76 to 0.84 amperes. If a shorted field is found, check the regulator contacts, since they may be burned or oxidized from these conditions.

(5) Inspect the commutator bars, since an open circuit in the armature, which would result in a low output or no output, will cause the commutator bars connected to the open circuited coils to burn.

(6) If the trouble has not yet been located, check the armature for short circuit, using a growler charged from a 110-volt source. A thin strip of steel, held in place over the armature core as it is revolved, will vibrate if a short circuit exists. If it is short-circuited, install a new armature.

**b. Unsteady or Low Output. Check as follows:**

(1) Check the generator charging circuit for a poor connection and loose or broken wires. Clean corroded fastenings and resolder broken joints. A poor connection will cause the generator to build up excessive voltage which may result in burned field or armature windings.

(2) Low spring tension will cause a reduced generator output and arcing and burning of the commutator and brushes. Check the pig tail lead connections at the brushes to see that they are tight. Check the brush spring tension and the brushes for sticking. Spring tension is 25 ounces.

(3) Inspect the commutator for roughness, grease, and dirt; check for dirt in slots, high mica, out-of-round, and burned bars. With any of these conditions, the commutator must be turned down in a lathe, and the mica undercut.

**c. Noisy Generator.** A noisy generator may be caused by worn bearings, worn brushes, a worn or broken drive coupling, or a loose mounting. Removal of the generator from the engine will permit a detailed inspection of these parts.

(1) Bearings may be replaced by new ones.

(2) Using a brush seating stone will eliminate new-brush chatter and will quiet old brushes if not too badly worn.

## **GENERATOR ASSEMBLY**

(3) The blower drive coupling assembly may need attention, or the generator coupling or drive hub may be worn and need to be replaced.

### **298. REMOVAL FROM ENGINE.**

a. Procedure for the removal of the generator when the engine is installed in the tank is outlined in TM 9-753 and TM 9-758.

b. Procedure for the removal of the generator when the engine is removed from the tank is outlined in paragraph 42 of this manual.

### **299. DISASSEMBLY OF THE GENERATOR ASSEMBLY.**

#### **a. Equipment.**

Block, wooden

Hammer

Screwdriver

Wrench, open-end,  $\frac{1}{8}$ -in.

Wrench, socket,  $\frac{7}{8}$ -in.

#### **b. Procedure (fig. 207).**

(1) Using a screwdriver, remove the screw and nut (42, fig. 207) holding the cover band (41) and remove the band.

(2) Check the tension spring of all brushes and mark any weak springs. Tension should be 25 ounces.

(3) Using a  $\frac{7}{8}$ -inch socket wrench, remove the six screws (59) and lock washers (58) holding the drive end frame (57) to the frame and field assembly. Remove the drive end frame assembly.

(4) Using a screwdriver, remove the five screws (51) and lock washers (52) holding the shaft bearing retainer plate (53) to the drive end frame and remove the plate and gasket (54). Remove the bearing (55).

(5) Using a screwdriver, remove the four attaching round, slotted-head bolts (8) and lock washers (7) holding the fan shroud (1) to the fan shroud plate (6) and remove the shroud.

(6) Using a  $\frac{1}{8}$ -inch open-end wrench, remove the nut (2) and lock washer (3) from the armature shaft. Lift the fan (4) and the space collar (13) from the shaft.


(7) With a hammer and a piece of wood, drive the armature shaft toward the drive end of the generator, forcing off the bearing (15) from the commutator end of the shaft.

(8) Pull out the armature (35) from the drive end.

(9) Using a screwdriver, remove the six attaching flat-head bolts (5) holding the fan shroud plate to the commutator end frame (14) and remove the plate.

(10) Using a screwdriver, remove the three lead screws (26) holding the field coil lead and the two commutator brush leads to the brush connectors.

ORDNANCE MAINTENANCE-GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2



RA PD 11444

Figure 207 —Components of Generator

GENERATOR ASSEMBLY

1. SHROUD, FAN

2. NUT

3. WASHER, LOCK

4. FAN

5. BOLT, ATTACHING

6. PLATE, FAN SHROUD

7. WASHER, LOCK

8. BOLT

9. BOLT

10. WASHER, LOCK

11. BOLT

12. WASHER, LOCK

13. COLLAR, SPACE

14. FRAME, COMMUTATOR END

15. BEARING, SHAFT (COMMUTATOR END)

16. GASKET, SHAFT BEARING PLATE

17. PLATE, SHAFT BEARING RETAINER (COMMUTATOR END)

18. BOLT, BRUSH SUPPORT

19. WASHER, LOCK

20. WASHER, SPACE

21. PLATE, BRUSH; ASSEMBLY

22. BUSHING, INSULATION (IN BRUSH PLATE)

23. BUSHING (STEEL—IN BRUSH HOLDER)

24. WASHER, INSULATION (2 HOLE)

25. BRACKET, BRUSH TERMINAL

26. WASHER, LOCK

27. SCREW, LEAD (RD. HD. SLOTTED)

28. SPRING, BRUSH

29. ARM, BRUSH

30. SLEEVE, SPACE

31. BRUSH

32. HOLDER, BRUSH

33. STUD, BRUSH HOLDER

34. COLLAR, SPACE

35. KEY, WOODRUFF

36. ARMATURE

37. SHOE, POLE

38. BUSHING, INSULATION (TERMINAL STUD AND LEAD)

39. STUD, TERMINAL

40. COIL, FIELD (4 COILS); ASSEMBLY

40. STRIP, INSULATION

41. BAND, COVER

42. NUT, SCREW

43. STUD AND LEAD, TERMINAL; ASSEMBLY

44. CAP, TERMINAL SHIELD

45. NUT, TERMINAL STUD AND LEAD

46. WASHER, LOCK

47. WASHER, PLAIN

48. WASHER, INSULATION

49. SHIELD, TERMINAL

50. SCREW, POLE SHOE

51. SCREW, SHAFT BEARING (DRIVE END)

52. WASHER, LOCK

53. PLATE, RETAINER

54. GASKET, SHAFT BEARING PLATE

55. BEARING, SHAFT (DRIVE END)

56. CUP, GREASE

57. FRAME, DRIVE END

58. WASHER, LOCK

59. SCREW, DRIVE END FRAME

RA PD 11444A

Figure 207A—Components of Generator—Nomenclature



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

(11) Using a  $\frac{1}{4}$ -inch socket wrench, remove the six attaching bolts (11) and lock washers (12) holding the commutator end frame and brush plate assembly (21) to the frame and field assembly.

(12) Using a screwdriver, remove the four plate attaching bolts (9) and lock washers (10) holding the brush plate assembly to the commutator end frame. **NOTE:** The brush plate assembly is doweled to the commutator end frame. Both are doweled to the frame and field assembly.

(13) Using a screwdriver, remove the five screws and lock washers holding the bearing plate retainer (17) and remove the plate and the gasket (16) from the commutator end frame. Lift off the spacer collar (33) and the bearing.

**300. INSPECTION AND OVERHAUL OF THE GENERATOR  
FRAME AND FIELD ASSEMBLY.**

**a. Equipment.**

Hammer

Tape, cotton

Punch

Wrench, open-end,  $\frac{1}{2}$ -in.

Screwdriver

Screwdriver, short, heavy, with

$\frac{1}{2}$ -in. sq. shank and  $\frac{1}{8}$ -in.

blade

**b. Procedure** (fig. 207). Test the frame and field assembly for shorts, being sure that the leads are not touching the frame, before making the high voltage test. Make a separate check for each coil. If evidence of shorts is found, it will be necessary to remove the field coil assembly (39, fig. 207) and four pole shoes (36) from the field frame. This is done as follows:

(1) Remove the terminal stud (38) by removing the terminal shield cap (44), the two terminal stud and lead nuts (45), the lock washer (46), the plain washer (47), and the insulation washer (48). The stud can now be removed from the inside of the frame, thus disconnecting the lead.

(2) With a short, heavy screwdriver, having a  $\frac{1}{2}$ -inch square shank and a blade approximately  $\frac{1}{8}$ -inch wide and  $\frac{1}{8}$ -inch thick, remove the eight pole shoe screws (50) from the field frame. **NOTE:** These screws have been installed under a very high tension, making it necessary to turn the screwdriver with a  $\frac{1}{2}$ -inch open-end wrench on the shank while holding the blade of the screwdriver firmly in place in the slot of the screw. To prevent burring or damaging of the screw heads, it is essential that the screwdriver be as close to the exact size as possible. In the absence of such a tool, the screws may be removed by using a punch and a hammer. However, in this case it will be necessary to replace them on reassembling.

## GENERATOR ASSEMBLY

(3) Remove the pole shoes and the field coil assemblies from the field frame and remove the shoes from the field coils. Also remove the insulation strip (40) which shields the field coil leads from the frame.

(4) Clean the shoes and the inside of the frame, being careful to remove any small metal particles, and examine the field coils for injury to the insulation or the coils.

(5) Retape the coils with cotton tape if it is not necessary for them to be replaced.

(6) Install the field coil assemblies into the frame.

(7) Install each pole shoe, and partially install the pole shoe screws to hold the shoe in place, being careful to see that the shoe is thoroughly nested inside the coil and is making complete metal-to-metal contact with the frame. NOTE: If the shoes do not make perfect metal-to-metal contact with the frame over their entire outside surface, the efficiency of the generator will be impaired.

(8) Using the screwdriver and the 1/2-inch open-end wrench used in step (2), tighten the pole shoe screws. NOTE: It is essential that these screws be installed at a very high tension, in order to prevent any possible loosening of the shoe.

(9) Install the terminal lead stud by first installing the insulation washer (48), the plain washer (47), the lock washer (46), the two terminal studs and lead nuts (45), and the terminal shield cap (44).

(10) Install the insulation strip.

### 301. INSPECTION AND OVERHAUL OF GENERATOR BRUSHES.

#### a. Equipment.

Screwdriver

b. Procedure (fig. 207). Inspect and service the brush plate assembly and brushes, using the following steps:

(1) Inspect the brushes for wear and for dirt. If the brushes have worn down more than half their original length, they should be replaced. Check the brush pig tails for tightness.

(2) Inspect the brush springs and the brush holders for evidence of overheating. If brushes or springs should need replacement, continue with the disassembly steps indicated in (3) below.

(3) Remove the lead screw (26, fig. 207) from the brush holder (31), and remove the brushes.

(4) If the brush springs are to be replaced, remove the brush holder stud (32), replace the spring (27), and reinstall the stud.

(5) Check free movement of all parts of the brush plate assembly. If any binding is evident, remove the brush holder, and clean and replace worn or faulty parts.

(6) Blow out the brush plate assembly with compressed air.

**TM 9-1750G**  
**301-303**

**ORDNANCE MAINTENANCE-GENERAL MOTORS TWIN DIESEL 6-71**  
**POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

(7) Check the commutator end terminal stud for stripped threads, and replace the plate and stud assembly if necessary.

(8) After replacing the worn parts, reassemble the brush and brush plate assembly by reversing the steps covered in the disassembly.

**302. INSPECTION AND OVERHAUL OF THE GENERATOR ASSEMBLY.**

**a. Equipment.**

Air, compressed

Sandpaper, No. 00

Fluid, cleaning

**b. Procedure (fig. 207).** Inspect and service the remaining parts of the generator assembly as follows:

(1) Clean all parts except the armature, using fuel oil or other cleaning fluid, and blow off with compressed air.

(2) Inspect the commutator end frame assembly.

(3) Examine the two bearings for smoothness and wear. Clean out and repack with new grease.

(4) Examine the space collars for smoothness and wear.

(5) Inspect the two grease caps, and, if dirty, clean out and refill with clean grease.

(6) Examine the fan for looseness on the shaft.

(7) Inspect the armature, checking the shafts for wear and smoothness at the points where they contact the bearings.

(8) Using No. 00 sandpaper, clean the commutator. Never use emery or carborundum cloth to clean brushes or armature. If the commutator is badly scored or worn, it should be trued in a lathe. After the commutator has been trued, the mica insulation between the bars should be undercut.

(9) Clean the armature thoroughly with compressed air.

(10) At the bench, test each segment of the armature for shorts.

(11) Replace all worn or damaged parts and reassemble.

**303. ASSEMBLY OF THE GENERATOR ASSEMBLY.**

**a. Equipment.**

Screwdriver

Wrench, socket,  $\frac{7}{8}$ -in.

Wrench, open-end,  $\frac{1}{2}$ -in.

**b. Procedure (fig. 207).**

(1) Install the shaft bearing (commutator end) (15, fig. 207), a new gasket (16), and the shaft bearing retainer plate (17) on the commutator end frame (14). Using a screwdriver, install and tighten the five bolts and lock washers.

(2) Install the brush assembly plate (21) to the commutator end

## **GENERATOR ASSEMBLY**

frame, which is doweled for the plate, and, using a screwdriver, install the four bolts (9) and lock washers (10).

(3) Install the commutator end frame with the attached brush plate assembly to the frame and field assembly in the position indicated by the dowels and dowel holes, and, using a  $\frac{7}{8}$ -inch socket wrench, install the six bolts (11) and lock washers (12).

(4) With a screwdriver, install the three lead screws (26) and lock washers (25) holding the field coil lead and the two brush leads to the brush connectors.

(5) Install the fan shroud plate (6) to the commutator end frame and, using a screwdriver, install the six countersunk attaching bolts (5).

(6) Install the space collar (33) on the armature shaft (commutator end).

(7) Install the armature (35) from the drive end, lifting the brushes to clear the armature.

(8) Install the space collar (13).

(9) Install the fan (4), engaging the slot on the Woodruff key (34).

(10) Using a  $\frac{1}{2}$ -inch open-end wrench, install the armature shaft lock washer and nut, while holding the armature to keep it from turning, in order to tighten the nut.

(11) Install the shaft bearing (drive end) (55) in the drive end frame (57). Install the shaft bearing plate gasket (54), and the retainer plate (53) and, using a screwdriver, install and tighten the five screws (51) and lock washers (52) holding the retainer to the drive end frame.

(12) Install the drive end frame assembly on the armature shaft and onto the field frame, lining up the dowel pins.

(13) Using a  $\frac{7}{8}$ -inch socket wrench, install and tighten the screws (59) and lock washers (58) holding the drive end frame to the frame and field assembly.

(14) Install the cover band (41) and tighten the screw and nut (42) with a screwdriver.

### **304. PREINSTALLATION INSPECTION.**

Before installing a generator assembly on the engine, check to make sure that the assembly is either a new unit or that it has been thoroughly overhauled and inspected.

### **305. INSTALLATION ON ENGINE.**

a. If the generator assembly is to be installed on an engine which is installed in the tank, refer to TM 9-753 and TM 9-758 for the steps to follow.

b. If the generator assembly is to be installed on an engine which has been removed from the tank, see paragraph 173 of this manual.

**TM 9-1750G**

**306**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section XX**

**INSTALLATION OF ENGINE ASSEMBLY IN TANK**

**Paragraph**

**Installation of engine assembly in tank**

**306**

**306. INSTALLATION OF ENGINE ASSEMBLY IN TANK.**

Detailed steps outlining the procedure necessary to install the engine assembly in the tank are given in TM 9-753 and TM 9-758.

**Section XXI**

**PREPARATION OF ENGINE FOR USE  
UNDER UNUSUAL CONDITIONS**

Preparation of engine for use under unusual conditions **Paragraph**  
**307**

**307. PREPARATION OF ENGINE FOR USE UNDER UNUSUAL  
CONDITIONS.**

a. Refer to section VIII of TM 9-753 and TM 9-758 for engine operation under the following conditions:

- (1) Cold weather operation.
- (2) Operation under warm temperatures.
- (3) High altitude.
- (4) Sand.
- (5) Slippery terrain.

b. Also refer to SOP 55.24\*.

\* In preparation.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section XXII**

**DECONTAMINATION**

<b>Decontamination</b>	<b>Paragraph</b> <b>308</b>
------------------------	--------------------------------

**308. DECONTAMINATION.**

Refer to section IX of TM 9-753 and TM 9-758 for decontamination of materiel when it is affected by gas. Also see FM 21-40 and TM 9-850.

**Section XXIII**

**INSTRUCTIONS FOR PACKING, SHIPMENT,  
AND STORAGE**

	<b>Paragraph</b>
<b>General</b> .....	<b>309</b>
<b>Depot storage</b> .....	<b>310</b>
<b>Preparation for shipment</b> .....	<b>311</b>
<b>Crating the engine assembly</b> .....	<b>312</b>

**309. GENERAL.**

Instructions for packing, shipment, and storage of the engine when installed in the M3A5 Medium Tank are contained in section XXIV of TM 9-753 and TM 9-758. Also refer to section III, "Preservatives," of TM 9-850.

**310. DEPOT STORAGE.**

When the engine assembly is to be stored or removed from operation for an extended period, special precautions should be taken to protect the assembly against accumulation of rust, corrosion on the wearing surfaces, and gumming in the fuel oil system.

a. **Injectors.** Remove injectors and wash them in SOLVENT, dry cleaning, or fuel oil (par. 52). "Pop" the injectors as outlined in paragraph 234. If this check finds any of the seven spray tip holes plugged, remove the tip and recondition it, as outlined in paragraphs 230 and 232. Then install the injectors (par. 161), time them (par. 163), and position the injector control racks (par. 167).

b. **Purge the Fuel System.** Fuel oil should not be left in the injectors for any extended period of time unless the injector operation is checked. Oxidation of the fuel is likely to leave gummy deposits on the close-fitting parts, and thus interfere with their proper operation. Therefore, before storing the engine assembly, the fuel system should be purged with a type of oil as indicated below, a quantity of which will remain in the system when the engine is in storage.

(1) Two mixtures satisfactory for purging are a mixture of 20 percent medium steam turbine oil and 80 percent pure white kerosene, or a mixture of 20 percent rustproofing oil and 80 percent pure white kerosene. The rustproofing oil should be of first-grade quality.

(2) After the injectors have been checked and, if necessary, reconditioned, drain the fuel oil from the fuel filters and the fuel tanks.

(3) Substitute approximately two gallons of purging oil in each tank and run the engines at a normal speed until the fuel supply in the tank is



**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

nearly exhausted. Then refill and leave the fuel system filled with the purging oil. **NOTE:** Disregard the appearance of smoky exhaust when starting the engine after using the purging oil, since this condition is normally likely to occur.

c. **Protect Cylinder Walls.** The cylinder walls should be coated with a film of OIL, engine, heavy, SAE 50 or SAE 60. To coat the cylinder walls, remove the injectors and turn over the engine until the various pistons are at bottom center. By means of an atomizing spray gun, coat the cylinder walls in turn by inserting the nozzle of the spray gun through the injector openings. **CAUTION:** Do not use enough oil inside the cylinder bores to form a puddle on top of the pistons.

d. **Oil Pans and Supply Tanks.** Drain oil pans and oil supply tanks. Then flush them clean with OIL, engine, light. Replace the drain plugs.

e. **Lubricating Oil Filters.** Remove and discard old filter elements and install new elements.

f. **Air Cleaners.** Wash accumulated dirt from the screen filtering element in clean SOLVENT, dry cleaning, or fuel oil. Let the element drain thoroughly before replacing in the container. Replenish the oil reservoirs with the same viscosity oil as used in the engine, up to the level indicated on the filter bowl.

g. **Cooling System.** Drain and flush the cooling system.

h. **Storage Battery.** Replenish the water to bring the level  $\frac{3}{8}$  inch above the plates. Fully charge the battery to 1.275 specific gravity. Store the battery in a dry place and keep it charged.

i. **Protect Engines with a Water-Proof Cover.**

**311. PREPARATION FOR SHIPMENT.**

The following steps should be followed in preparing the engine assembly for shipment:

a. Remove the fans and tape the fan shafts with waterproof tape.

b. Tape the thermostat housing water outlets.

c. Protect the oil cooler water inlet with a thin strip of wood held in place by the flange bolts.

d. Protect the oil inlet and outlet elbows on the oil pan with tape or pipe caps.

e. Protect the air shut-down solenoids by taping.

f. Cover each group of air cleaners with waterproof paper held in place with tape.

g. Protect the battery connection to the starter solenoid switch assembly.

## **INSTRUCTIONS FOR PACKING, SHIPMENT, AND STORAGE**

**h.** If shipment is to be made in such a manner that will not require crating, a twin engine dolly stand without casters may be satisfactorily used. If crating is required, see the following paragraph.

### **312. CRATING THE ENGINE ASSEMBLY.**

A wooden crate for shipping the engine assembly can be made, as outlined in the steps which follow. It is of primary importance to construct the framework under the engine assembly strong enough to withstand shocks in shipment. Therefore, 2 x 6- or 2 x 8-inch timbers should be used for the framework.

**a.** The engine assembly should be supported on the following surfaces:

(1) On the sides of the oil pan bolting flange from a point just behind the oil inlet and outlet elbows to the rear of the fan.

(2) On the oil pan bolting flange across the front of both engines under the crankshaft front cover. This piece should be relieved below the vibration dampers to prevent loading at these points.

(3) Under the flywheel housing, just inside the engine mounting brackets. These supporting surfaces should be 1½ inches below the oil pan bolting surfaces.

**b.** The engine assembly must be securely fastened to this framework. This is most readily accomplished by using steel banding, if available. This banding should be placed underneath the heavy framework upon which the engine assembly rests. At the front of the assembly each engine should be tied down by bands passing through the front lifter bracket eyes, and the bands pulled very tightly with a banding machine. A band may be placed over the flywheel housings, under the framework at the rear of the engine assembly, and pulled down tightly. Heavy paper may be used between the band and the flywheel housings to prevent rubbing.

**c.** A box can now be made and secured to the heavy framework base, covering the entire unit. The top of the box should be covered with waterproof paper. It is desirable to make this upper structure sufficiently sturdy to permit lifter hooks to be used to move the entire crated unit about. If a crate similar to the shipping crate used by a manufacturer is made, the units may be stacked one on top of the other, or moved about with cranes or hoists by means of hooks.

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

**Section XXIV**

**CLEARANCES, TOLERANCES, AND SPECIAL TOOLS**

	Paragraph
Table of specifications and clearance and wear limits	313
Tension wrench table	314
Special tools	315

**313. TABLE OF SPECIFICATIONS AND CLEARANCE AND WEAR LIMITS.**

The following table will serve as a guide in inspecting new and repaired parts before making replacements:

**CYLINDER LINER**

Diameter, inside	4.2492–4.2507 in.
Diameter, piston skirt	4.2427–4.2442 in.
Clearance, piston with liner	0.006 – .007 in. selected
Allowable out-of-round	0.001 in.
Allowable taper	0.001 in.

**MAIN BEARINGS**

Diameter, inside, shells	3.502 –3.503 in.
Diameter, outside, journal	3.500 –3.499 in.
Clearance, shell with journal	0.002 –0.004 in.
Length, over thrust washer (rear main bearing)	1.4965–1.4935 in.
Length, shaft	1.4990–1.501 in.
Clearance, thrust, rear main bearing	0.0025–0.0075 in.

**PISTONS**

Diameter, skirt	4.2427–4.2442 in.
Diameter, inside, liner	4.2492–4.2507 in.
Clearance, piston with liner	0.006 –0.007 in. selected
Diameter, inside, pin bushings	1.503 –1.5025 in.
Diameter, outside, pin	1.500 –1.4998 in.
Clearance, pin with bushings	0.0025–0.0032 in.

**PISTON RINGS**

**Compression**

Gap	0.020 –0.025 in.
Clearance in groove (upper ring)	0.010 –0.0125 in.
Clearance in groove (2nd from top)	0.008 –0.0105 in.
Clearance in groove (3rd and 4th rings)	0.006 –0.0085 in.

**CLEARANCES, TOLERANCES, AND SPECIAL TOOLS****PISTON RINGS—Continued****Oil Control**

Gap	0.010 -0.020 in.
Clearance in groove	0.0045-0.0085 in.

**CONNECTING RODS**

Diameter, inside, lower shells	2.752 -2.753 in.
Clearance, lower shells with journal	0.002 -0.004 in.
Width, lower end	2.117 -2.115 in.
End play, lower end	0.006 -0.012 in.

**GEAR TRAIN****Backlash**

Crankshaft to idler gears	0.005 -0.007 in.
Idler to camshaft to blower drive gears	0.004 -0.006 in.

**Blower Drive Gear**

Diameter, inside, support bushings	1.6260-1.6265 in.
Diameter, outside, hub	1.6250-1.6245 in.
Clearance, annular, bushings with hub	0.001 -0.002 in.
Length, support over bushings	2.997 -2.996 in.
Length, hub between shoulders	3.002 -3.000 in.
Clearance, end, bushings with hub	0.003 -0.006 in.

**Idler Gear**

Diameter, inside, gear bushings	2.7485-2.749 in.
Diameter, outside, hub	2.7465-2.746 in.
Clearance, gear bushings with hub	0.002 -0.003 in.
Length, over gear bushings	1.186 -1.184 in.
Length, between hub shoulder and thrust washer	1.189 -1.190 in.
Clearance, end, between gear and hub	0.003 -0.006 in.

**CAMSHAFT AND BALANCE SHAFT**

Diameter, inside, plain and grooved (thrust) bearings	1.500 -1.501 in.
Diameter, outside, shaft	1.4985-1.4980 in.
Clearance, bearing with shaft	0.0015-0.003 in.
Diameter, inside, intermediate bearings (camshaft)	1.5010-1.5020 in.
Diameter, outside, shaft	1.4985-1.4980 in.
Clearance, intermediate bearing with shaft	0.0025-0.004 in.

# **ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71 POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

## **CAMSHAFT AND BALANCE SHAFT—Continued**

Length, thrust journal between shoulder of shaft and gear	2.874 –2.876 in.
Length, thrust bearing	2.864 –2.866 in.
Clearance, end, between thrust shoulder and bearing	0.008 –0.012 in.

## **EXHAUST VALVES**

Diameter, stem	0.3425–0.3415 in.
Diameter, inside, guide	0.3435–0.3445 in.
Clearance, stem with guide	0.001 –0.003 in.

## **ROCKER ARMS**

Diameter, outside, shaft	0.8740–0.8735 in.
Diameter, inside, rocker arm	0.8750–0.8760 in.
Clearance, shaft with rocker arm	0.001 –0.0025 in.

## **CAM FOLLOWERS**

Diameter, outside, follower	1.061 –1.060 in.
Diameter, inside, cylinder head	1.062 –1.063 in.
Clearance, follower with cylinder head	0.001 –0.003 in.
Looseness, radial, follower roller with pin	0.005 –0.0016 in.

## **LUBRICATING OIL PUMP**

Backlash, gears	0.018 –0.020 in.
Diameter, outside, gear	1.683 –1.681 in.
Diameter, inside, body	1.687 –1.690 in.
Width, gear	1.7480–1.7475 in.
Width, body	1.7500–1.7520 in.
Clearance, radial, gears with pump body	0.002 –0.0045 in.
Clearance, end, gears with pump body	0.002 0.0045 in.

## **BLOWER**

Clearance, rotors to rear end plate	0.007 –0.009 in.
Clearance, rotors to front end plate	0.014 –0.016 in.
Clearance, leading side upper rotor with trailing side of lower rotor	0.016 –0.022 in.
Clearance, trailing side of upper rotor with leading side of lower rotor	0.004 –0.006 in.

**NOTE:** Any differences in tolerances should be reported immediately to the Office of the Chief of Ordnance, Field Service, Maintenance Division.

## **CLEARANCES, TOLERANCES, AND SPECIAL TOOLS**

### **314. TENSION WRENCH TABLE.**

Assembly and installation of parts or subassemblies occasionally require the use of a tension wrench. The table below should be followed in such instances.

<b>Nut or Bolt</b>	<b>Foot-Pounds Torque Recommended</b>
Cap, main bearing	185
Cover, balance weight	40
Cover, crankshaft front	85
Flywheel to crankshaft	125
Gears, blower retainer	45
Head, cylinder	Hot, 180; Cold, 160
Housing, flywheel	85
Retainer, injector	8-12
Rod, connecting	65-70
Shafts, cam and balance	200

### **315. SPECIAL TOOLS.**

To facilitate efficient handling of disassembly, service, and assembly operations on the engine, special tools are provided as listed below and as illustrated in figures 208 to 217 inclusive.

<b>Tool No.</b>	<b>Description</b>
KM-341	Valve stem guide reamer—roughing
KM-J-129-2	Valve stem guide reamer—finishing
KM-J-943-A	Transfer case shaft inner bearing and housing and countershaft oil seal remover
KM-J-1227	Valve spring compressor and injector remover (also for use for fan shaft bearing retainer oil seal remover)
KM-J-1229	Injector tube flanger and driver
KM-J-1231-A	Injector tube reamer set with pressure feed attachment
KM-J-1233	Valve stem guide remover and replacer
KM-J-1238	Injector nut wrench
KM-J-1241-A	Injector service set
KM-J-1244	Broken push rod and cam follower remover
KM-J-1245-A	Push rod remover (set)
KM-J-1261-A	Injector body vise jaws with popping tool
KM-J-1290	Injector spring lifter

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

<b>Tool No.</b>	<b>Description</b>
<b>KM-J-1291-A</b>	<b>Spray tip driver and injector bushing cleaner</b>
<b>KM-J-1319-A</b>	<b>Cylinder compression gage</b>
<b>KM-J-1330</b>	<b>Injector valve lapping block</b>
<b>KM-J-1359</b>	<b>Flywheel housing oil seal expander</b>
<b>KM-J-1471</b>	<b>Blower drive gear flexible coupling spring spreader</b>
<b>KM-J-1472</b>	<b>Main bearing cap puller</b>
<b>KM-J-1508</b>	<b>Fuel pump tool set</b>
<b>KM-J-1513</b>	<b>Piston pin bushing remover and replacer set</b>
<b>KM-J-1641-A</b>	<b>Valve insert remover</b>
<b>KM-J-1652</b>	<b>Mechanical governor spring retainer nut wrench</b>
<b>KM-J-1682-C</b>	<b>Rotor blower service tool set</b>
<b>KM-J-1688</b>	<b>Connecting rod bushing reaming fixture</b>
<b>KM-J-1687</b>	<b>Cylinder sleeve air port carbon remover</b>
<b>KM-J-1698</b>	<b>Blower clearance feeler set</b>
<b>KM-J-1699</b>	<b>Socket head screw wrench for water pump drive coupling</b>
<b>KM-J-1720</b>	<b>Water pump impeller seal seat finishing tool</b>
<b>KM-J-1853</b>	<b>Fuel injector timing gage (high output engine)</b>
<b>KM-J-1885</b>	<b>Fuel line double flare seat tool</b>
<b>KM-J-1891</b>	<b>Injector tube remover</b>
<b>KM-J-1902</b>	<b>Camshaft gear puller</b>
<b>KM-J-1903</b>	<b>Camshaft gear replacer</b>
<b>KM-J-1904</b>	<b>Flywheel removing wrenches (set of 2)</b>
<b>KM-J-1905</b>	<b>Crankshaft vibration dampener puller</b>
<b>KM-J-1906</b>	<b>Clutch yoke shaft needle bearing replacer</b>
<b>KM-J-1907</b>	<b>Clutch yoke shaft needle bearing remover</b>
<b>KM-J-1908</b>	<b>Transfer case shaft inner bearing replacer</b>
<b>KM-J-1909</b>	<b>Cylinder sleeve clamp</b>
<b>KM-J-1910</b>	<b>Transfer case shafts and clutch pilot bearing replacer</b>
<b>KM-J-1911</b>	<b>Fan shaft friction flange bearings and gear replacer</b>
<b>KM-J-1912</b>	<b>Transfer case countershaft oil seal replacer</b>
<b>KM-J-1913</b>	<b>Transfer case hexagon nut socket wrench with handle (2¾-in.)</b>
<b>KM-J-1914</b>	<b>Flywheel pilot bearing remover</b>
<b>KM-J-1915</b>	<b>Clutch alining pilot tool</b>
<b>KM-J-1916</b>	<b>Transfer case shaft oil seal remover and replacer</b>

**CLEARANCES, TOLERANCES, AND SPECIAL TOOLS**

<b>Tool No.</b>	<b>Description</b>
<b>KM-J-1917</b>	<b>Camshaft tachometer drive remover</b>
<b>KM-J-1918</b>	<b>Cylinder liner remover and replacer</b>
<b>KM-J-1919</b>	<b>Puller for removing fan shaft gear bearings and friction plate. Also transfer case, countershaft bearings and oil pump drive shaft gear remover and replacer</b>
<b>KM-J-1920</b>	<b>Injector popping and test fixture with pressure gage</b>
<b>KM-J-1922</b>	<b>Push rod lock nut wrench</b>
<b>KM-J-1924</b>	<b>Twin motor assembly frame and carriage</b>
<b>KM-J-1925</b>	<b>Engine lifting hooks, twin and single</b>
<b>KM-J-1926</b>	<b>Engine overhaul stand (with casters)</b>
<b>KM-J-1927</b>	<b>Flywheel housing alining studs</b>
<b>KM-J-1928</b>	<b><math>\frac{1}{8}</math>-inch cylinder-head stud nut wrench (nuts under control shaft)</b>
<b>KM-J-1929</b>	<b>Piston top center indicator</b>
<b>KM-J-1930</b>	<b>Water pump drive coupling and oil slinger remover</b>
<b>KM-J-1931</b>	<b>Camshaft balancer weight, lubricator oil pump shaft drive gear puller, and crankshaft oil pump drive gear puller</b>
<b>KM-J-1932</b>	<b>Clutch throw-out bearing lock nut wrench</b>
<b>KM-J-1933</b>	<b>Fuel pump assembly guide dowels</b>
<b>KM-J-1935</b>	<b>Crankshaft oil pump drive gear replacer</b>
<b>KM-KMO-320</b>	<b>Fuel pressure gage</b>
<b>KM-KMO-326-A</b>	<b>Fuel pump wrench</b>



ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2





Figure 208—Special Tool Group

**CLEARANCES, TOLERANCES, AND SPECIAL TOOLS**



**Figure 209—Special Tool Group**

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2




Figure 210—Special Tool Group

CLEARANCES, TOLERANCES, AND SPECIAL TOOLS

RA PG 11448





Figure 211 - Special Tool Group

**TM 9-17500**  
**315**

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



**KM - J-1935**



**KM - J-1929 (2 PIECES)**

**RA PD 11449**

**Figure 212—Special Tool Group**

CLEARANCES, TOLERANCES, AND SPECIAL TOOLS




Figure 213--Special Tool Group

RA PD 11450

ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2






Figure 214—Special Tool Group

**CLEARANCES, TOLERANCES, AND SPECIAL TOOLS**




**Figure 215—Twin Motor Assembly Frame and Carriage**



**Figure 216—Engine Lifting Hooks, Twin and Single**



**ORDNANCE MAINTENANCE--GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**



***Figure 217--Rotating Engine Stand***

Section XXV

REFERENCES

	Paragraph
Standard nomenclature lists	316
Explanatory publications	317
Training films and film strips	318

316. STANDARD NOMENCLATURE LISTS.

- a. Medium Tank, M3A3 SNL G-104, Vol. V
- b. Cleaning, preserving, and lubricating materials SNL K-1

Current Standard Nomenclature Lists are as tabulated here. An up-to-date list of SNL's is maintained as the "Ordnance Publications for Supply Index"

OPSI

317. EXPLANATORY PUBLICATIONS.

- a. Medium Tanks, M3A3 and M3A5 TM 9-753
- b. Cleaning, preserving, lubricating and welding materials TM 9-850
- c. Diesel engines and fuels TM 10-575
- e. Shipment and storage.
- Storage of motor vehicle equipment AR 850-18

Loading of mechanized and motorized army equipment on open top railroad equipment—Association of American Railroads.

c. Miscellaneous.

List of publications for training	FM 21-6
Cold weather operation of automotive equipment	OFSB 6-G-3
Fire prevention, safety precautions, accidents	TM 10-360
Echelon system of maintenance	TM 10-525
Electrical fundamentals	TM 1-455

318. TRAINING FILMS AND FILM STRIPS.

- a. Lubrication FS 10-39
- b. Hand, measuring, and power tools FS 10-40
- c. Diesels.
  - Diesel engines TF 10-158
  - Diesel engines and fuels FS 10-37
- d. Maintenance.
  - Third echelon of maintenance FS 10-55
  - Fourth echelon of maintenance FS 10-56

	Page No.		Page No.
assembly), dis-		balancer shaft assembly	166
226-231		blower assembly	234-242
(See Oil Cooler		blower drive gear, hub and sup-	
assembly)		port	160-162
idling	257-258	camshaft assembly	153
plunger gap		clutch assembly	308-309
256-257		clutch housing assembly	302-306
205		crankshaft rear cover assembly	172
blies)		cylinder head and related as-	
		semblies	133-134
	177	engine transfer gear housing as-	
	177, 288	sembly	295-298
service	177	fan drive gear and balance weight	
	214-215	assembly	156
storage	339	fan shaft assembly	150
ee		fuel pump assembly	252-255
	288-289	generator assembly	333-334
	288	governor control housing	265-266
	288	governor cover and lever assembly	267
	289	injector assembly	278-279
	286	oil cooler and adapter assembly	283
	211	oil pressure regulator valve as-	
	289	sembly	169
	288	oil pump assembly	140-144
ine	286	piston and connecting rod as-	
	286	sembly	115
assembly)		propeller shaft assembly	313
	242-243	secondary fuel filter	175
	223-226	solenoid switch assembly	323-325
ine	243	starting motor assemblies	323-325
		water outlet manifold and thermo-	
	232-233	stat assembly	146
	221-222	water pump assembly	246-248
	243	weight and housing assembly	
	233	(governor)	270-271
	223	weight and hub assembly	164
		Assembly of the engine	178-220
	8	(See installation under names	
	21-26	of components or assemblies	
operations, echelon		and Assembly)	
	38	Auxiliary drive	15
	6-8		
	26		
blies	177		
blies	288-289		
assembly	242-243		
cover and fan			
	168		

# INDEX

B—Cont'd		Page No.		Page No.
Balance weight assembly			Camshaft (assembly) (and balance shaft)	
assembly		156	assembly	153
disassembly		153-156	bearings	
inspection		156	lubrication	18
Balance weight cover (assembly) (and fan idler gears)			oil	187
assembly		168	removal	98
disassembly		166-168	description and location	15-18
inspection and service		168	disassembly	150-151
installation		190	inspection	151-153
removal		91	location	9
Balancer shaft (assembly)			removal	95
assembly		166	specifications and clearances	342-343
disassembly		164	Cleaning cylinder head	126
location		9	Clearances, table of	341-343
inspection		164	Clutch assembly	
installation		187-188	assembly	308-309
Battery, storage		339	disassembly	306-307
Bearings (See specific names)			housing (and assemblies)	
Blower assemblies (-y)			assembly	302-306
and attached parts			disassembly	300-301
installation		195-196	inspection	301-302
removal		80-82	on engine	299
assembly		234-242	preinstallation	309
disassembly		226-231	installation	215-217
function		6, 8, 21	on engine	309
gears and bearings, lubrication		26	overhaul	302
inspection			removal	48-50
disassembled		232-233	from engine	299
on engine		221-222	trouble shooting	299
preinstallation		243	inspection	307-308
installation on engine		243	preinstallation	309
overhaul		233	installation on engine	309
removal		223	overhaul	308
specifications (and clearances)		35, 343	removal	85-86
trouble shooting		222-223	Clutch, disk and clutch assemblies,	
(See also Air inlet housing (assembly))			installation	193-194
Blower drive gear, hub and support			Connecting rod (s) (assembly)	
assembly		160-162	description	11-15
disassembly		156-159	bearing shells	15
inspection and service		159	bearings and inspection	114-115
Brushes (See specific names and also under components or assemblies)			bushings, replacement	113-114
Buffer spring adjustment (governor)		258	removal	77
Bushings (See specific names)			bearings	75
Bypass circulation		33	specifications	34
			specifications and clearances	342
			(See also Piston and connecting rod assembly)	
			Combustion	
			cycle	8
			fuel injector, use	26-29
			Compression ratio	8

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

<b>C—Cont'd</b>	<b>Page No.</b>		<b>Page No.</b>
Cooling oil, supply of	15	Cylinder liner(s)	
Cooling system		installation	197
description	32-33	measurements	107
maintenance operations, echelon		removal	77-80
breakdown of	38	specifications	34
specifications	36	specifications and clearances	341
Counterweights		use of	10
balancing engine	18		
use	11	<b>D</b>	
Crankpin bearing, specifications	35	Data, tabulated	33-37
Crankshaft		noninterchangeable parts	36-37
gear (and oil slinger)		specifications	33-36
inspection	173	Decontamination	337
installation	186	Definitions of terms used in repair	39
removal	98-99	Description (See names of compo- nents or assemblies)	
general remarks on	11	Diesel principle	6-8
inspection	107-108	combustion engine	6
installation	183-185	combustion cycle	8
main bearings, specifications	35	Disassembly	
oil pump driving gear, removal		air cleaner assemblies	177
of from	169-170	air heater assemblies	288
rear cover (assembly)		air inlet housing assembly	223-226
assembly	172	inspection	232-233
disassembly	172	balance weight cover assembly	166-168
inspection and service	172	balance shaft assembly	164
installation	189	blower assembly	
removal	94	and accessories	226-231
removal	100-104	and attached parts	80-82
Crankshaft oil pump driving gear	170	inspection	232-233
Crating the engine assembly	340	blower drive gear, hub and sup- port	156-159
Cylinder block		camshaft assembly	150-151
cylinder head	18-19	clutch assembly	306-307
inspection and service	175	housing	300-301
installation on engine stand	180-181	crankshaft rear cover	172
Cylinder block and crankcase	9-10	cylinder head	115
Cylinder block end plates		fan drive gear and balance weight assembly	153-156
installation	182-183	fan idler gears	168
removal	100	fan shaft assembly	146-148
Cylinder head (and related assem- blies)		fuel pump assembly	249-251
assembly	133-134	generator assembly	329-331
description	18-19	governor control housing	262-265
disassembly	115	cover and lever assembly	267
inspection and cleaning	126-127	injector assembly	273-277
installing injector hold tube in	130-133	oil cooler and adapter assem- bly	282-283
installation	202-203	oil pressure regulator valve as- sembly	168
removal	68-70	oil pump	134-140
Cylinder head vent			
installation	206		
removal	64-67		

## INDEX

D—Cont'd		Page No.		Page No.
Disassembly—Cont'd			disassembly	42-104
piston and connecting rod as-			end plates, use	10
sembly	109		flywheel, location	11
propeller shaft assembly	311		fuel system	26-31
removal of engine before	41		fuel injector	26-29
secondary fuel filter	175		fuel oil filters	31
starting motor assembly	316-318		fuel oil pump	29-31
water outlet manifold and thermo-			gear train	15
stat assembly	144		timing	18
water pump assembly	244-246		governor	
weight and housing assembly			lubrication	32
(governor)	268-269		operation	32
weight and hub assembly	162		purpose	31
Disassembly of the engine	42-104		type	31-32
(See removal under names of com-			LA engine	
ponents or assemblies and Dis-			installation of on engine stand	214
assembly)			removal of from stand	54
E			lubrication system	20-21
Echelon breakdown of maintenance			filter system	20
operations (See Maintenance op-			oil cooler	21
erations, echelon breakdown of)			passage of oil	21
Electrical system			protection	20
maintenance operations, echelon			main bearings shells, description	10
breakdown of	38-39		maintenance and repair, general	
specifications	36		discussion	107
End bearings			maintenance operations, echelon	
balance shaft	98		breakdown of	
camshaft	187		definition of terms	39
End plates, use	10		tabulated breakdown	37-39
Engine			parts, arrangement of	5
air inlet housing and blower as-			pistons, description	11
semblies, installation of on	243		preparation for use under un-	
air intake system, description	21-26		usual conditions	336
attaching to rotating engine			removal of from rotating stand	210-211
stand	61-62		removal of from tank	41
balance	18		serial numbers	5
camshaft and balance shaft, de-			specifications	33-34
scription and location	15-18		timing	218-220
connecting rods, description	11-15		trouble shooting	40
cooling system, description	32-33		valve and injector operating mech-	
crankshaft, general remarks on	11		anism, description and parts	19-20
cylinder block and crankcase,			water pump	
description	9-10		installation	248
cylinder head, description	18-19		removal of from	244
cylinder liners, use of	10		Engine lifter brackets, removal	115
data, tabulated	33-37		Engine oil tubes, removal	29-61
noninterchangeable parts	36-37		Engine transfer gear housing as-	
specifications	33-36		sembly	
decontamination	337		assembly	295-298
Diesel principle	6-8		disassembly	290-293
combustion cycle	8		inspection	294
			on engine	290

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

<b>E—Cont'd</b>		<b>Page No.</b>		<b>Page No.</b>
Engine transfer gear housing as-			disassembly	144-148
sembly—Cont'd			inspection in service	148
preinstallation	298		Fan shrouds, weight	36
installation	217-218		Filters, fuel oil	20, 31
on engine	298		(See also Secondary fuel filter (and	
overhaul	294		lines))	
removal	45-48		Flywheel and flywheel housing	
from engine	290		installation	192-193
trouble shooting	290		location	11
Engine stand			removal	86-90
installation of cylinder block			Flywheel ring gear, installation	108
on	180-181		Frame and field assemblies (See	
installation of LA engine on	214		Starter frame and field assem-	
Engine trouble shooting (See			blies)	
Trouble shooting)			Friction in governor mechanism,	
Exhaust manifold			elimination of	259
installation	205		Fuel	
removal	68		ignition	6
Exhaust mufflers, weight	36		increasing or decreasing amount	
Exhaust valve inserts			injected	209
inspection and removal	125-126		Fuel injector	
installation	128-129		function in cooling	19
Exhaust valves (assemblies)			location and function	29-31
inspection and reassembly	133		(See also Injectors and Injector	
specifications	34		assembly)	
specifications and clearances	343		Fuel manifolds	118-122
			Fuel oil filters	20, 31
<b>F</b>			Fuel oil pump (See also Fuel pump	
Facilities needed for:			assembly)	
assembly of the engine	179		description and location	29
disassembly of the engine	43		relief valve	29-31
Fan and related parts			specifications	35
installation	215		Fuel pipe	205
removal	50-53		Fuel pump assembly	
Fan bushing, removal and installa-			assembly	252-255
tion	150		disassembly	249-251
Fan drive gear and balance weight			inspection	252
assembly			on vehicle	249
assembly	156		preinstallation	255
disassembly	153-156		installation on vehicle	255
inspection	156		overhaul	252
installation	189		removal from engine	249
removal	95		trouble shooting	249
Fan idler gears	168		Fuel system	
(See also Balance weight cover			description	
(assembly) (and fan idler gears))			injector	26-29
Fan oil pipe			oil filters	31
installation	190		oil pump	29-31
removal	91		maintenance operations, echelon	
Fan shaft assembly			breakdown of	39
assembly	150			

## INDEX

<b>F—Cont'd</b>	<b>Page No.</b>		<b>Page No.</b>
<b>Fuel System—Cont'd</b>		low-speed spring plunger gap adjustment	256-257
precaution for storage	338-339	installation on engine	271
Fuel tubes	59-61	lubrication	32
		operation	32
		preinstallation inspection	271
		purpose	31
		removal from engine	259
		trouble shooting	258-259
		type	31-32
		Grinding valve seats	129-130
		Guide, cam follower, location and function	19
		<b>H</b>	
		Handhole covers, installation	211
		High tension leads	
		installation	212
		removal	61
		Hub and support (See Blower drive gear, hub and support)	
		<b>I</b>	
		Idler gear (assembly)	
		inspection	172-173
		installation	186
		removal	99
		Idling speed, controlling	257-258
		Ignition, method of	6
		Injector assembly	
		assembly	278-279
		control tube and bracket assembly	
		installation	203
		removal	68
		disassembly	273-277
		hole tubes	
		installation	130-133
		removal	123
		inspection	277
		on engine	272
		preinstallation	280-281
		installation on engine	281
		overhaul	277-278
		removal from engine	272
		rocker arm assemblies	133
		trouble shooting	272
		Injectors (See also Injector assembly)	
		balancing	209
		installation	201-202
		removal	70-73



# **ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71 POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

<b>I—Cont'd</b>	<b>Page No.</b>		<b>Page No.</b>
<b>Injectors—Cont'd</b>		<b>governor assembly</b>	
specifications	35	control housing	265
storage	338	cover and lever assembly	267
timing	203	on engine	256-258
<b>Inspection</b>		preinstallation	271
air cleaner assemblies	177	idler gear assembly	172-173
air heater assemblies	288	injector assembly	277
on engine	286	on engine	272
preinstallation	289	preinstallation	280-281
air inlet housing assemblies		rocker arm assemblies	133
disassembled	232-233	main bearings	109
on engine	221-222	oil cooler and adapter assembly	283
balance weight cover and fan		on engine	282
idler gears	168	preinstallation	283
balancer shaft assembly	164	oil pressure regulator valve as-	
blower assemblies		sembly	168-169
disassembled	232-233	oil pump assembly	140
on engine	221-222	oil pump driving gear	170
blower drive gear, hub and support	159	pistons	109-111
camshaft assembly	151-153	rings	111
clutch assembly	207-208	propeller shaft assembly	313
housing assembly	301-302	installing in vehicle	310-311
on engine	299	preinstallation	313
preinstallation	309	secondary fuel filter	175
connecting rod bearings	114-115	starting motor	
crankshaft	107-108	assembly	322-323
gear and oil slinger	173	brushes	322
rear cover	172	frame and field assemblies	321-322
cylinder		on vehicle	314
block	175	solenoid switch assembly	318-320
head	126-127	on vehicle	314
engine components in assembly	179	preinstallation	325
engine transfer gear housing as-		thermostat assembly	144-146
sembly	294	valve guides	125
on engine	290	water drain valve	146
preinstallation	298	water pump assembly	246
exhaust valve assemblies	133	on engine	243
exhaust valve inserts	125-126	preinstallation	248
fan drive gear and balance weight		weight and housing assembly	
assembly	156	(governor)	269
fan shaft assembly	148	weight and hub assembly	162
fuel pump assembly	252	<b>Interchangeability</b>	
on engine	249	crankshafts	11
preinstallation	255	parts	5
generator assembly	333		
brushes	332-333		
frame and field assembly	331-332	<b>Junction plates</b>	
on engine	327	installation	211-213
preinstallation	334	removal	59-61

## INDEX

	Page No.		Page No.
Leakage, prevention of	19	passage to oil cooler	21
Leads (See High tension leads)		Oil bath air cleaners, specifications	36
Liner (See Cylinder liner(s))		Oil cooler and adapter assembly	
Low-speed adjustment for control-		assembly	283
ling engine idling speed	257-258	disassembly	282-283
Lubricating oil cooler	35	inspection	283
Lubricating oil filters, preparation		on engine	282
for storage	339	preinstallation	283
Lubricating oil lines	212-213	installation on engine	283
Lubricating oil pump, specifications		overhaul	283
and clearances	34, 343	removal from engine	282
Lubricating system, maintenance op-		trouble shooting	282
erations	39	Oil cooler (assembly) (See also Oil	
Lubrication		cooler and adapter assembly)	
assembly of components	180	function	21
blower gear and bearings	26	installation	194-195
camshaft, and balancer shaft end		removal	84-85
bearings	18	Oil pan	200
description	20-21	Oil pressure regulator (valve)	
filter system	20	(assembly)	
oil cooler	21	assembly	169
passage of oil	21	disassembly	168
protection	20	inspection and service	168-169
governor	32	installation	200
valve-operating mechanism	20	purpose	20
		removal	73-75
		Oil pump assembly	
		assembly	140-144
		disassembly	134-140
		driven	20
		inlet and outlet elbows, installa-	
		tion	201
		installation	200
		removal	73-75
		(See also Fuel pump assembly)	
		Oil pump driving gear	
		inspection	140, 170
		removal of from crankshaft	169-170
		Oil seals, use	29
		Oil slinger (See gear and (oil	
		slinger) under Crankshaft)	
		Overhaul	
		air heater assemblies	288
		air inlet housing assemblies	233
		blower assemblies	233
		clutch assembly	308
		clutch housing assembly	302
		engine transfer gear housing as-	
		sembly	294
		fuel pump assembly	252
		generator assembly	333

# ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71 POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2

O—Cont'd	Page No.		Page No.
Overhaul—Cont'd		Power transfer, specifications	35
generator assembly—Cont'd		Precautions	
brushes	332-333	assembly of the engine	179
governor		disassembly of the engine	43-45
control housing	265	general	43-45
cover and lever assembly	267	Preinstallation inspection (See under Inspection)	
weight and housing assembly	270	Propeller shaft assembly	
injector assembly	277-278	assembly	313
oil cooler and adapter assembly	283	disassembly	311
propeller shaft assembly	313	inspection	313
solenoid switch assembly	318-320	installing in vehicle	310-311
starter brushes	322	installation in vehicle	313
starting motor assembly	322-323	overhaul	313
water pump assembly	246	removal from the vehicle	311
		trouble shooting	311
		weight	36
		Purge and fuel system, precautions for storage	338-339
<b>P</b>		<b>R</b>	
Packing, shipment, and storage		Radiators, weight	36
depot storage		Reaming valve guides	128
air cleaners	339	Reassembly	
cooling system	339	exhaust valve assemblies	133
cylinder walls, protection	339	injector rocker arm assemblies	133
engines, protection	339	"Rebuild," definition	39
injectors	338	"Repair," definition	39
lubricating oil filters	339	"Replace," definition	39
oil pans and supply tanks	339	Rocker arms	
purge and fuel system	338-339	operation	19
storage battery	339	purpose	18
engine assembly, crated	340	specifications and clearances	343
instructions, general	338	Rotating engine stand	
Piston and connecting rod assembly		attaching engine to	61-62
assembly	115	removing engine from	210-211
installation	197-200	Rotors	26
removal	77		
Piston rings		<b>S</b>	
fitting	111-113	Scavenging system	20
inspection	111	Secondary fuel filter (and lines)	
specifications	34	assembly	175
specifications and clearances		disassembly, inspection, and serv- ice	175
compression	341	installation	205-206
oil control	342	removal	67-68
Pistons		Serial numbers	5
description	11	Shipment (See Packing, shipment, and storage)	
fitting	111	Special tools	344-346
inspection	109-111	Specifications	
position of in combustion	8	power plant	33-36
specifications	34		
specifications and clearances	341		
Ports			
purpose and arrangement of	10		
use of	6-8		
Power plant, weight	36		

## INDEX

<b>S—Cont'd</b>	<b>Page No.</b>		<b>Page No.</b>
<b>Specifications—Cont'd</b>		<b>Timing</b>	
table of	341-343	engine	218-220
<b>Speed</b>		gear train	18
control of by governor	31-32	injectors	203
variations	258-259	<b>Tolerances</b>	341-343
<b>Stand (See Rotating engine stand)</b>		<b>Tools, special</b>	344-346
<b>Starter brushes</b>	322	<b>Trouble shooting</b>	
<b>Starter frame and field assemblies</b>	321-322	air heater assemblies	286
(Starter) solenoid switch assemblies		blower assemblies	222-223
assembly	323-325	clutch housing and clutch assemblies	299
inspection	318-320	blies	299
on engine	314	engine transfer gear housing assembly	290
preinstallation	325	facilities	40
overhaul	318-320	fuel pump assembly	249
removal from engine	314	generator assembly	327-329
<b>Starting motor (assembly)</b>		governor assembly	258-259
assembly	323-325	injector assembly	272
disassembly	316-318	oil cooler and adapter assembly	282
inspection and overhaul	322-323	procedure	40-43
inspection		propeller shaft assembly	311
preinstallation	325	starting motor	314
while on vehicle	314	water pump assembly	244
installation on engine	325		
removal	84, 314	<b>U</b>	
trouble shooting	314	Unusual conditions, preparing engine for use under	336
<b>Storage (See Packing, shipment, and storage)</b>			
		<b>V</b>	
<b>T</b>		<b>Valve and injector operating mechanism</b>	
<b>Table</b>		description and parts	19-20
specifications and clearances and wear limits	341-343	lubrication	20
tension wrench	344	<b>Valves</b>	
<b>Tachometer drive</b>		guides	
installation	188	inspection and removal	125
removal	91	installation and reaming	127-128
<b>Tank</b>		lash adjustment	205
installation of engine assembly in	335	lifter assemblies, removal	122-123
removal of engine assembly from	41	removal	118
<b>Tension wrench table</b>	344	rocker cover	19
<b>Testing</b>		seats, grinding	129-130
grounded armature (generator)	327-328	<b>Vibration damper assembly</b>	
valve seats	129-130	installation	189-190
<b>Thermostat(s) (assembly)</b>		removal	92-94
assembly	146	<b>Voltage and current regulator</b>	36
control of water temperature	33		
disassembly	144	<b>W</b>	
inspection	144-146	<b>Water bypass tube</b>	
servicing	146	installation	210
<b>Three-way tee, installation</b>	213	removal	64

**ORDNANCE MAINTENANCE—GENERAL MOTORS TWIN DIESEL 6-71  
POWER PLANT FOR MEDIUM TANKS M3A3, M3A5 AND M4A2**

<b>W—Cont'd</b>	<b>Page No.</b>		<b>Page No.</b>
Water drain valve		Water temperature, control	33
inspection	146	Weight and housing assembly (gov-	
service	146	ernor)	
Water outlet manifold		assembly	270-271
assembly	146	disassembly	268-269
disassembly	144	inspection	269
Water jackets	9, 33	overhaul	270
Water pump (assembly)		Weight and hub assembly	
assembly	246-248	assembly	164
disassembly	244-246	disassembly	162
function in cooling system	32-33	inspection and service	162
inspection	246	installation	188-189
on engine	244	removal	95
preinstallation	248		
installation on engine	248	Weights	
overhaul	246	balance	18
removal from engine	244	specifications	36

[ A.G. 062.11 (6-6-42)  
O.O. 461 23097 O.O. (9-10-42) ]

**BY ORDER OF THE SECRETARY OF WAR:**

**G. C. MARSHALL,**  
*Chief of Staff.*

**OFFICIAL:**

**J. A. ULIO,**  
*Major General,*  
*The Adjutant General.*

**DISTRIBUTION:**

**D 17 (5); R 9 (2); Bn 18 (2); IBn 9 (1); IC 9 (3)**  
**(For explanation of symbols, see FM 21-6.)**